

**GOLDNEXT
11507 Cube
Power Socket**



GOLDNEXT 11507 Cube Power Socket User Manual

[Home](#) » [GOLDNEXT](#) » GOLDNEXT 11507 Cube Power Socket User Manual 

Contents

- [1 GOLDNEXT 11507 Cube Power Socket](#)
- [2 Product Diagram](#)
- [3 Specification](#)
- [4 Package Contents](#)
- [5 Getting Started](#)
- [6 Service](#)
- [7 Safety Caution](#)
- [8 Warranty](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)


GOLDNEXT

GOLDNEXT 11507 Cube Power Socket



Thank you for purchasing GOLDNEXT products. Please read this user manual carefully and keep it for future reference.

Product Diagram



Specification

- **Model:** 11507
- **Name:** Cube Power Socket
- **Material:** PC (fire resistant)
- **Interface:** 4 AC Outlets+1 USB-A+1 USB-C Ports
- **Input Voltage:** Max 16A/250V~50/60Hz
- **Power:** Max 3680W
- **Rated current:** Max 16A
- **USB Output:** 5V3A 9V2A 12V1.5A (18W Max)
- **Type C Output:** 5V3A 9V2.22A 12V1.67A (20W Max)
- **Total Output:** Max 5V 3.1A
- **Size:** 76.2mm*76.7mm*114mm
- **Weight:** 200g
 - **Note:** The adapter does not convert voltage.

Please make sure the input voltage range of your device is 100V-250V.

Package Contents

- Cube Power Socket x1
- User's Manual x1

Getting Started

1. Take the socket cube out of the packaging.
2. Check whether the packaging is complete.
3. Check the cube socket for damage. If it is, do not use the socket.
4. Insert the cube socket into a properly installed grounded receptacle.
5. Connect the devices to the designated sockets of the cube power socket.

Service

- 18 month warranty
- Lifetime support
- If you have any questions or suggestions about our products, please send an email to: Goldnext-store@outlook.com.

Safety Caution

1. The adapter cannot be used as a voltage converter. Please check if your mobile device is suitable for local voltage before use.
2. Do not expand a socket cube with another socket cube in a wall socket.
3. Improper connection to an AC outlet can result in a short circuit and/or potential injury.
4. Do not bend the blade or Pins of the plug.
5. Do not attempt to repair, disassemble, or modify the unit yourself or by outside personnel.

6. Do not use electrical equipment that has a grounded circuit.
7. To prevent overheating, please do not cover! Do not use the unit in damp or humid environments.
8. Keep the socket cube away from easily flammable materials and objects.
9. Keep away from children when charging to avoid electric shock.
10. For indoor use only.

Warranty

Our company provides customers with a warranty of 18 MONTHS from the date of purchase.



Email: Goldnext-store@outlook.com.

Warranty Card

- Please keep this warranty card carefully and fill it out accurately.
- Include it with your proof of purchase when you return the product.

Name:

Street:

Zip Code, City, Country:


Phone number:

Email:

Date of Purchase/Order Number:

Reason for return:

Documents / Resources

	<p>GOLDNEXT 11507 Cube Power Socket [pdf] User Manual</p> <p>11507 Cube Power Socket, 11507, Cube Power Socket, Power Socket, Socket</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.