

Goldtouch
Elite Adjustable
Keyboard



Goldtouch Elite Adjustable Keyboard User Guide

[Home](#) » [Goldtouch](#) » Goldtouch Elite Adjustable Keyboard User Guide 

Contents

- [1 Goldtouch Elite Adjustable Keyboard](#)
- [2 Step 1](#)
- [3 Step 2](#)
- [4 Step 3](#)
- [5 Step 4](#)
- [6 Troubleshooting](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

Goldtouch

Goldtouch Elite Adjustable Keyboard



Follow these steps to configure your keyboard.

Step 1

Squeeze the keyboard lever to start making your adjustments.



Step 2

While the handle is squeezed, pull the two halves of the keyboard apart until you reach the angle where your wrists are straight horizontally. This is your splay angle. Release the handle.

Step 3

With the handles squeezed, tent the keyboard upwards until you determine the angle where any tension in the hands, wrists, and forearms disappears. Release the handle.

Step 4

You're ready to start typing!



Troubleshooting



- 1. The Elite Keyboard has two different Layout options: Select the correct operating system on the back side of the keyboard. PC should be selected for PC devices and Mac should be selected for Mac devices.
- 2. Default and Alternate. The Elite ships in Default mode. To utilize the Alternate mode, use the switch on the rear of the keyboard. This changes the select navigation control key functions to the left side. Check the Elite Keyboard User Manual for additional instructions.

Documents / Resources

	Goldtouch Elite Adjustable Keyboard [pdf] User Guide Elite Adjustable Keyboard, Keyboard, Elite Keyboard, Adjustable Keyboard
	Goldtouch Elite Adjustable Keyboard [pdf] User Guide 2024, Elite Adjustable Keyboard, Elite Keyboard, Adjustable Keyboard, Keyboard

References

- [Support Videos - Goldtouch](#)

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.