





goobay 68906 Protective Contact Socket With Switch User **Manual**

Home » goobay » goobay 68906 Protective Contact Socket With Switch User Manual



Contents

- 1 goobay 68906 Protective Contact Socket With **Switch**
- 2 Safety instructions
- 3 Description and function
- **4 Specifications**
- 5 Intended use
- **6 Preparation**
- 7 Connection and operation
- 8 Maintenance, Care, Storage and Transportation
- 9 Disposal instructions
- 10 EU Declaration of Conformity
- 11 Symbols used
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts



goobay 68906 Protective Contact Socket With Switch



Safety instructions

- The user manual is part of the product and contains important information for correct use. Read the user manual completely and carefully before use.
- The user manual must be available for uncertainties and passing the product.
 Keep this user manual.
- Voltage-free only when the plug is pulled out.
 In case of emergency, after use and during thunderstorms, disconnect the power plug directly at the from the socket directly at the plug housing.
 - Do not open the housing.
 - Do not modify product and accessories.
 - Do not short-circuit connectors and circuits.
- A defective device must not be put into operation, but must be secured against unintentional further use.
 - Only use the product, product parts and accessories if they are in perfect condition.
 - Avoid extreme loads such as heat and cold, wetness and direct sunlight, microwaves as well as vibrations and mechanical pressure.
 - In case of questions, defects, mechanical damage, malfunctions and other problems that cannot be solved by the accompanying documentation, contact the dealer or manufacturer.
 - Installation, disassembly, maintenance and repair work may only be carried out by qualified electrical specialists.
 - Compare technical data of product, power supply and peripheral devices. They must be identical.
 - · Do not plug in one after the other.
 - Never touch the power plug with wet hands.
 - Do not operate covered.
 - Do not operate in potentially explosive atmospheres.
 - Use only in dry conditions.
- Not suitable for children. The product is not a toy!
 Secure packaging, small parts and insulating material against accidental use.

Description and function

Product

This product is a protective contact socket with switch for DE plug systems. With illuminated safety switch for switching on and off (1-pin)

Scope of delivery

Protective contact socket 16 A, User Manual

Operating Elements



- 1. ON/OFF switch
- 2. Protective contact socket
- 3. Protective contact plug
- 4. Housing

Specifications

Article number	68906	
Connection type 1	1x Protective contact socket (Type F, CEE 7/3)	
Connection type 2	1x Safety power plug (Type F, CEE7/4)	
Rated voltage / current	250 V ~, 50 Hz, 16 A max.	
Max. permissible load capacity (W)	3500	
Protection class Protection level	I P20	
Dimensions (LxWxH) [mm]	77 x 76 x 51	
Weight (g)	77	

Intended use

We do not permit using the device in other ways like described in chapter "Description and Function" or in the "Safety Instructions". Use the product only in dry interior rooms. Not attending to these regulations and safety instructions might cause fatal accidents, injuries, and damages to persons and property.

Preparation

- 1. Check the scope of delivery for completeness and integrity.
- 2. Compare the specifications of all used devices and ensure compatibility.

Connection and operation

- 1. Connect your household appliances to the protective contact socket.
- 2. Connect the protective contact plug to an easily accessible mains socket.
- 3. Switch on the protective contact socket.
- 4. Disconnect all cable connections after use and turn off the switch of the protective contact socket.

Maintenance, Care, Storage and Transportation

The product is maintenance-free.

NOTICE!

Material damage

- Disconnect the power plug from the socket before each cleaning.
- Only use a dry and soft cloth for cleaning.
- Do not use detergents or chemicals.
- Store the product out the reach of children and in a dry and dust-protected ambiance when not in use.
- Store cool and dry.
- · Keep and use the original packaging for transport.

Disposal instructions

Product

According to the European WEEE directive, electrical and electronic equipment must not be disposed with consumers waste. Its components must be recycled or disposed apart from each other. Otherwise contaminative and hazardous substances can damage the health and pollute the environment. As a consumer, you are committed by law to dispose electrical and electronic devices to the producer, the dealer, or public collecting points at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the user manual, or at the packaging alludes to these terms. With this kind of waste separation, application, and waste disposal of used devices you achieve an important share to environmental protection.

WEEE No: 82898622

Packaging

Packaging can be disposed of free of charge at the suitable collection points – paper belongs in paper bins, plastics belong in yellow sacks and glass belongs in used glass bins.

DE4535302615620

EU Declaration of Conformity

EWith the CE sign Goobay®, a registered trademark of Wentronic GmbH ensures, that the product is

conformed to the basic European standards and directives.

Symbols used

For indoor use only	IEC 60417- 5957	
Alternating current	IEC 60417- 5032	\sim
Recycling	ISO 7001 - PI PF 066	3
Protective earth; protective ground (Class I equipment)	IEC 60417- 5019	

REV2024-11-11 V2.1fw

Subject to change without notice.

Goobay®

by Wentronic GmbH | Pillmannstraße 12 38112 Braunschweig | Germany cs@wentronic.com

Documents / Resources



goobay 68906 Protective Contact Socket With Switch [pdf] User Manual 68906 Protective Contact Socket With Switch, 68906, Protective Contact Socket With Switch, C ontact Socket With Switch, Socket With Switch, With Switch

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.