



googboy 60928 Speaker Switch Box User Manual

[Home](#) » [googboy](#) » googboy 60928 Speaker Switch Box User Manual 

Contents

- 1 [googboy 60928 Speaker Switch Box](#)
- 2 [Safety Instructions](#)
 - 2.1 [General](#)
 - 2.2 [Warning levels](#)
- 3 [Description and Function](#)
 - 3.1 [Product](#)
 - 3.2 [Scope of delivery](#)
 - 3.3 [Operating elements and product parts](#)
 - 3.4 [Specifications](#)
- 4 [Connecting](#)
- 5 [Operating](#)
 - 5.1 [Maintenance, Care, Storage and Transport](#)
- 6 [Liability Notice](#)
- 7 [Disposal Notes](#)
- 8 [Documents / Resources](#)
- 9 [Related Posts](#)





Safety Instructions

General

- Read the user manual completely and carefully before use. The user manual is part of the product and contains important information for correct use.

- Keep this user manual.

The user manual must be available for uncertainties and passing the product.

Risk of electric shock

- Do not open the housing.
- Do not modify product and accessories.
- Do not short connectors and circuits.
- Use product, product parts and accessories only in perfect condition.

A defective device may not be put into operation, but must be disconnected from mains and protected against further use.

- In case of questions, defects, mechanical damage, trouble and other problems, non-recoverable by the documentation, contact your dealer or producer.

- **Target group information**

Not meant for children. The product is not a toy!

- Secure packaging, small parts and insulation against accidental use.
- Avoid stresses such as heat and cold, moisture and direct sunlight vibration and mechanical pressure.

Warning levels

CAUTION: Warnings against hazards that may result in injuries in case of non-observance.

NOTICE: Warnings against hazards that may result in material damage in case of non-observance.

Description and Function

Product

- For the connection of up to 2 (Model 60928) or up to 4 (Model 11934) pairs of speakers.
- Speaker pairs can be used individually or together
- Colour-coded clamp connectors

Scope of delivery

Speaker switch box, user manual

Operating elements and product parts



Fig. 2: Operating elements

1. ON / OFF switch
2. Stereo speaker connections
3. Amplifier connections

Specifications

Article number	60928	11934
Inputs (amplifier)	2x 2 Spring clips (R/L)	
Outputs (speaker)	2x 4 clamp connections (R/L), Ø 4,0 mm ²	4x 4 clamp connections (R/L), Ø 2,5 mm ²
Input power amplifier (W)	200	
Input power 2 speaker (W)	100 x 2	
Input power 4 speaker (W)	50 x 4	
Impedance (Ω)	4,0-8,0	
Operating temperature (°C)	0,0 ~ +45,0	
Dimensions (mm)	175,0 x 114,0 x 49,0	175,0 x 114,0 x 49,0
Net to weight (g)	335,0	362,0

We do not permit using the device in other ways like described in chapter Description and Function. Use the product only in dry interior rooms. Not attending to these regulations and safety instructions might cause fatal accidents, injuries, and damages to persons and property.

Connecting

CAUTION: Risk of injury by stumbling and falling

- Route the cable safely.

- Install the system and devices attached to it in a way that persons cannot be injured, or objects not be damaged for example by dropping or stumbling.

NOTICE: Material damage

- Only place on a level and non-slip surface.
- Observe the polarity of your amplifier.

The negative output of the amplifier must be connected to the black negative pole of the amplifier input of the switch box.

Reversing the polarity between amplifier and switch box may result in a short circuit at the amplifier output!

1. Compare the specifications of all used devices to ensure compatibility
2. Check the scope of delivery for completeness and integrity.
3. Connect the speaker cables to the speaker outputs (2) of the switch box, taking into account the correct polarity, each according to requirements and model.

The connections for the pairs of speakers are numbered and colourcoded.

4. Connect your amplifier to the amplifier input (3) of the speaker switch box, observing the correct polarity.
The left and right channels are identified accordingly and are colourcoded

Operating

Depending on model the 2 or 4 pairs of speakers can be individually or jointly switched ON and OFF with the toggle switches (1).

Maintenance, Care, Storage and Transport

The products are maintenance-free.

CAUTION: Material damages

- Clean only with a dry, soft cloth.
- Do not use cleaning agents and chemicals.
- Store cool and dry.
- Store the product out the reach of children and in a dry and dust-protected ambience when not in use.
- Keep and use the original packaging for transport

Liability Notice

We reserve the right to printing errors and changes to product, packaging or product documentation.

- See our terms of warranty. These are available in their current form under the given contact details.

Disposal Notes


According to the European WEEE directive, electrical and electronic equipment must not be disposed with

consumers waste. Its components must be recycled or disposed apart from each other. Otherwise contaminative and hazardous substances can pollute our environment.

As a consumer, you are committed by law to dispose electrical and electronic devices to the producer, the dealer, or public collecting points at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product ,in the user`s manual, or at the packaging alludes to these terms.
With this kind of waste separation, application, and waste disposal of used devices you achieve an important share to environ mental protection.

WEEE No: 82898622

Documents / Resources



[googboy 60928 Speaker Switch Box](#) [pdf] User Manual
60928, 11934, Speaker Switch Box