



Google GWT9R Smart Watch User Guide

[Home](#) » [Google](#) » Google GWT9R Smart Watch User Guide 

Google GWT9R Smart Watch User Guide



Contents

- [1 Let's get started](#)
- [2 What's included](#)
- [3 Basic safety](#)
- [4 Proper Handling and Usage](#)
- [5 Service and Support](#)
- [6 BATTERY CHARGER EFFICIENCY](#)
- [7 Arbitration \(USA only\)](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Let's get started

1. Unlock your phone and turn on Bluetooth®
2. Press and hold the crown on your watch for 3 seconds
3. Follow steps on your phone to finish setup



Need help?


Make sure your phone is running Android 8+ and you have the Google Pixel Watch app. For more help, **visit** g.co/pixelwatch/setup

Put on your watch



1. Slide the band through the outer loop
2. Press the metal peg into a hole
3. Tuck in the band. If it's too long, try the other band

Remove your watch



1. Untuck the band
2. Bend the band back to release the peg

Detach a band



1. Turn your watch over
2. Press the band secure button, then slide the band over the band secure button
3. Repeat on other side

Attach a band



1. Turn your watch over
2. Use the band to press the band secure button, then slide the band into place
3. Repeat on other side

What's included

Google Pixel Watch with large band



Small band



USB-C® Magnetic Charging Cable



Cleaning

Turn off your watch. Wipe the face and band with a damp cloth (no soap). Let air-dry or wipe with a nonabrasive cloth. For more cleaning tips, visit g.co/pixelwatch/care

We're here for you

For online help and support, visit g.co/pixelwatch/help

Safety, Warranty and Regulatory Guide for Google Pixel Watch and Google Pixel Watch USB- C Magnetic Charging Cable

This booklet provides important safety, regulatory, and warranty information that you should read before using your Google Pixel Watch. You can find an online version of this document at g.co/pixelwatch/regulatory

Basic safety



WARNING: HEALTH AND SAFETY INFORMATION

To avoid damaging your device, accessories, or any connected devices and to reduce the risk of personal injury, discomfort, property damage or other potential hazards, follow the precautions below and those found in the Google Pixel Watch Safety Information at g.co/pixelwatch/regulatory:

- Handle your Google Pixel Watch and the Google Pixel Watch USB-C Magnetic Charging Cable with care. You may damage the Google Pixel Watch or its battery, or the Google Pixel Watch USB-C Magnetic Charging Cable, if you disassemble, drop, bend, burn, crush or puncture the device. Do not use a device with a cracked screen or damaged enclosure. Be sure the charger and device are well ventilated when in use or charging. Using a damaged Google Pixel Watch, damaged cables or chargers or charging when moisture or debris is present, may cause overheating, fire, electric shock, injury or damage to your device or other property. If the device gets wet, do not attempt to dry it using an external heat source. Do not charge your Google Pixel Watch when wet or in direct sunlight. Your devices are designed to work best in ambient temperatures between 32° and 95° F (0° and 35° C) and should be stored between ambient temperatures of -4° and 113° F (-20° and 45° C). Do not expose the device to temperatures above 113° F (45° C) as this may damage the device, overheat the battery, or pose a risk of fire.
- These devices must be used with a certified AC adapter with Limited Power Source (LPS) output per IEC 60950-1 and/or PS2 classified output per IEC 62368-1, rated: 5 Volts DC, maximum 1 Amp. Only charge your Google Pixel Watch with the included charging cable or compatible charging accessories, which are available on the Google Store or at Google authorized resellers (look for Google's •made for• badge). Failure to use compatible charging accessories can cause fire, electric shock, injury, or damage to the device and the accessories.
- Do not place metallic or magnetic objects between the wireless charging surface and your Google Pixel Watch, as this could cause heating of the other object or cause your device not to charge properly.
- Strangulation and choking hazard. Google Pixel Watch and the Google Pixel Watch USB-C Magnetic Charging Cable are not toys. Your device and its accessories may contain (or may come with) small parts, plastic, glass, or metal elements, and parts with sharp edges that may cause an injury or create a choking hazard. Google Pixel Watch also comes with cords that may create a strangulation hazard. Children have strangled on cords. Keep the cords out of the reach of children (more than 3 feet/ 1 meter away) and do not allow them to play with the device and its accessories. They could hurt themselves or others, or could accidentally damage the device. Seek medical attention immediately if small parts are swallowed or injury occurs.
- Some people may experience reactions to substances found in wearable products that are in extended contact

with the skin. This can be due to allergies, skin irritants (like soap, sunscreen, or sweat), or other causes. Keep your Google Pixel Watch and its bands clean and dry, do not wear Google Pixel Watch too tightly, and periodically remove it to reduce the chance of skin irritation. If you experience skin irritation or discomfort where your device is in contact with your skin, please remove the device and consult a doctor before wearing it again.

- Google Pixel Watch and its charger generate heat during normal operation and comply with applicable surface temperature standards and limits. When plugged into a power source or using a cellular connection, the device may become warm. Avoid prolonged, direct or indirect skin contact when the device is charging because exposing skin to warm surfaces for a long period of time may cause discomfort or burns. While your device is charging, do not sleep on or with your device or its charger, or cover them with a blanket or pillow. Be aware of this issue if you have a physical condition that affects your ability to detect heat against your skin.
- Prolonged exposure to loud sounds (including music) can cause hearing loss. To prevent possible hearing damage, avoid listening at high volume for prolonged periods of time. Continued exposure to high volumes and background noise can make loud sounds seem quieter than they actually are. Check the volume before using headphones or earphones.



FITNESS RELATED FUNCTIONS

Your Google Pixel Watch may record your fitness activities and other physiological functions. These features are intended only for general fitness and wellness purposes and should not be used as a substitute for professional medical judgment. This device is not a medical device and is not designed or intended for use in the diagnosis of any disease or condition, or in the cure, mitigation, monitoring, prediction, treatment, or prevention of any disease or condition, or as compensation for any injury or disability.

BATTERY

Google Pixel Watch contains a rechargeable lithium-ion battery, which is a sensitive component that can cause injury if damaged. Do not attempt to remove the battery or disassemble your device. Contact Google to have your damaged device repaired or replaced. For contact information, visit g.co/pixelwatch/contact. You may be provided with a new or refurbished replacement device after repair or service.

MEDICAL DEVICE INTERFERENCE

Your device uses radios and other components that emit electromagnetic fields, and contains magnets. Some Google Pixel Watch bands may also contain magnets. These electromagnetic fields and magnets may interfere with pacemakers and other implanted and nearby medical devices. Always keep the device and its charger at a safe distance away from the pacemaker or other implanted medical device. If you have questions about using your Google Pixel Watch near your pacemaker or other implanted or nearby medical devices, consult your healthcare provider before using your device. If you suspect your device is interfering with your pacemaker or medical devices, turn off your device and consult your doctor for information specific to your medical device. See g.co/pixelwatch/regulatory for more information.

Proper Handling and Usage

CARE AND CLEANING

Turn off your watch. Wipe your device with a damp cloth (no soap). Let air-dry or wipe with a non-abrasive cloth. For more cleaning tips, visit g.co/pixelwatch/care

WATER RESISTANCE

Your Google Pixel Watch is designed to comply with water protection rating 5 ATM under ISO Standard 22810:2010 when manufactured, but it is not waterproof. Water resistance is not a permanent condition, and decreases or is lost over time due to normal wear and tear, repair, disassembly, or damage. Dropping or otherwise impacting your device may result in a loss of water resistance. Deep water activities such as scuba

diving or snorkeling, activities where high velocity streams of water may be present, such as diving, surfing, or water skiing, and exposure to water at high temperature, such as in a steam room or hot tub, may damage your device and should be avoided. Do not expose your device to substances such as sunscreen, soap, lotion, oil, insect repellent, perfume, alcohol or other liquids which may compromise water resistance or otherwise damage your device. Clean and dry your device after exposure to liquids. The charger and other accessories, including some Google Pixel Watch bands are not water resistant and should not be exposed to liquids.

Service and Support

For online help and support, visit g.co/pixelwatch/service. If you send your device for service, you might receive a replacement device (in place of your original device). Devices presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair devices. Repair or replacement will result in the loss of user-generated data.

BATTERY CHARGER EFFICIENCY



© 2021 Google LLC. Pixel, Google, G logo and related marks and logos are trademarks of Google LLC. Fitbit and the Fitbit logo are registered trademarks or trademarks of Google LLC and/or its affiliates in the United States and other countries. [usa-cs](#) is a registered trademark of USB Implementers Forum. Wi-Fi and the Wi-Fi logo are trademarks of Wi-Fi Alliance. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. All other trademarks are the property of their respective owners.

Google Consumer Hardware Limited Warranty – USA and Canada

If there are any differences between this limited Warranty included in the box with your product and the online limited Warranty available at g.co/devicewarranty, then the online limited Warranty will supersede the terms of this in-the-box warranty. This limited Warranty applies only if you are a consumer and purchased your Google-branded product ("Google Product") in the United States or Canada.

What will Google do? (THIS IS YOUR EXCLUSIVE REMEDY) If a defect covered by this Limited Warranty arises and you return your Google Product as directed by Google during the limited Warranty period (which is one year for new Google Products and ninety days for Refurbished Google Products), Google will elect in its sole discretion and to the extent permitted by law to repair your Google Product using new or refurbished parts, replace your Google Product with a new or refurbished Google Product functionally at least equivalent to yours, or accept the return of your Google Product in exchange for a refund of the purchase price you paid for your Google Product. If Google repairs or replaces your Google Product, the repaired or replaced Google Product will continue to be warranted for the remaining time of the original warranty period. All returned parts for which you have received a replacement will become the property of Google. Repair or replacement may result in loss of data. Nothing in this limited Warranty will reduce or otherwise affect your statutory rights in relation to your Google Product.

What does this warranty not cover? This Limited Warranty is only valid and enforceable in locations where the Google Product is sold and will apply only if you purchased your Google Product from Google or its authorized resellers. This Limited Warranty only applies to hardware components (and not any software elements) of Google Product. This Limited Warranty also does not apply to any consumable parts, such as batteries or protective coatings, that due to their nature diminish over time, unless failure has occurred due to a defect in materials or workmanship, nor to any cosmetic damage unless failure has occurred due to a defect in materials or workmanship. This Limited Warranty does not apply to damage caused by: (1) normal wear and tear; (2) accidents; (3) misuse (including failure to follow product documentation); (4) neglect; (5) disassembly; (6) alterations; (7) servicing other than by Google-authorized technicians; and (8) external causes such as, but not limited to: liquid damage, exposure to sharp objects, exposure to excessive force, anomalies in the electrical current supplied to the Google product, and extreme thermal or environmental conditions. Liquid damage voids this Limited Warranty. This Limited Warranty does not guarantee that use of the Google Product will be uninterrupted or error-free. The ninety-day Limited Warranty Google provides for Refurbished Google Products is


not applicable to Google Products refurbished by third parties not authorized to do so by Google, even if sold by a Google authorized reseller.

Arbitration (USA only)

NOTICE OF ARBITRATION

In accordance with the Google Arbitration Agreement – Devices, Related Accessories, and Related Subscription Services (“Arbitration Terms”) set forth at g.co/devicearbitration, you acknowledge and agree that disputes relating to your Google device, related accessories, and related subscription services for your Google device (“Google Device”) will be resolved through BINDING ARBITRATION on an individual, non-class basis, unless you have opted out or another exception applies as described in the Arbitration Terms. For disputes subject to arbitration, you agree to first send a written notice of the dispute by certified U.S. Mail or by Federal Express (or international equivalent) to Google’s address for notice, Google LLC, Legal Department – Hardware Arbitration, c/o Corporation Service Company, 2710 Gateway Oaks Drive, Suite 150N, Sacramento, CA 95833. The notice has to include, if available: (a) the name of the person making the claim, (b) the type of Google Device, as applicable, (c) the serial number of the Google Device, (d) the email address used to activate the Google Device, as applicable, (e) a description of the nature and basis of the claim, (f) the result that is desired (e.g., an amount of money), and (g) the case number(s) assigned by Google to track previous attempts to resolve the dispute, if there is one. We each agree to try to resolve the claim, but if we can’t do that within 60 days after the notice is received, you or Google may initiate an arbitration proceeding by following the American Arbitration Association (“AAA”) Rules. Unless the parties agree otherwise, your demand for arbitration must be sent to Google’s address for notice and entitled “Demand for Arbitration.” Google will send demands for arbitration to you at the e-mail address provided in the notice of the dispute.

Documents / Resources

	Google GWT9R Smart Watch [pdf] User Guide GWT9R Smart Watch, GWT9R, Smart Watch, Watch
---	---