

GOPPER RV Awning Shade Screen User Manual

Home » GOPPER » GOPPER RV Awning Shade Screen User Manual





User Manual-Gopper RV Awning

Contents

- 1 Introduction
- 2 Unpacking andUnfolding
- 3 Installing the RVAwning
- 4 Maintenance and Care
- 5 Documents / Resources
 - **5.1 References**

Introduction

Thank you for choosing Gopper RVAwning Sunshade Screen!

This user manual aims to provide clear and simple instructions for setting up and securing your RV Awning. Please read the following steps carefully before proceeding.

Unpacking and Unfolding

Step 1: Open the black carry bag and ensure that all the contents are included. The package should contain the following items:

- RVAwning Sunshade Screen
- Carry bag
- · Awning Stakes
- · Bungee cords

Step 2: Check the contents to ensure everything is complete.

Step 3: Unfold the RVAwning Sunshade Screen. Take care not to force or tug on the fabric. Gently extend it to its full length.



Installing the RVAwning

Step 1: Open the awning so that the open slot access is exposed below the awning arm.

Step 2: Slide the Poly-cord into the awning slot. Move it along the slot until it is securely in place.





Step3: To prevent the awning from blowing up in the wind, use the supplied stakes and bungee cords. Insert the stakes into the ground at suitable points along the base of the sunshade. Attach the bungee cords to the awning and secure them to the stakes. Make sure the cords are taut but not overly stretched.



Maintenance and Care

- Avoid placing excessive weight on the RV awning.
- Regularly inspect and remove any debris or leaves that may accumulate on the fabric to maintain its longevity.
- Do not leave the RV awing installed during heavy rain or extreme weather conditions, as it may become damaged.

We hope this user manual has provided you with the necessary instructions to set up and secure your RV Awning! Enjoy your outdoor adventures with Gopper RV Awning!



Documents / Resources



GOPPER RV Awning Shade Screen [pdf] User Manual RV Awning Shade Screen, RV, Awning Shade Screen, Screen

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.