



GoPro Display Mod User Manual


[Home](#) » [Support](#) » GoPro Display Mod User Manual 

Contents

- [1 GoPro Display Mod User Manual](#)
- [2 The Basics](#)
- [3 Battery](#)
 - [3.1 CHARGING](#)
 - [3.2 BATTERY LIFE](#)
- [4 Mounting](#)
 - [4.1 FOLDING DESIGN](#)
- [5 Using Your Display Mod](#)
- [6 DOWNLOAD](#)
- [7 References](#)
- [8 Related Posts](#)


GoPro Display Mod User Manual

The Basics



1. USB-C Port
2. Power Button
3. Micro-HDMI Cable
4. Battery Status Indicator

Battery



CHARGING


Connect your Display Mod to a USB charger or computer using the included USB-C cable. It will take about 1 to 1.5 hours to fully charge the battery. Charge time will vary depending on your charging method. Charging with a computer will take longer than using a standard phone charger. You can see the charge status by checking the battery status indicator .

BATTERY LIFE


The Display Mod battery can power the screen continuously for up to 2 hours. Battery life may vary based on usage and other external conditions.

Heads Up: The battery status indicator shows your Display Mod's battery life. Check your camera's touch screen to see your camera's battery life.

Mounting



Note: Camera and Media Mod are not included.




FOLDING DESIGN

Screen folds down when not in use.

Using Your Display Mod

Press the Power button on your Display Mod to turn it on and see the live view from your camera.

Heads Up: Your Display Mod will turn itself off if it doesn't receive a signal from your camera for more than 5 minutes.



SWITCHING SCREENS

Press the Power button when your Display Mod is on to switch back and forth between your camera's screen and Display Mod screen.

Heads Up: Only one screen can be active at a time. Camera controls can only be accessed with your camera's touch screen.

POWERING OFF

Press and hold the Power button for 4 seconds.

RESETTING YOUR DISPLAY MOD

Press and hold the Power button for 8 seconds.

WARNING: Display Mod is not waterproof.



DOWNLOAD

GoPro Display Mod User Manual – [[Download PDF](#)]

References

- [User Manual](#)