



gosund EP2 10A EU Wifi Smart Power Plug Socket User Manual

[Home](#) » [gosund](#) » gosund EP2 10A EU Wifi Smart Power Plug Socket User Manual 



EP2 10A EU Wifi Smart Power Plug Socket



User Manual

Since this device only supports a 2.4G Wi-Fi connection, please ensure that the mobile phone and the device are connected to the 2.4G Wi-Fi simultaneously.

Contents

- 1 Introduction
- 2 Specifications
- 3 Main Features
- 4 Pairing
- 5 Warnings and Precautions
- 6 Warranty Conditions
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts

Introduction



- 1. ON/OFF button
- 2. Flame-resistant material
- 3. Power plug
- 4. Socket panel

Specifications

Model	EP2
Rated Voltage	230V~50/60Hz
Rated Current	Max. 10A
Wi-Fi Frequency	2.4GHz
Power Output	Max. 2300W

Main Features



Voice control



Control through the
app



Scheduled control



Family sharing



No hub required



Small size



Group & scenes
customization



V0 fireproof materials

Download the Gosund app

You can either search for “Ground” in the App Store or Google Play, or you can scan the following QR code to enter the download page.



<https://smartapp.tuya.com/gosundsmart>

Pairing

- Open the Ground app and create your Ground account.
- Turn on the plug and put it close to the router when pairing.
- Press and hold the ON/OFF button for five seconds and release it when the plug starts blinking fast to enter the network pairing mode.

You can add a new device in two ways.

You can tap the “+” symbol in the upper right corner and select “Auto Scan”. Or you can tap the “+” symbol in the upper right corner, select “Add Manually”, and then select “Ground EP2”. Follow the instruction in the app to complete the operation.

Connecting with Alexa

First, make sure that your Alexa device is powered on and connected to a 2.4GHz Wi-Fi network. Then, open the Amazon Alexa app and select “skills & games”. Click the search icon and enter “Ground”. After finding Ground, click on “Enable” and connect your Ground account to enable this skill. The device can now be controlled through Alexa.

Connecting with Google Assistant

First, open the Google Assistant app and login in. Tap your account name in the upper right corner, then click on "Devices" in order to add a new device. Find "link a smart home device" and click on it. Enter "Ground" in the search bar and click on "Ground smart". Then link your Gosund account with your Google Assistant account. This device can now be controlled through Google Assistant.

Reset

Turn on the power, hold the switch/pairing button for eight seconds, and let go when the socket starts to flash quickly. The reset is now successful.

When the socket is in a new network environment, you need to restore the factory settings, and then reconnect to the network.

Warnings and Precautions

- Keep the device out of reach of children and pets.
- Do not use this product in humid environments or outdoors. It's for indoor use only.
- Do not place this product near heating devices, such as microwave ovens, or radiators.
- Protect the product from extreme temperatures, direct sunlight, strong jolts, high humidity, moisture, flammable gases, vapors, and solvents.
- Do not disassemble, modify, or repair your device, and ask for help from authorized professionals if the device malfunctions.
- Do not use the device when it is no longer working properly or is visibly damaged.
- Do not store the device for extended periods of time in poor ambient conditions.
- Do not insert your device into another device.
- Never use aggressive detergents, such as rubbing alcohol or other chemical solutions, because these could damage the casing or even impair the functioning of the product.

Note: The images shown in the manual are indicative only. If there is an inconsistency between the images and the actual product, the actual product shall govern.

Warranty Conditions

A new product purchased in the Alza.cz sales network is guaranteed for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the date of purchase.

The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:

- Using the product for any purpose other than that for which the product is intended or failing to follow the instructions for maintenance, operation, and service of the product.
- Damage to the product by a natural disaster, the intervention of an unauthorized person, or mechanically through the fault of the buyer (e.g. during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid intrusion, object intrusion, mains overvoltage, electrostatic discharge voltage (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes such as used power supplies, etc.
- If anyone has made modifications, modifications, alterations to the design or adaptations to change or extend

the functions of the product compared to the purchased design or use of non-original components.

EU Declaration of Conformity

Identification data of the manufacturer's / importer's authorized representative:

Importer: Alza.cz a.s.

Registered office: Jankovcova 1522/53, Holešovice, 170 00 Prague 7

IČO: 27082440

The subject of the declaration:

Title: Smart socket

Model / Type: EP2

The above product has been tested in accordance with the standard(s) used to demonstrate compliance with the essential requirements laid down in the Directive(s):

Directive No. (EU) 2014/35/EU

Directive No. (EU) 2014/53/EU

Directive No. (EU) 2011/65/EU as amended 2015/863/EU

Prague, 23.8.2021



WEEE

This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19 / EU). Instead, it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.



The product user guide contains product features, how to use, and the operating procedure. Read the user manual carefully to get the best experience and avoid unnecessary damage. Keep this manual for future reference. If you have any questions or comments about the device, please contact the customer line.

✉ www.alza.co.uk/kontakt

☎ +44 (0)203 514 4411

Importer Alza.cz a.s., Jankovcova 1522/53, Holešovice,
170 00 Praha 7, www.alza.cz

Documents / Resources



[gosund EP2 10A EU Wifi Smart Power Plug Socket](#) [pdf] User Manual

EP2, 10A EU Wifi Smart Power Plug Socket, EP2 10A EU Wifi Smart Power Plug Socket, EU Wifi Smart Power Plug Socket, Smart Power Plug Socket, Power Plug Socket, Plug Socket, Socket

References

- [alza.at](#)
- [alza.co.uk](#)
- [alza.de](#)
- [alza.hu](#)
- [alza.sk](#)