

GRANDSTREAM HT802 V2 Analog Telephone Adapter Instruction Manual

Home » GRANDSTREAM » GRANDSTREAM HT802 V2 Analog Telephone Adapter Instruction Manual



Contents

- 1 GRANDSTREAM HT802 V2 Analog Telephone
- **2 Product Usage Instructions**
- 3 FAQ
- **4 PACKAGE CONTENT**
- **5 PORTS and LED indicators**
- **6 PRECAUTIONS**
- 7 Warranty
- **8 CONTACT**
- 9 Documents / Resources
 - 9.1 References



GRANDSTREAM HT802 V2 Analog Telephone Adapter



Product Usage Instructions

Power On

- Connect the 5V power adapter to the power socket on the device.
- Press the Power ON button to turn on the device. The Power LED should light up.

Connecting Analog Phones

- Connect your analog telephone devices to the FXS ports on the device.
- The FXS 1-2 LED indicators will show the status of the connected analog phones.

Network Connection

- Connect the device to your network using the NET port.
- The NET LED indicator will show the network connection status.

Resetting the Device

- To reset the device, use a micro-USB cable connected to the reset port.
- The device will restart, and you can reconfigure it as needed.

FAQ

- Q: Can the HT802 V2 be used to contact emergency services?
 - **A:** No, Grandstream does not provide connections to emergency services via the HT802 V2. It is recommended to make alternative arrangements for accessing emergency services.
- Q: How can I access the GNU GPL license terms for the device?
 - A: The GNU GPL license terms can be accessed via the Web user interface of the device or by visiting


<u>https://www.grandstream.com/legal/open-source-software</u>. For a CD with GPL source code information, submit a request to <u>info@grandstream.com</u>.

PACKAGE CONTENT


• HT802 V2




• Ethernet Cable



• 5V power adapter




• Quick Installation Guide




PORTS and LED indicators

HT802 V2 PORTS and LED indicators

- 1. Power ON LED
- 2. FXS 1-2 LED
- 3. NET LED
- 4. NET port
- 5. Reset
- 6. Micro-USB power socket (5V)
- 7. FXS ports





PRECAUTIONS

- Please DO NOT power cycle the HT802 V2 during system boot-up or firmware upgrade. You may corrupt firmware images and cause the unit to malfunction.
- Use only the power adapter included in the HT802 V2 package. Using an alternative non-qualified power adapter may damage the unit.

The HT802 V2 is not pre-configured to support or make emergency calls to any type of hospital, law enforcement agency, medical care unit ("Emergency Service(s)"), or any other kind of Emergency Service. You must make additional arrangements to access Emergency Services. It is your responsibility to purchase a SIP-compliant Internet telephone service, properly configure the HT802 V2 to use that service, and periodically test your configuration to confirm that it works as you expect. It is also your responsibility to purchase traditional wireless or landline telephone services to access Emergency Services.

GRANDSTREAM DOES NOT PROVIDE CONNECTIONS TO EMERGENCY SERVICES VIA THE HT802 V2. NEITHER GRANDSTREAM NOR ITS OFFICES, EMPLOYEES, OR AFFILIATES MAY BE HELD LIABLE FOR ANY CLAIM, DAMAGE, OR LOSS, AND YOU HEREBY WAIVE ANY AND ALL SUCH CLAIMS OR CAUSES OF ACTION ARISING FROM OR RELATING TO YOUR INABILITY TO USE THE HT802 V2 TO CONTACT EMERGENCY SERVICES, AND YOUR FAILURE TO MAKE ADDITIONAL ARRANGEMENTS TO ACCESS EMERGENCY SERVICES UNDER THE IMMEDIATELY PRECEDING PARAGRAPH.

The GNU GPL license terms are incorporated into the device firmware and can be accessed via the Web user interface of the device at my_device_ip/gpl_license. It can also be accessed here:

https://www.grandstream.com/legal/open-source-software

To obtain a CD with GPL source code information please submit a written request to info@grandstream.com

EU Regulatory Information

- Hereby, [Grandstream Networks, Inc.] declares that the radio equipment type [HT802 V2] complies with Directive 2014/30/EU&Directive 2001/95/EC.
- The full text of the EU Declaration of Conformity is available at the following internet address: http://www.grandstream.com

Warranty

• For Certification, Warranty, and RMA information, please visit www.grandstream.com



CONTACT

Grandstream Networks, Inc.

- 126 Brookline Ave, 3rd Floor
- Boston, MA 02215. USA
- Tel: +1 (617) 566 9300
- www.grandstream.com

EU Agent

- · Picus Advisors Ltd
- Taivalmaki 9F1-02200 Espoo, FINLAND
- https://www.picus.fi

Note: For the European Union only

Documents / Resources



GRANDSTREAM HT802 V2 Analog Telephone Adapter [pdf] Instruction Manual HT802 V2, HT802 V2 Analog Telephone Adapter, Analog Telephone Adapter, Telephone Adapter, Adapter

References

- S Grandstream Networks Networking & Unified Communications
- U Picus is your market entry advisor.
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned b SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.	y Bluetooth
Sig, inc. The Wi-ries word mark and logos are registered trademarks owned by the Wi-ri Alliance. Any use of these marks on this website does not imply any animation with or endorsement.	