

GRAPHTEC OPH-A45 Carrier Sheet Table Instruction Manual

Home » GRAPHTEC » GRAPHTEC OPH-A45 Carrier Sheet Table Instruction Manual





(Carrier Sheet support table for the CE8000-40/60) This option is used to be stabilized feed for the carrier sheet. When the carrier sheet is used, please install this option to the CE8000-40/60.

Contents of kit

4 pieces









1 Sheet

Installation manual (This sheet)

Contents


- 1 How to install this option
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**


How to install this option

Mount the carrier sheet table to the front and back of the cutting plotter. Insert the projection under the carrier sheet table into the dent part.

For CE8000-40, insert the front side into the first and third grooves from the right. Align the back side in the same position as the front side.

For CE8000-60, insert the front side into the second and fourth grooves from the right. Align the back side in the same position as the front side.





How to set the carrier sheet

Please refer to the user's manual (PDF). The manual (PDF) is available at: http://www.graphteccorp.com/support/index.html





GRAPHTEC OPH-A45 Carrier Sheet Table [pdf] Instruction Manual OPH-A45 Carrier Sheet Table, OPH-A45, Carrier Sheet Table, Table

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.