

Grays 9327 Multi Function Watch



Grays 9327 Multi Function Watch Instruction Manual

[Home](#) » [Grays](#) » Grays 9327 Multi Function Watch Instruction Manual 

Contents


- 1 Grays 9327 Multi Function Watch
- 2 DISPLAY
- 3 SETTING THE TIME & DAY
- 4 SETTING THE DATE
- 5 Documents / Resources
 - 5.1 References

MICHAEL HILL

Grays 9327 Multi Function Watch



DISPLAY



*Dial positions and layout of the face might vary depending on the watch model.

SETTING THE TIME & DAY

1. Pull the crown out to the 2nd position when the second hand is at the 12 o'clock position.
2. Turn the crown clockwise to advance hour and minute hands until day hand is set to the desired day of the week.
3. Turn to set the time taking AM or PM into consideration.
4. Push crown back to normal position.

SETTING THE DATE

1. Pull out the crown to 1st position.
2. Turn the crown counter-clockwise to set date hand.
3. Push crown back to normal position.

WARNING: THIS PRODUCT CONTAINS A BUTTON BATTERY

If swallowed or placed inside any part of the body, the battery can cause serious injuries. It can cause severe or fatal injuries within two hours or less. Button batteries are hazardous. Keep batteries out of reach of children. If you think the battery may have been swallowed or placed inside any part of the body, you should contact your local Poisons Information Centre immediately for 24/7 fast, expert advice.

AUSTRALIA

Australian Poisons Information Centre 13 11 26


NEW ZEALAND

New Zealand Poisons Information Centre 0800 764 766

CANADA

Canada Poisons Information Centre 1 844 764 7669

Documents / Resources

| | |
|---|--|
|  | Grays 9327 Multi Function Watch [pdf] Instruction Manual 9327 Multi Function Watch, 9327, Multi Function Watch, Function Watch, Watch |
|---|--|

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.