




GREADIO GR-092P Emergency Weather Alert Radio Owner's Manual

[Home](#) » [GREADIO](#) » GREADIO GR-092P Emergency Weather Alert Radio Owner's Manual 

GREADIO






GR-092P
Owner's Manual




Contents

- 1 Radio Operation
- 2 Weather Alert
- 3 Phone Charging
- 4 Power the Device
 - 4.1 USB Charging
 - 4.2 Hand Crank
- 5 Earphone Jack
 - 5.1 Solar Powered
 - 5.2 AAA Dry Batteries
- 6 Bottle Opener
- 7 Flashlight
- 8 SOS Alarm
- 9 Specifications
- 10 Safety Instructions
- 11 Warranty
- 12 Packing list
- 13 Documents / Resources
- 14 Related Posts

Radio Operation

- Press the button “” to turn on the radio, the power indicator turns blue.
- Press the “BAND” button to select FM/AM/WB.
- After selecting band FM/AM/WB , short press the button “” or “” to select a channel. Long press button “” or “” to search the channels automatically, and it will stop when a channel is properly selected and the green signal indicator light will come on. Extend the antenna and adjust the direction to get a better signal.
- Press the Volume button” + “or”-“to adjust volume up/down.



NOTE:

- Indicator Lights (From top to bottom: Charging indicator, Signal indicator, Power indicator, Alert indicator)

Weather Alert


- Press the “AL” button to switch to weather alert mode. The yellow alert indicator will light up.
- Once the bad weather information is received, the signal indicator will turn green and the yellow alert indicator will flash. Also, “ALERT” will flash on the LCD screen and the device will alarm.
- Press button “AL” or “BAND” to exit weather alert mode.

Phone Charging

It has a 2000mAh capacity to charge USB devices. You can also charge your phone by inserting the 3AAA batteries into the radio.

NOTE:

- To extend the battery life, it's suggested to use this function only in an emergency.



Power the Device

Before powering the radio, make sure you read the safety instructions.

USB Charging


- To charge the radio, insert the supplied USB cable into the USB power source. Plug the Micro USB connector into the input port on the side of the radio.
- When the battery is charged, the charging indicator will flash red. When the battery is fully charged, the indicator will always be red.
- It takes 3-4 hours to fully charge.

NOTE:

- It would be better to turn off the radio before the device is charged.


Hand Crank

The radio can also be charged by turning the handle at the back of the device and activating the dynamo.




NOTE:

- Ensure the negative(-) end is placed against the spring.
- There is a priority to use AAA dry batteries.
- Remove the AAA dry batteries when they are not used.



Earphone Jack

- Insert the 3.5mm Earphone jack to listen to the radio to enjoy your leisure time.
- If you press the SOS button at this time, the alarm sound will still be emitted from the speaker and the LCD screen will go out.



- The handle can be turned either clockwise or counter clockwise. The charging indicator should also light red when the handle is being turned.
- The handle can be turned either clockwise or counter clockwise. Spin the handle for 1 minute at the speed of 130-150 RPM. It can be used for a flashlight for 30 minutes or a radio (at medium volume) for 5 minutes.

Solar Powered

Place the unit in clear sunlight to let it charge as efficiently as possible.

- The charging indicator will light red when the radio receives sunlight to start charging up.
- The charging effect depends on the intensity of sunlight and the irradiation time of sunlight.
- Kindly remind that it's difficult to fully charge the radio this way. It is mostly used for maintaining the battery, to prolong the battery life.

AAA Dry Batteries

Remove the battery compartment cover which is on the bottom of the device, then insert 3 AAA batteries into the compartment. The symbol displayed on the LCD screen battery level will be converted to AAA.

Bottle Opener

- Put the bottle opener in the bottle cap and press down or lift it up by hand to open the cap of beer, cola or other drink. Best for use in camping or party.

Flashlight

- The flashlight can be turned on by clicking on the light button on the top of the radio.
- Press it again to turn it off.

SOS Alarm

- The radio has an SOS feature for an emergency that activates a loud siren and a flashlight. Long press the SOS button in the lower-left corner to activate it.
- Press the SOS button again to turn it off.

Specifications

Frequency Range	FM: 87-108MHz AM: 520-1710KHz WB: 162.40-162.55MHz
Dimensions	159*47*81mm 16.26*1.85*3.19in
Weight	310g
Product Material	ABS plastic
Maximum	9W
Working Voltage	2.7-4.2V
Battery Voltage	2000mAh/3.7V Li-ion
Water Resistant Level	IPX3
LED Flashlight	1W/70LM
After fully charged, it supports	LED lighting: 10-12h Radio play: 4-5h

Safety Instructions

- For the first use or when the unit idles over 60 days, please place under strong solar light(day light>86000LUX) for 30 minutes or hand crank for 1 minute to activate the internal battery.
- Please do not over-discharge the unit,so as not to reduce the internal battery life, or even damage the internal battery.
- Use a soft damp cloth to clean the radio surface. Do not use alcohol or other liquids containing corrosive ingredients to clean this unit.
- Unit is not waterproof, only water-resistant. Do not submerge in water.


Warranty

The device has a full 18-month warranty against manufacturing defects from the date of purchase.

Packing list

Radio x 1
User Manual x 1
Micro USB Cable x 1
Packing Box x 1

info@thegreadio.com



CONTENTS:

- RADIO OPERATION
- WEATHER ALERT
- PHONE CHARGING
- POWER THE DEVICE
- EARPHONE JACK
- BOTTLE OPENER
- FLASHLIGHT
- SOS ALARM
- SPECIFICATIONS
- SAFETY INSTRUCTIONS
- WARRANTY
- PACKING LIST

[GREADIO GR-092P Emergency Weather Alert Radio](#) [pdf] Owner's Manual

GR-092P, Emergency Weather Alert Radio