

[Skip to content](#)

Manuals+

User Manuals Simplified.



greenworks G40LT33K2 Cordless String Trimmer User Guide

[Home](#) » [Greenworks](#) » **greenworks G40LT33K2**
Cordless String Trimmer User Guide 

greenworks®

G40LT33K2 Cordless String Trimmer User Guide

Contents

[1 G40LT33K2 Cordless String Trimmer](#)

[2 INSTALLATION](#)


[3 OPERATION](#)

[4 MAINTENANCE](#)

[5 Documents / Resources](#)

[5.1 References](#)


G40LT33K2 Cordless String Trimmer



2 IN 1 STRING TRIMMER & EDGER

Depending on the model

purchased, packaging will contain different accessories and parts.
Refer to the package for more details.



KNOW YOUR MACHINE


1. Lock-out button
2. Trigger
3. Auxiliary handle
4. Upper shaft
5. Cam lock
6. Lower shaft
7. Cut-off blade
8. Edge guide
9. Trimmer head
10. Wheel
11. Guard

INSTALLATION




Attach the guard

Attach the wheel



Install the




battery

OPERATION

Start the machine



Adjust the length of the shaft



Operation tips




Change to the edging mode




MAINTENANCE


Install the cutting line



greenworks®




Europe



www.greenworkstools.eu


USA



www.greenworkstools.com

Canada

www.greenworkstools.ca



- User Manual

Manuals+, Privacy Policy