



# Home » GRIFFIN » GRIFFIN GRFCC2001 Wireless Transmitter with Backseat Charging Hub User Manual ₹

## Contents [ hide ]

- 1 GRIFFIN GRFCC2001 Wireless Transmitter with Backseat Charging Hub
- 2 Specifications
- 3 Product Usage Instructions
- 4 Bluetooth Mode Controls:
- 5 Important Safety Precautions
- 6 Introduction
- 7 Features
- 8 Package Contents
- 9 A Quick Look
- 10 CONNECTING TO A CAR CHARGER
- 11 Bluetooth Mode
- 12 Bluetooth Mode Controls
- 13 Charging Ports
- 14 FCC Compliance Statement
- 15 One Year Warranty
- 16 FAQS
- 17 Documents / Resources
  - 17.1 References



**GRIFFIN GRFCC2001 Wireless Transmitter with Backseat Charging Hub** 



## **Specifications**

• Working Voltage: 12- 24V

• Transmission Distance: 5-10m

• Front USB-A Output: 5V/3.1A

• Front USB-C Output: 5V/3.1A

Rear USB Output: 5V/3.1A

Rear USB-C Output: 5V/3.1A

# **Product Usage Instructions**

## **Connecting to a Car Charger**

Before connecting your transmitter to your vehicle, turn the vehicle's engine ON. Connect your transmitter to your car's 12V DC power supply.

**CAUTION:** Do not connect your transmitter to your vehicle BEFORE the vehicle's engine has started. When the car's engine is turned off, the transmitter will automatically turn off shortly afterward. Take the transmitter out and store it in a cool, dry location.

#### **Bluetooth Mode**

- 1. Start the vehicle engine.
- 2. Connect your transmitter to your car's 12V DC power supply. The transmitter will automatically enter Bluetooth Mode.

## **Pairing Instructions:**

- 1. Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on.
- 2. Connect to the device listed as GRFCC2001.

**NOTE:** Disconnect through your connected device.

#### **Bluetooth Mode Controls:**

#### • Left Button:

- Press to play the previous song in a playlist.
- Press and hold to reduce the volume.

## • Right Button:

- Press to play the next song in a playlist.
- Press and hold to increase the volume.

#### • Multifunction Button:

- Press to answer an incoming call.
- Press and hold to reject an incoming call.
- Press to play/pause videos.

# **Charging Ports**

The transmitter comes with one USB-A port and one USB-C port. The transmitter is connected to a charging hub with two USB-A ports and one USB-C port. Connect a compatible charging cable to one of the ports. Ensure it is fully inserted and no tears or damage are visible to the connection or cable.

**NOTE:** Some devices require a specific output voltage. Before connecting, make sure that your device is compatible with the transmitter's output.

# **Important Safety Precautions**

When using your Griffon Wireless Transmitter with Backseat Charging Hub, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR WIRELESS TRANSMITTER.

- 2. Do not use your product near water. Clean using a soft cloth or paper towel.
- 3. Do not place your product on any wet surfaces.
- 4. Do not allow children or the infirm to use your product without adult supervision.
- 5. Do not expose your product to excessive heat, flames, or fire.
- 6. Always press all buttons or switches carefully. Do not manhandle your product.
- 7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
- 8. Do not expose your product to temperatures above 60°C.
- 9. Do not attempt to repair this product yourself. Contact a qualified service center if your product needs service.
- 10. Do not drop, puncture, or expose your product to excessive trauma.
- 11. Your product is not intended for commercial use.
- 12. Do not place near objects that generate a strong magnetic field.
- 13. Unplug this device when not in use for long periods or during lightning storms.
- 14. Your product is intended to be used in an automobile.
- 15. Do not operate your product while you are driving your automobile.

#### **CAUTION**

#### Risk of Fire and Burns.

Do Not Open, Crush, Heat Above 104°F (40°C) or Incinerate. Always Follow All Manufacturer's Instructions When Using.

### Introduction

Thank you for purchasing your Gri?n Wireless Transmitter with Backseat Charging Hub, item GRFCC2001. To get the best results, please read this manual ?first.

### **Features**

- 15W Per Port
- Bluetooth
- Extra Ports for Extra Passengers

# **Package Contents**

- 5-Port Car Charger Hub
- User's Manual With Warranty Information

## A Quick Look



1	USB-C Port	6	Multifunction Button
2	USB-A Port	7	Negative Pole
3	Left Button	8	Positive Pole
4	Right Button	9	Charging Hub
5	LED Display		

## **CONNECTING TO A CAR CHARGER**

Before connecting your transmitter to your vehicle, turn the vehicle's engine ON. Connect your transmitter to your car's 12V DC power supply.

**CAUTION:** Do not connect your transmitter to your vehicle BEFORE the vehicle's engine has started.

When the car's engine is turned of, the transmitter will automatically turn off shortly afterward. Take the transmitter out and store it in a cool, dry location.

### **Bluetooth Mode**

Start the vehicle engine. Connect your transmitter to your car's 12V DC power supply.

The transmitter will automatically enter Bluetooth Mode.

Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "GRFCC2001".



**NOTE:** Disconnect through your connected device.

## **Bluetooth Mode Controls**

#### Left Button:

- Press to play the previous song in a playlist.
- Press and hold to reduce the volume.

### **Right Button:**

- Press to play the next song in a playlist.
- Press and hold to increase the volume.

#### **Multifunction Button:**

- Press to answer an incoming call.
- Press and hold to reject an incoming call.
- Press to play/pause videos.

# **Charging Ports**

The transmitter comes with one USB-A port and one USB-C port. The transmitter is connected to a charging hub with two USB-A ports and one USB-C port. Connect a compatible charging cable to one of the ports. Ensure it is fully inserted and no tears or damage are visible to the connection or cable.

**NOTE:** Some devices require a specific output voltage. Before connecting, make sure that your device is compatible with the transmitter's output.

## **FCC Compliance Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the ECC Bules. Operation is subject to the following the part 15 of the ECC Bules.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **One Year Warranty**

This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

#### What Is Not Covered by Warranty

- Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but not limited to, repair by unauthorized parties, tampering, modification or accident.
- To Obtain Warranty Service and Troubleshooting Information:
- Call 1-800-592-9541 or visit our website at <a href="https://www.griffintechnology.com">www.griffintechnology.com</a>.
- To receive Warranty service, along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

#### **©2025GSICS**

- 195 Carter Drive
- Edison, NJ 08817
- Support: 800 592 9541
- www.griffintechnology.com

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc., and any use of such marks by Sakar International. It is under license. Other

trademarks and trade names are those of their respective owners.

#### **FAQS**

 Q: What should I do if my device is not charging when connected to the transmitter?

A: Make sure that the charging cable is securely connected to the transmitter and your device. Check for any damage to the cable or ports. Ensure that your device is compatible with the transmitter's output voltage.

Q: How can I reset the transmitter if it is not working properly?

A: To reset the transmitter, disconnect it from the power source, wait for a few seconds, and then reconnect it. You can also try restarting your vehicle's engine and reconnecting the transmitter.

# **Documents / Resources**



GRIFFIN GRFCC2001 Wireless Transmitter with Backseat Charging Hub [

pdf] User Manual

2A3ZO-250080A, 2A3ZO250080A, 250080a, GRFCC2001 Wireless Trans mitter with Backseat Charging Hub, GRFCC2001, Wireless Transmitter with Backseat Charging Hub, Transmitter with Backseat Charging Hub, Backseat Charging Hub, Charging Hub, Hub, Transmitter

#### References

- Namebay newsletter
- User Manual
- **■** GRIFFIN
- ♦ 250080a, 2A3ZO-250080A, 2A3ZO250080A, Backseat Charging Hub, Charging Hub, GRFCC2001, GRFCC2001 Wireless Transmitter with Backseat Charging Hub, GRIFFIN, Hub, Transmitter, Transmitter with Backseat Charging Hub, Wireless Transmitter with Backseat Charging Hub
  - —Previous Post

**GRIFFIN GRFPB1001-BLK 5000mAh Magnetic Powerbank with Wireless Charging User Manual** 

# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \* Name Email Website Save my name, email, and website in this browser for the next time I comment. **Post Comment** Search: e.g. whirlpool wrf535swhz Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.