



groov-e GV-WC05 Artemis Wireless Charging Station with LED Touch Lamp User Manual

[Home](#) » [Groov-e](#) » groov-e GV-WC05 Artemis Wireless Charging Station with LED Touch Lamp User Manual 

groov-e GV-WC05 Artemis Wireless Charging Station with LED Touch Lamp User Manual



“**Congratulations** on your purchase and Thank You for choosing the Groov-e GV-WC05 Artemis. Please read the guide carefully before using.”


Contents

- [1 Important safety information](#)
- [2 Overview](#)
- [3 Wireless Charging](#)
- [4 Light Setting](#)
- [5 FEATURES](#)
- [6 SPECIFICATIONS](#)
- [7 Guarantee](#)
- [8 Warranty](#)
- [9 Contact Us](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

Important safety information


1. Keep the adapter and product dry.
2. Do not let water run into the appliance or spill water onto the appliance or adapter.
3. This appliance is for indoor use only.
4. Only use the appliance in combination with the adapter supplied.
5. Place the appliance on a stable, level and non – slippery surface.
6. Do not disassemble the product in case of electrical shock
7. Do not use the product at room temperatures lower than 10C or higher than 35C.
8. Do not impair the light function of the product by covering it with items such as blankets clothing, papers, etc.

Overview



Wireless Charging

To enable wireless charging, ensure the product is powered by connecting the mains adapter to the DC input.




Place your wireless charging enabled device on the charging pad. Your device will start charging. The output rate for charging is 5W. For optimum charging, ensure the device is placed directly onto the charging pad.

Note: Your device must have wireless charging capabilities to be able to use this function.

Light Setting

The GV-WC05 has a touch sensitive light. To enable this, ensure the product is powered by connecting the mains adapter to the DC input.



There are 3 brightness settings available: **LOW, MEDIUM, HIGH.**

Short touch the frame of the product to turn the lamp on. Touch again to go through the various brightness settings.

FEATURES

- Wireless charger 5W – charge your wireless enabled device
- Touch control LED lamp
- 3 LED light settings: low / medium / high

- LED brightness 220 lumens
- LED lifespan 15,000 hours
- Long-life energy saving LED's
- Ideal for any room in the house or office
- DC mains 12V adapter (included)



Wireless
Charging (5W)



LED Lamp
3 Light Modes



Touch
Control

SPECIFICATIONS

Adaptor: 12V / 1A

Output: 5V/1A (5W) Wireless Charging

Colour Temperature: 4000K +/- 250K

Environment Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



Guarantee

Subject Subject to the conditions stated below, Groov-e guarantees this equipment against defects in workmanship or materials of its mechanical and electronic component parts (excluding styling, battery cells, magnetic tapes, re-chargeable batteries, user removeable memory devices, with the exception where the battery is inbuilt into the product) for a period of one year from the date of purchase. This product will be repaired or if necessary replaced free of charge if it has been proven to be defective within the one year warranty period.

1. Claims under this guarantee should be made through the authorised dealer/retailer from whom the equipment was purchased. If this is not possible, please contact Groov-e directly.
2. This guarantee is only valid when the equipment is purchased and retained within the United Kingdom and a valid proof of purchase has been provided.
3. This Guarantee Excludes:
 1. All damage caused through accident, misuse, wear and tear, neglect, installation and/or use in a manner inconsistent with technical and safety standards.
 2. Alterations or adjustments made to equipment
 3. Loss of data resultant from malfunction of hard drive or other storage device
 4. Damage caused to any third party device as a result of using the product.
4. No liability under this guarantee shall be incurred:
 1. In respect of damage or loss occurring during transit to or from the purchaser
 2. Where the serial number plate of the equipment has

5. Groov-e shall not be liable for consequential damage, loss or injury arising from or in connection with the equipment, excepting only that nothing in this condition shall or shall be construed so as to exclude or restrict liability for negligence.
6. The cost of carriage to and from Groov-e shall be borne by the purchaser.
7. This guarantee is personal to the original purchaser and is not transferable.
8. If the equipment, in respect of which a claim hereunder is made, is found on examination to comply with the published specifications, a test fee may be incurred.

This guarantee is in addition to and does not in any way affect any statutory or other right of consumer purchasers, including those rights in relation to sections 13 to 15 of the Sale of Goods Act 1979, the Sale and Supply of Goods to Consumer Regulations 2002, The Consumer Rights Act 2015 or the Sale of Goods and Supply of Services Act 1980 (for ROI).

Warranty

30 Day Right To Return



We do not envisage any problems occurring with your Groov-e GV-WC05 Artemis. However, for your peace of mind, should any fault occur, please return it within 30 days to your retailer with your proof of purchase for an exchange or refund.

12 Month Guarantee



This product is guaranteed for twelve months.

Please retain your receipt as this will be required as proof of purchase, in the event that the device does not perform as expected then please contact your original point of purchase, should you require further assistance then please contact us.

Extended Warranty



Please register your product within 30 days from date of purchase www.groov-e.co.ukwarranty.
Proof of purchase required.

Contact Us




Reach out to us at info@groov-e.co.uk or visit
www.groov-e.co.uk



Unit J
Braintree Road
Braintree Industrial Estate
Ruislip
Middlesex
HA4 0EJ
www.groov-e.co.uk
Email: info@groov-e.co.uk
Telephone: 020 8839 0978



Documents / Resources

 <p>The image shows the cover of a user manual. At the top is the groov-e logo. Below it is the model name "GV-WC05 Artemis". In the center is a photograph of the white wireless charging station with a black LED touch lamp. Below the photo, it says "User Manual" and "2-1". At the bottom, it says "Wireless Charging Station with LED Touch Lamp" and "groov-e.co.uk".</p>	<p>groov-e GV-WC05 Artemis Wireless Charging Station with LED Touch Lamp [pdf] User Manual</p> <p>GV-WC05, Artemis Wireless Charging Station with LED Touch Lamp</p>
---	--

References

-  [Groov-e](#)
-  [Groov-e](#)

[Manuals+.](#)