

GROWATT ShineWiFi-X WiFi Module USB for Inverter Installation Guide

Home » Growatt » GROWATT ShineWiFi-X WiFi Module USB for Inverter Installation Guide Table 1.



Contents


- 1 Ste p 1 . Electrical connection
- 2 Step2. Turn on inverter and check ShineWiFi-X
- 3 Step3. Registration and adding device
- 4 Step4 Reset Shine WiFi to Factory Settings
- 5 Troubleshooting
- 6 Documents / Resources



Growatt ShineWiFi-X Quick Installation Guideline

Ste p 1. Electrical connection

- 1. Rotate the USB cover of the photovoltaic device counterclockwise
- 2. Rotate the datalogger locker on the upper, make sure the triangle is on the front side and in the middle.
- 3. connect the datalogger to the inverter USB port, make sure the triangle is on the front side, press the locker and rotate clockwise until it is tighten.



Step2. Turn on inverter and check ShineWiFi-X state

After install the ShineWiFi-X module, turn on the inverter, red LED flashing indicates the inverter and ShineWiFi-X communication is normal.

LED State	Indication
ALL three LED off	ShineWiFi-X not connected well with inverter USB port
Only Red LED flashes	ShineWiFi-X and inverter communication is OK
Only Green LED flashes	ShineWiFi-X, inverter and router communication is OK
Only Blue LED flashes	ShineWiFi-X, inverter, router and ShineServer communication is OK

Step3. Registration and adding device

Scan the QR code below to download ShinePhone, also you can search ShinePhone in iOS or Google Play Store, download and install it.

Note:

- 1. Make sure you download the latest version
- 2. For further information please visit server.growatt.com




http://server.growatt.com/app/xml/download_growatt.png.jsp


1. Connect your mobile phone to the WiFi of your home router .Select country and city, then click "Next" enter next page. of which the ShineWiFi-X module will be connected.

Note: If you select a wrong country and city, the system


- (1) The router name should consist with English letters and time maybe wrong. numbers, it does not support special symbols.
- (2) For safety reason, please use an encrypted wireless networ
- (3) It does not support a public network that uses a secondary authentication.
- (4) It does not support bridge network.
- 2. Open ShinePhone APP, click "Register" on login page.



3. Select country and city, then click "Next" enter next page. Note: If you select a wrong country and city, the system time maybe wrong.





- 4. Fill out the required information, then click "Next", it will guide you to the "Add datalogger" page.
- 5. Scan QR code or input the ShineWiFi-X barcode and checkcode, then click "Register", it will move you to the "Set ShineWifi-X" page.






6. Fill out the wifi network and password, then click"Configuration", after successful configuration, a note will pop up "Configured successfully", then it will move to the "my plant" page. Note: There are 3 LEDs on ShineWiFi-X, only the blue LED flashing indicates the ShineWiFi-X module is successfully connected to the router and Growatt Shine Server.





7. If the pop up a message says "Failed", please refer to Appendix A of the troubleshooting guide to solve the problem. After that, login to your account and click the "+" sign on the right top side of the page, and

select"Datalogger list"in the appearing dialog window. Push on the datalogger's serial number for 3 sec, until a small dialog window appears, select "Configure datalogger". It will move to the "Set ShineWifi-X"page, enter the home routers name and password, then click, "Set" the connection configuration process will begin.






8. After successful configuration, it will move to the "my plant" page, select the Inverter in the device list to check the inverter update information.



- 9. If you want to add/edit/delete/configure a datalogger, click the "+" sign on the right top side of the "my plant" page. There are 4 options in the dialog window when push on the datalogger's serial number, click the one you need.
 - 1) rAdd datalogger" is for adding a new ShineWiFi-X module to this account.
 - 2)"Edit datalogger" is used to assign an alias name for your ShineWiFi-X module.
 - 3)"Delete datalogger" is used to remove the ShineWiFi-X module from this account.
 - 4)"Configure datalogger" is used for configuring the connection of the ShineWiFi-X module to the router.





Step4 Reset Shine WiFi to Factory Settings

When you have changed your home router password, or changed to a new router, you need to reset Shine WiFi-X to factory settings and reconfigure it. Press the KEY button for 6 sec, until all three LEDs long light up, then login to your ShinePhone account, click the "+"on right top of this page, long press this datalogger serial number to reconfigure.

Appendix A: ShineWiFi-X KEY Button Description

Operation	Description
When ShineWiFi-X is powered on, remove the rubber plug, and press the KEY button. (ShineWiFi LED will change from flash to always O N)	ShineWiFi-X will enter to AP mode. (AP mode is a debug mode, only allo wed for professional)
When ShineWiFi-X in AP mode, press The KEY button of Shine WiFi-X (ShineWiFi-X LED will change from always ON to flash)	Quit AP mode
Long press the KEY button forMore than 6 sec (ShineWiFi-X All LEDs always ON)	Reset ShineWiFi-X to Factory settings

Troubleshooting

LED State	Indicate	Troubleshooting
All three LEDs are dar	ShineWifi-X can not find inverter via USB port	1.Try to reconnect ShineWifi-X to the inverter USB po r
After configuration, on ly Red LED flashes	ShineWiFi-X can't connect to the home router	1) Check router information a) Router name should consist of English letters and numbers, it does not support special symbols b) For safety reason, please use encrypted wireless network c) It does not support public network that use second ary authentication 2) Check if you filled in the correct name and password of the home router when configuring it
After configuration, Only Green LED flash es	ShineWiFi-X already connected to the home router, but not connected To Growatt ShineServer	(1) Check if home router is connected to the internet (2) Check if the router firewall allows to select port 52 79 and 5280
After configuration, Only Blue LED flashes	ShineWiFi-X communication O K with inverter, home router, an d Growatt ShineServer	Normal working state
Red LED always ON	ShineWiFi-X module error	(Need to replace with a new ShineWiFi-X
Green LED always O N	Cannot connect to the router	Please check if the configuration input password is c orrect. If the input is incorrect, please reset it and configure it again.
Blue LED always ON	ShineWiFi-X module is in AP m ode	Debug mode, short press the KEY button to quit

For more info, please download from http://server.growatt.com

T +86 755 2747 1942

F +86 755 2747 2131

E <u>service@ginverter.com</u>

W www.growatt.com

Documents / Resources



<u>GROWATT ShineWiFi-X WiFi Module USB for Inverter</u> [pdf] Installation Guide ShineWiFi-X WiFi Module USB for Inverter, ShineWiFi-X, WiFi Module USB for Inverter, Module USB for Inverter, USB for Inverter, Inverter

