

Gus Ledger Side Board Instruction Manual

Home » Gus » Gus Ledger Side Board Instruction Manual

Contents

- 1 Gus Ledger Side Board
- 2 TOOLS
- 3 ASSEMBLY


INSTRUCTIONS

- 4 Documents / Resources
 - **4.1 References**
- **5 Related Posts**



Gus Ledger Side Board





ASSEMBLY INSTRUCTIONS

KEEP ALL PACKAGING MATERIALS UNTIL YOU HAVE VERIFIED ALL COMPONENTS AND PARTS

Preventative Measures: Wood


The Ledger Series is constructed with a combination of solid and engineered wood, each with its own distinct grain pattern and coloring. These variations make each piece natural and unique. We recommend cleaning all wood components with a damp, soft cloth. Do not put any extremely hot or cold food items/beverages in direct contact with the wood surface as this may cause marking or damage to the finish. Spills must be cleaned immediately or this may cause discoloration and /or swelling to the wood and may cause permanent damage. Do not apply oils or other stains to refinish the surface. Take care when opening and closing doors to keep the tambour doors functioning correctly.


- 1. Carefully place the unit on its back on a clean, flat surface.
- 2. Bolt the legs to the corners of the skirt by lining up the holes and using hardware (A) provided. Tighten with the provided Allen wrench (D) and install the felt pads (C) on each leg.
- 3. Install the center leg.
- 4. Adjust the center leg until the cabinet is level and the doors move freely.
- 5. Apply paraffin (B) to the groove of the tambour door and move the doors back and forth ~ 15x
- 6. Remove transport clamps from shelves.
- 7. Install the anti-tip hardware (E) to secure the unit to an adjacent wall.

To improve stability it may be necessary to periodically tighten all the fasteners. Do not use abrasive cleaning products.

INFO







Documents / Resources



Gus Ledger Side Board [pdf] Instruction Manual Ledger Side Board, Side Board, Board

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.