


# hager XEVS000 Charging Station Controller Instruction Manual

Home » hager » hager XEVS000 Charging Station Controller Instruction Manual

hager XEVS000 Charging Station Controller



## **Contents**

- 1 Package Content
- 2 Installation


## Instructions


- **3 Operating Instructions**
- **4 Safety instructions**
- 5 Recommendations
- 6 Documents /

#### Resources


- **6.1 References**
- **7 Related Posts**

# **Package Content**








**Installation Instructions** 





**Operating Instructions** 















# Safety instructions



Electrical devices must only be installed and assembled by a qualified electrician.

The accident prevention recommendations applicable in the country must be followed. Failure to follow the installation instructions may result indamage to the device, fire or other dangers.



- Do not forget all the circuit breakers that deliver voltages which are potentially dangerous to the device or the load.
- · Risk of electric shock.
- The charging station must be powered off when replacing a spare part.
- Please read the maintenance manual before servicing a charging station.
- The device must only be installed by an electrician, in accordance with the installation stand ards applicable in the country.
- Holding the edges of the card only, to avoid touching the sensitive components.
- Wearing an antistatic bracelet when handling the card to prevent any damage. If you do not
  have an antistatic bracelet, touch a metal object connected to the earth before handling the
  card to remove any static electricity from your body. Regularly touch the metallic object
  when handling the card.
- Until the electronic products are installed, store them in their packaging to protect them from electrostatic discharges, or on an antistatic support.



Do not access or tamper with any internal sections of the device beyond those mentioned in these instructions. Doing so will void the warranty and any other assistance. Indeed, this kind of tampering may cause damage to electrical components and/or parts. These products have been designed so that there is no need to access these areas as part of set-up and maintenance.



How to dispose of this product (electrical and electronic equipment waste).

(Applicable in European Union countries and other European countries with selective waste collection systems). This symbol on the product or its documentation indicates that it must not be disposed of with other household waste at the end of its life cycle.

As disposing of waste inappropriately may harm the environment or human health, please separate it from other types of waste and recycle it responsibly.

In this way you will contribute to the sustainable re-use of material resources. Individuals should contact the retailer who sold them the product or contact their local council to find out where and how they can dispose of this product for recycling in an environmentally friendly manner Companies should contact their suppliers and read the terms of their sales contract. This product must not be disposed of with the other commercial waste.



This document is not contractually binding and is subject to change without notice.

#### **Documents / Resources**



<u>hager XEVS000 Charging Station Controller</u> [pdf] Instruction Manual

XEVS000 Charging Station Controller, XEVS000, Charging Station Controller, Station Controller, Controller

## References

- :h Hager worldwide
- :h Hager Support PRO | Hager France

Manuals+,