



Haier HWF85BW1 Front Load Washing Machine Installation Guide

[Home](#) » [Haier](#) » Haier HWF85BW1 Front Load Washing Machine Installation Guide 

Contents

- [1 Haier HWF85BW1 Front Load Washing Machine](#)
- [2 Product Information](#)
- [3 Specifications](#)
- [4 Product Usage Instructions](#)
- [5 TOP DECK & CONTROL COMPONENTS](#)
- [6 CABINET COMPONENTS](#)
- [7 BOWL COMPONENTS](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

Haier

Haier HWF85BW1 Front Load Washing Machine



Product Information

Front Load Washing Machine HWF85BW1 HA AA

- **Product Code:** 61397-A
- **Model:** HWF85BW1
- **Country:** AU, NZ

Specifications

- **Top Deck & Control Components:** 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36
- **Cabinet Components:** 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20
- **Bowl Components:** 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54

Product Usage Instructions

Preparation

Before using the washing machine, please ensure the following:

- Ensure the power cord is properly connected to a power outlet.
- Make sure the water supply is connected to the machine.
- Check that the drain hose is properly connected and positioned.

- Place the machine on a stable and level surface.

Loading Clothes

Follow these steps to load clothes into the washing machine:

1. Open the door of the washing machine.
2. Add clothes to the drum, making sure not to overload it.
3. Close the door securely.

Selecting a Program

To select a program for your laundry, follow these instructions:

1. Turn on the washing machine by pressing the power button.
2. Use the control panel to select the desired program. Refer to the user manual for program options.

Starting the Wash

Once you have selected a program, follow these steps to start the wash:

1. Press the start button to begin the wash cycle.
2. The machine will automatically adjust settings based on the selected program.
3. Wait for the wash cycle to complete.

Removing Clothes

After the wash cycle is complete, follow these steps to remove your clothes:

1. Open the door of the washing machine.
2. Take out the clothes from the drum.
3. Close the door securely.

Maintenance and Care


Regular maintenance and care will help prolong the life of your washing machine. Follow these guidelines:

- Clean the drum and detergent dispenser regularly.
- Check and clean the filter if necessary.
- Avoid overloading the machine with clothes.
- Keep the machine in a well-ventilated area.


Troubleshooting

If you encounter any issues with your washing machine, refer to the troubleshooting section of the user manual or contact customer support for assistance.

TOP DECK & CONTROL COMPONENTS




CABINET COMPONENTS



DWG004292

BOWL COMPONENTS



FAQ

Frequently Asked Questions

• **Q: How do I clean the drum of the washing machine?**

- A: To clean the drum, follow these steps:
 - Remove all clothes from the drum.
 - Prepare a mixture of mild detergent and water.
 - Wipe the drum with a soft cloth soaked in the detergent mixture.
 - Rinse the drum thoroughly with clean water.

• **Q: Can I use bleach in this washing machine?**

- A: Yes, you can use bleach in this washing machine. However, please refer to the user manual for specific instructions on using bleach safely and effectively.


• **Q: How often should I clean the filter?**

- A: It is recommended to clean the filter at least once every few months or as needed. Refer to the user

manual for instructions on how to locate and clean the filter.

DWG 005231
Front Load Washing Machine
HWF85BW1 HA AA
Product Code
61397-A

Documents / Resources

	<p>Haier HWF85BW1 Front Load Washing Machine [pdf] Installation Guide HWF85BW1, HWF85BW1 Front Load Washing Machine, Front Load Washing Machine, Load Washing Machine, Washing Machine, Machine</p>
---	---

References

- [User Manual](#)