



## Contents [ [hide](#) ]

- [1 Haier KS-HE01V Universal Replace A C Remote Control](#)
- [2 Setup Methods](#)
- [3 Corresponding buttons](#)
- [4 Fast cooling and heating function](#)
- [5 CODES LIST](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)

# Haier®

## Haier KS-HE01V Universal Replace A C Remote Control



## Setup Methods








### Method A: Brand Button

**Automatically searches only the codes relevant to your A/C brand**

1. Point the remote at your A/C and hold down the button that corresponds to your brand as per the “Corresponding buttons” below. For example, the TIME OFF button for Fujitsu A/Cs. If your brand is CEnghuttone halow.For ovamnls, the TIME OEE button for Eulits Ce cannot be listed, please refer to Method B & C.
2. Immediately, as your A/C responds (e.g, makes a beep sound), release the button. This may take up to approximately two minutes. If the remote does not control the A/C

properly or your A/C does not respond, please refer to Method B & C.

## Corresponding buttons

 ON/OFF	 TEMP+	 TEMP-	 WIND
<b>GREE/ HAIER</b>	<b>MIDEA/ TOSHIBA/ CHANGHONG</b>	<b>SHARP/ KELON</b>	<b>MITSUBISHI/ OTHERS</b>
 MODE	 MANUAL SWING	 AUTO SWING	TIME ON
<b>LG/ SAMSUNG</b>	<b>HITACHI/ PANASONIC</b>	<b>SANYO/ HISENSE</b>	<b>CHIGO/ DAIKIN</b>
TIME OFF	F.Cool FAST COOLING	F.Heat FAST HEATING	
<b>FUJITSU/ CARRIER</b>	<b>AIRWELL</b>	<b>KELVINATOR</b>	

### Method B: Automatic Search

Automatically search every code.


1. Point the remote at your A/C and hold down the “SET” button for approximately 10 seconds. You will then see the remote start to scroll through codes 001 to 999 in the bottom right-hand corner of the
2. Hover your finger over the “OK” button and immediately, as your A/C responds (e.g, makes a beep sound), press the “OK” button twice.e
3. If the remote does not function as expected repeat steps 1 and 2 again and the remote will search for another code that connects the remote with your A/C. Otherwise try Method C.

### Method C: Brand Code

Manually search only the codes relevant to your branch, one by one. Lookup

1. up your brand in the code list to determine the relevant codes.
2. Point the remote at your A/C and hold down the “SET” button for 2 seconds until you see a code start flashing in the bottom right hand corner of the screen.
3. Use the “TEMP +” or “TEMP-“to adjust the code to the first relevant code, and the A/C will respond if it is compatible., If the A/C responds, press the “OK” button to select the code. If the remote does not control the A/C properly or your A/C does not respond, please repeat steps 2 and 3 using the next relevant code.

### **Restore factory settings**

Press the “SET +”WIND”  buttons at the same time for approximately 3 seconds until the entire remote screen flashes to restore factory settings□

### **Fast cooling and heating function**

#### **FAST COOLING**

Point the remote at the A/C and press the “F. COOL” button. This will change the mode to cooling temperature to 21 degrees, wind speed to strong, and direction to automatic.

#### **FAST HEATING**

Point the remote at the A/C and press the “F. HEAT button. This will change the mode to heating, temperature to 27 degrees, wind speed to strong, a nd direction to aautomatic

### **Clock function**

1. Hold down the “CLOCK” button for approximately 3 seconds until the time on the screen starts flashing.
2. Use the “TEMP+” and “TEMP-“buttons to adjust the time, please note if you hold down the button it will adjust faster.
3. Press the “CLOCK button to confirm the adjusted time.

### **Timer function**

Please note that the remote must be programmed with your A/C for this function to work. The remote must also be turned on which you can determine by whether or not a temperature is displayed on the remote screen, If it is not turned on then please press the power button Please note using the TIME ON and TIME OFF button may not work

for all A/Cs.

1. Point the remote at the A/C and Press the “TIME ON” or “TIME OFF” button depending on your desired function, the remote screen will then display “TIME ON01” or “TIME OFF01” and your A/C should respond by flashing a light or making a beep sound. “01” indicates the A/C is set to turn on/turn off automatically in 1 hour.
2. Press the same button again to increase the number of hours. The maximum is 15 hours and if you press the same button once more after it shows “TIME ON15 or “TIME OFF15” on the screen it will turn off this function.

### Note

The E A Heating button activates the electrical heating function which only a limited number of A/Cs have. If your A/C has this functionality, whilst in heating mode press this button to start the function.



### CODES LIST

- ACSON 980
- ACTRONAIR 019
- ADC 861
- AEA AUSTRALIA 920
- AGER 013,953
- AIDELONG 293-295
- AIRWELL 134,771,952
- AITE 296-299
- AKIRA 796-797
- ALPIN 989-991,995
- AMCOR 501,508,509,532, 973 978 979
- AMICO 982
- AOKE 301-302
- AOLI 300
- APTON 862
- ATWELL 134

- AUCMA 210-229,933
- AUX 180-199
- BAIXUE 299
- BEIJINGJINGDIAN 304
- BIG-THUMB 331
- BLUE STAR 057,550,887
- BLUEWAY 906
- BOERKA 305-306,630
- BORLER 307
- BOSHI 310
- BOSHIGAO 308-309
- BOYIN 290
- BREEZON 190
- CAIXING 311
- CARRIER 599,690-699,888. 890-899
- CELESTIAL 064
- CENTREX 261
- CHANGFENG 190
- CHANGFU 835-838
- CHANGHONG 059-079,934,947
- CHANGLING 312-323
- CHENG YUAN 324
- CHIGO 080-099
- CHUANGHUA 325-328
- CHUANYAN 861
- CHUNLAN 170-179
- CLIMATE CONTROL 847
- CONVAIR 830
- COLROLLA 861
- CONROWA 337-341
- CONSUL 993
- CORONA 760-769
- CROWN 861
- DAEWOO 332-333

- DAIKIN 028,740-759
- DAJINXING 329-330
- DAKE 861
- DAOTIAN 821-824
- DELONGHI 798,878,900
- DIAMOND 822
- DIGITAL LIFE 121
- DIMPLEX 017
- DIY 044,090,092,095
- DL 121
- DONGXIA 334-335
- DONGXINBAO 260-26B
- DUNAN 336
- DUNNAIR 088
- DVINCI 212
- ECLIPSE 921
- ELCO 982
- ELECTER 981-986
- ELECTROLUX 250,471-474,807- 808,906
- FEDDERS 878
- FEIEDRICH 879
- FEIGE 829-830
- FEILU 240-249,413
- FERROLI 901
- FIRST 864
- FRESTECH 270-279.944-945
- FUJITSU 700-719
- FUNIKI 992
- GALANZ 124-129,134-139. 936-940
- GEER 342-343
- GLEE 280
- GOLDSTAR 303
- GOODMAN 132
- GREE 000,020-039

- GUANGDA 345-346
- GUDIAO 344
- HAIER 001-019
- HELTON 863
- HEMILTON 095
- HICON 391-392
- HISENSE 230-239
- HITACHI 640-659
- HOMEMAKER 181
- HONGYI 347
- HUABAO 100-109
- HUAGAO 348
- HUAKE 349-350
- HUALING 045,150-169
- HUAMEI 351-352
- HUANGHE 353
- HUAWEI 281
- HUIFENG 354-357,360
- HYUNDAI 780-789
- INYCIN 475-483
- ITANIUM 123
- JVL 013
- JIALE 358
- JIANGNAN 359
- JINBEWJING 361-362
- JINDA 491-492
- JINSONG 363-385
- JMSTAR 360
- JOHNSO 282
- KARDA 551
- KANGLI 368-370
- KELONG 110-119
- KELVINATOR 022-028,031,285, 601,609,637,919
- KLIMATAIR 797-800

- KOBE 172
- KONKA 366-367
- KRIS 804-805
- LG 600-609
- LIANGYU 780
- LIKEAIR 386-387
- LITTLESWAN 453
- LONGHE 861
- LOREN-SEBO 801-803
- LUXAIRE 256
- MAYOKI 182
- MCQUAY 790-795
- MEILING 388-391
- MIDEA 040-058
- MILANO 172
- MINGXING 290
- MITSUBISHI 161,551-599
- MITSUCO 885
- MITSUKA 904
- MODERN AIR 906
- NATIONAL 660-689
- NEC 500-550.860.943,946
- NEXAIR 090
- NIKKO 810-811
- NISO 398-399,497
- NORCA 994
- NORCA 994
- O GENERAL 659,717-719
- OLYMPUS 995-996
- ONIX 846
- OPAL 997
- PANASONIC 660-689
- PANDA
- 464-466




- PEREG 998
- PILOT 902
- PINSHANG 290
- PIONEER 696
- POLAR ICE 019
- POLOCOOL 924
- PUYI 862
- QIXING 393
- RAYBO 371-383
- RHOSS 903
- RICAI 394
- RIJIANG 395-397
- ROWA 383-385
- SACON 414
- SAMSUNG 610-629
- SANYO 500-550.860.943.946
- SANZUAN 190
- SAPORO B61
- SAST 450-452
- SENSOR 860
- SERENE 499
- SHAMEI 400
- SHANGLING 403-409
- SHANXING 401-402
- SHANYE B62
- SHARP 720-739
- SHENBAO 410-411
- SHENGFENG 412,413
- SHINCO 200-209
- SHINING 415
- SHUANGLU 416-418,946
- SIGMA 447
- SOGO 291
- SONGLINXIA B62

- SONGXING 419
- SOVA 292,420
- SOWA 862-863
- SOYEA 421-422
- SPEED 987
- SATC 423
- STARIGHT-AIRCON BBO
- SUNBURG 817-820
- TADIAIR/TADIRAN 501.508,509,532,630, 969.978,979,991
- TAIYA 862
- TCL 120-133
- TEAC 850-859
- TECO 017,028,831-834
- TIANJINKONGTIAO 424
- TIANYUAN 425-428
- TOBO 250-269
- TONGLI 429-430
- TOSHIBA 630-639
- TOTALINE 548
- TOYO 825-828
- TRANE B12-816
- UNI-AIR 368-369
- UTTLEDUCK 454-456
- VIDEOCON 597.627.628.629.884
- VOLTAS 056,057,549.598.609. 627-629
- WANBAO 431-433
- WANGZI 861
- WEATHERMAKER 894
- WEILI 434-443,553-576
- WEITELI 444
- WHIRLPOOL 119,550,739,770-774
- WOLFF 180
- WUFENG 445-446
- XILENG 448-449

- XINGHE 462-463
- XINHUABAO 290
- XINLE 457-460
- XINLING 461
- XIONGDI 862
- YAIR 013-015,044,467-471
- YAOMA 470
- YIDONG 499
- YORK 775-779
- YUETU 949
- YUTU 484-490
- ZHONGYI 493-494
- ZUODAN 495

## Documents / Resources

	<p><a href="#">Haier KS-HE01V Universal Replace A C Remote Control [pdf]</a> User Manual</p> <p>KS-HE01V Universal Replace A C Remote Control, KS-HE01V, Universal Replace A C Remote Control, Replace A C Remote Control, A C Remote Control, Remote Control, Control</p>
---	--

## References

- [User Manual](#)

■ Haier

◆ A C Remote Control, control, Haier, KS-HE01V, KS-HE01V Universal Replace A C Remote Control, Remote Control, Replace A C Remote Control, Universal Replace A C Remote Control

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.