

hama 00004633 Bluetooth Remote Control Instruction Manual

Home » Hama » hama 00004633 Bluetooth Remote Control Instruction Manual



Contents


- 1 hama 00004633 Bluetooth Remote Control Instruction Manual
- 2 Bluetooth Operating Instructions
- 3 G Operating instruction
- 4 Controls and Displays
- 5 1. Explanation of Warning Symbols and Notes
- 6 2. Package Contents
- 7 3. Safety Notes
- 8 Warning Batteries
- 9 Warning Button cells
- 10 4. System Requirements
- 11 5. Getting Started
- 12 6. Operation
- 13 6.1. Bluetooth pairing
- 14 6.2. Automatic Bluetooth connection (after successful pairing)
- 15 6.1. Bluetooth pairing.
- 16 6.3. Replacing the batteries
- 17 7. Care and Maintenance
- 18 8. Warranty Disclaimer
- 19 9. Technical Data Bluetooth Remote Shutter
- 20 10. Declaration of Conformity
- 21 Read More About This Manual & Download PDF:
- 22 Documents / Resources
 - 22.1 References

hama 00004633 Bluetooth Remote Control Instruction Manual



Bluetooth Operating Instructions





G Operating instruction

Controls and Displays

- 1. LED indicator light
- 2. ON / OFF button
- 3. Release button
- 4. Battery compartment cover

1. Explanation of Warning Symbols and Notes

Warning This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks. Note This symbol is used to indicate additional information or important notes.

2. Package Contents

- Bluetooth Remote Shutter BRS2
- 1 hand strap
- 1 battery (CR2032)
- · These operating instructions

3. Safety Notes

- Protect the product from dirt, moisture and overheating, and only use it in a dryenvironment.
- Do not use the product in areas where the use of electronic devices is not permitted.
- Do not use the product in moist environments and avoid splashes.
- Do not drop the product and do not expose it to any major shocks.
- Dispose of packaging material immediately according to locally applicable regulations.
- Do not modify the product in any way. Doing so voids the warranty.
- Use the product for its intended purpose only.
- This product is intended for private, non-commercial use only.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Keep this product, as all electrical products, out of the reach of children!
- Do not operate the product outside the power limits given in the specifications.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Do not open the device or continue to operate it if it becomes damaged.

Warning Batteries

- When inserting batteries, note the correct polarity (+ and markings) and insert the batteries accordingly. Failure to do so could result in the batteries leaking or exploding.
- Only use batteries (or rechargeable batteries) that match the specified type.
- Before you insert the batteries, clean the battery contacts and the polar contacts.
- Do not allow children to change batteries without supervision.
- Do ot mix old and new batteries or batteries of a different type or make.
- Remove the batteries from products that are not being used for an extended period (unless these are being kept ready for an emergency).
- · Do not short-circuit batteries.
- · Do not charge batteries.
- Do not throw batteries in a fire.
- Keep batteries out of the reach of children.
- Never open, damage or swallow batteries or allow them to enter the environment. They can contain toxic, environmentally harmful heavy metals.
- Immediately remove and dispose of dead batteries from the product.

 Avoid storing, charging or using the device in extreme temperatures and extremely low atmospheric pressure (for example, at high altitudes).

Warning Button cells

- Do not ingest battery, risk of burns due to dangerous substances.
- This product contains button cells. If swallowed, the button cell can cause severe internal burns within just two hours and lead to death.
- Keep new and used batteries out of the reach of children.
- If the battery compartment does not close securely, stop using the product and keep it out of the reach of children.
- If you think that batteries were swallowed or are in a part of the body, seek medical assistance immediately.

4. System Requirements

• The Bluetooth remote release supports Bluetooth-capable terminal devices such as smartphones and tablet PCs that run the iOS 6 or Android 4.2.2 (or newer) operating systems.

Note

- Note that support of the Bluetooth remote release depends on your terminal device.
- Please refer to the operating instructions for the device you are using.

5. Getting Started

- Open the battery compartment by undoing the screws on the battery cover (4) using a screwdriver.
- Remove the battery cover (4) and insert a CR2032 battery with the correct polarity (B).
- Close the battery compartment by putting back the battery cover and tightening the screws using a screwdriver (B).

6. Operation

Note

- The functions described in this section are only available for Bluetooth-capable terminal devices.
- Note that the maximum range for Bluetooth is 10 metres without obstacles such as walls, people, etc.

6.1. Bluetooth pairing

Note Pairing

Make sure that your Bluetooth-capable terminal device is on and Bluetooth is activated.

- Make sure that your Bluetooth-capable terminal device is visible for other Bluetooth devices.
- For more information, please refer to the operating instructions of your terminal device.
- Slide the On/off switch (2) to the ON position to switch on the Bluetooth remote release. The control light (1) begins to flash green (slowly).
- This means the Bluetooth remote release is searching for a Bluetooth connection.
- Open the Bluetooth settings on your terminal device and wait until Hama BRS2 appears in the list of Bluetooth devices found.
- Select Hama BRS2 and wait until the Bluetooth remote release is listed as connected in the Bluetooth settings on your terminal device. The control light (1) begins to flash green (quickly).
- You can now use the Bluetooth remote release.

6.2. Automatic Bluetooth connection (after successful pairing)

Note

- Make sure that your Bluetooth-capable terminal device is on and Bluetooth is activated.
- Make sure that your Bluetooth-capable terminal device is visible for other Bluetooth devices.
- For more information, please refer to the operating instructions of your terminaldevice.
- The Bluetooth remote release remains connected to the Bluetooth device it was last paired with.
- Slide the On/off switch (2) to the ON position to switch on the Bluetooth remote release. The control light (1) begins to flash green (slowly).
- After 35 seconds, the Bluetooth remote release automatically connects to the device.
- You can now use the Bluetooth remote release.

Note Connection impaired After the devices have been paired once, the connection is then established automatically. If the Bluetooth connection is not established automatically, check the following:

• Check the Bluetooth settings of your terminal device to see whether Hama BRS2 is connected. If not, repeat the steps listed under

6.1. Bluetooth pairing.

- Check whether obstacles are impairing the range. If so, move the devices closertogether.
- The performance can also be affected by a weak battery. Change the batteryif necessary.
- Only one Bluetooth device can be connected at a time. If there is an active connection to another device, deactivate this connection and try again.

6.3. Replacing the batteries

The battery has been designed to last for up to 2,000 shots, although this depends on the conditions of use. If the Bluetooth remote release does not respond after you press the release button (3), or does not connect to the terminal device, etc., change the battery as follows: See (B).

7. Care and Maintenance

Only clean this product with a slightly damp, lint-free cloth and do not use aggressive cleaning agents. Make sure that water does not get into the product.

8. Warranty Disclaimer

Hama GmbH & Co. KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

9. Technical Data Bluetooth Remote Shutter

| Bluetooth version | 3.0 |
|----------------------|-----------------|
| Bluetooth Class | Class 2 |
| Range | Max. 10 m |
| Dimensions (W xLx H) | 35 x 35 x 15 mm |
| Weight | Approx. 10 g |
| Battery type | CR2032 |

10. Declaration of Conformity

Hereby, Hama GmbH & Co KG declares that the radio equipment type [00004633] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.hama.com / 00004633 / Downloads.

| Frequency band(s) | 2.402 GHz ~ 2.480 GHz |
|---|-----------------------|
| Maximum radio-frequency power transmitted | 0.03 mW E.I.R.P. |

Hama GmbH & Co KG 86652 Monheim / Germany Service & Support www.hama.com +49 9091 502-0 DG

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hama GmbH & Co KG is under license. Other trademarks and trade names are those of their respective owners.www.hama.com/nep

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

Read More About This Manual & Download PDF:

Documents / Resources

hama 00004633 Bluetooth Remote Control [pdf] Instruction Manual 00004633 Bluetooth Remote Control, 00004633, Bluetooth Remote Control, Control

References

- h hama.com
- h Recycling Information hama.com
- h UCHWYT DO SMARTFONA PRO II 9,5 CM Z SAMOWYZW. BT | Hama
- h Suport pentru telefon "Pro II", de 9,5 cm, cu declanÈ™ator Bluetooth "BRS2" | Hama
- h "Pro II" Smartphone Holder, 9.5 cm, with "BRS2" Bluetooth® Remote Trigger | Hama
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.