


# hama 00054117 USB Notebook Combination Lock Instruction **Manual**

Home » Hama » hama 00054117 USB Notebook Combination Lock Instruction Manual



#### hama 00054117 USB Notebook Combination Lock



Thank you for choosing a Hama product. Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference.

#### **Contents**

- **1 Explanation of Warning Symbols and Notes**
- 2 Package Contents
- 3 Safety notes
- 4 Setting the combination number
- 5 Connection and locking of Notebook lock
- 6 Open the Notebook lock
- 7 Warranty Disclaimer
- 8 Service and Support
- 9 Documents / Resources
  - 9.1 References
- 10 Related Posts

# **Explanation of Warning Symbols and Notes**



# Warning

This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.



#### Note

This symbol is used to indicate additional information or important notes.

#### **Package Contents**

- USB Notebook lock
- These operating instructions

# Safety notes




#### Warning


Run the cable of the Notebook lock so that it does not pose a tripping hazard or block emergency exits.

# Setting the combination number


The combination is factory-set to `0000'. (Fig. 1)




• With a valid combination (`0000' factory setting, or stored personal code), push the cable towards the numbered wheels and hold it in position. (Fig. 2)



• Using the numbered wheels, enter your new, personalised combination (Fig. 3)



• Release the cable in order to save the new combination. (Fig. 4)





Make sure that the cable springs back to its original position after releasing it.



- We expressly recommend writing the new combination down and storing it in a safe place.
- We accept no liability for any damages resulting from lost or forgotten combinations.

#### Connection and locking of Notebook lock

- Attach the cable to a fixed object, e.g. foot of a table, cupboard.
- · Hold down the button on the lock.
- Plug the lock into the USB port on the device you want to secure.
- Then release the button.
- · Adjust the combination number.



This notebook lock is intended for use on USB sockets as defined by the USB specification. The function may b e limited if the USB socket has a special design.

# **Open the Notebook lock**

- Enter the correct combination number.
- · Press the button.
- · Pull the lock out of the USB port.

#### **Warranty Disclaimer**

Hama GmbH & Co KG assumes no liability and provides no warranty for damage resulting from improper installation/ mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

# **Service and Support**

Please contact Hama Product Consulting if you have any questions about this product.

Hotline: +49 9091 502-115 (German/English)

Further support information can be found here: www.hama.com

#### Hama GmbH & Co KG 86652 Monheim/ Germany www.hama.com

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.



#### **Documents / Resources**



#### References

• h hama.com

Manuals+,