



hama 00176554 WiFi Motion Detector Instruction Manual

[Home](#) » [Hama](#) » hama 00176554 WiFi Motion Detector Instruction Manual 

hama

00176554

WiFi Motion Detector
WiFi-Bewegungsmelder
Operating instruction

Link to App



de.hama.com/smarthome#smart-solution

Contents

- [1 It's so simple:](#)
- [2 Warranty Disclaimer](#)
- [3 Recycling Information](#)
- [4 Declaration of Conformity](#)
- [5 Safety notes](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

It's so simple:

- Download the Hama Smart Solution app from the Apple App Store or on Google Play.
- Start the Hama Smart Solution app
- If you're using it for the first time, you'll have to register and create a new account. If you already have an account, log in using your login details
- Remove the bottom of the item by turning anticlockwise, insert the batteries, and press and hold the button for 5 seconds.
- The LED on the front begins to flash quickly.
- Now click + in the upper-right corner and select others.
- Confirm with the Device is flashing quickly.
- Now enter the name of your WiFi network and the password, and confirm with Confirm.
- The device is now connected. Once the connection has been established, the LED stops flashing.
- Now you can set up and configure the motion detector using the app.

Warranty Disclaimer

Hama GmbH & Co KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product, or failure to observe the operating instructions and/or safety notes.

Recycling Information

Note on environmental protection:



After the implementation of the European Directive 2012/19/EU and 2006/66/EU in the national legal system, the following applies: Electric and electronic devices, as well as batteries, must not be disposed of with household waste. Consumers are obliged by law to return electrical and electronic devices as well as batteries at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country.

This symbol on the product, the instruction manual, or the package indicates that a product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices/Batteries, you are making an important contribution to protecting our environment.

Declaration of Conformity

Hereby, Hama GmbH & Co KG declares that the radio equipment type [00176554] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.hama.com -> 00176554 -> Downloads.

| | |
|---|---------|
| Frequency band(s) | 2,4 GHz |
| Maximum radio-frequency power transmitted | 0.05 W |

Safety notes

- The product is intended for private, noncommercial use only.
- Protect the product from dirt, moisture, and overheating, and only use it in an dry environment.
- If the product is to be operated outdoors, it may be operated only in protected outdoor areas.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Do not continue to operate the product if it becomes visibly damaged.

- Keep this product, like all electrical products, out of the reach of children!



Detailed operating instructions are available at www.hama.com



Hama GmbH & CoKG
86652 Monheim /Germany
Service & Support



“Google and Google Play are trademarks of Google LLC.”

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.
00176554/12.20

Documents / Resources

| | |
|--|--|
| | <p>hama 00176554 WiFi Motion Detector [pdf] Instruction Manual 00176554, WiFi Motion Detector</p> |
| | <p>hama 00176554 WiFi Motion Detector [pdf] Instruction Manual 00176554, WiFi Motion Detector</p> |
| | <p>hama 00176554 WiFi Motion Detector [pdf] Instruction Manual 00176554, WiFi Motion Detector, 00176554 WiFi Motion Detector</p> |

References

- [!\[\]\(effbd7993c63c039a58fd3395789cf3f_img.jpg\) Smart-Home-Geräte: Smarte Produkte kaufen | Hama DE](#)
- [!\[\]\(144980d038f2541d7b588a8a9132bd70_img.jpg\) hama.com](#)
- [!\[\]\(c4ce2d477989700c971cf3d240ad9283_img.jpg\) hama.com](#)

Manuals+.