



hama 00185869 MADEIRA Table Clock User Manual

[Home](#) » [Hama](#) » hama 00185869 MADEIRA Table Clock User Manual 

Contents

- 1 hama 00185869 MADEIRA Table Clock User Manual
- 2 Operating instruction
- 3 Warning
- 4 Note
- 5 Safety Notes
- 6 Getting Started
- 7 Replacing the battery
- 8 Mounting
- 9 Operation
- 10 Care and Maintenance
- 11 Warranty Disclaimer
- 12 Technical Data
- 13 Read More About This Manual & Download PDF:
- 14 Documents / Resources
 - 14.1 References



Operating instruction

Explanation of Warning Symbols and Notes



This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.



This symbol is used to indicate additional information or important notes.

1. Package Contents

- Table Clock
- 1 AA battery
- These operating instructions

Safety Notes

- This product is not suitable for lighting rooms in domestic
- Do not use the product in areas where the use of electronic devices is not
- Do not drop the product and do not expose it to any major
- Do not modify the product in any Doing so voids the warranty.
- Keep the packaging material out of the reach of children due to the risk of
- Dispose of packaging material immediately according to locally applicable
- The product is intended for private, non-commercial use
- Use the product for its intended purpose
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct

- Do not operate the product outside the power limits given in the
- Do not open the device or continue to operate it if it becomes
- Do not attempt to service or repair the product Leave any and all service work to qualified experts.
- Keep this product, as all electrical products, out of the reach of children!
- Use the item only in moderate climatic conditions



Warning – Batteries

- When inserting batteries, note the correct polarity (+ and – markings) and insert the batteries Failure to do so could result in the batteries leaking or exploding.
- Only use batteries that match the specified type. Keep the instructions for the correct choice of batteries included with the operating instructions of devices safe for future
- Before you insert the batteries, clean the battery contacts and the polarity
- Do not allow children to change batteries without
- Replace all the batteries in a set at the same
- Do not mix old and new batteries, or batteries of different types or from different manufacturers.
- Remove the batteries from products that are not being used for an extended period (unless these are being kept ready for an emergency).
- Do not short-circuit
- Do not charge
- Do not burn batteries or heat them
- Never open, damage or swallow batteries or allow them to enter the They can contain toxic, environmentally harmful heavy metals.
- Remove spent batteries from the product and dispose of them without
- Avoid storing, charging and using in extreme temperatures and at extremely low atmospheric pressures (such as at high altitudes).



- Ensure that batteries with damaged housings do not come into contact with water.
- Keep batteries out of the reach of

Warning – Batteries

- When inserting batteries, note the correct polarity (+ and – markings) and insert the batteries Failure to do so could result in the batteries leaking or exploding.
- Only use batteries that match the specified type. Keep the instructions for the correct choice of batteries included with the operating instructions of devices safe for future
- Before you insert the batteries, clean the battery contacts and the polarity
- Do not allow children to change batteries without
- Replace all the batteries in a set at the same
- Do not mix old and new batteries, or batteries of different types or from different manufacturers.
- Remove the batteries from products that are not being used for an extended period (unless these are being kept ready for an emergency).

- Do not short-circuit
- Do not charge
- Do not burn batteries or heat them
- Never open, damage or swallow batteries or allow them to enter the They can contain toxic, environmentally harmful heavy metals.
- Remove spent batteries from the product and dispose of them without
- Avoid storing, charging and using in extreme temperatures and at extremely low atmospheric pressures (such as at high altitudes).
- Ensure that batteries with damaged housings do not come into contact with water.
- Keep batteries out of the reach of

Getting Started

- Inserting the battery Remove the safety film if necessary as well as the contact breaker and insert the batteries with the correct polarity.
- The clock is ready for operation.

Replacing the battery

- Remove and dispose of any used batteries. Insert the new battery (AA).
- Ensure that the polarity of the battery corresponds to the symbols in the battery compartment.

Mounting

- Use the base to position the table clock on a level surface.
- Alternatively, you can mount the table clock on a wall using the recess on the back

Operation

- Once the battery is inserted properly, the clock will automatically start
- Use the setting wheel on the back of the clock to set the


Care and Maintenance

- Only clean this product with a slightly damp, lint-free cloth and do not use aggressive cleaning
- Make sure that water does not get into the

Warranty Disclaimer


Hama GmbH & Co KG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

Technical Data

	Table Clock
Power supply	1.5 V, 1x AA battery

Read More About This Manual & Download PDF:

Documents / Resources

	hama 00185869 MADEIRA Table Clock [pdf] User Manual 00185869 MADEIRA Table Clock, 00185869, MADEIRA Table Clock, Table Clock, Clock
---	--

References

- [hama.com](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.