

hama

hama USB 2.0
and USB 3.0
Card Reader



hama USB 2.0 and USB 3.0 Card Reader Instruction Manual

[Home](#) » [Hama](#) » hama USB 2.0 and USB 3.0 Card Reader Instruction Manual 

Contents

- [1 hama USB 2.0 and USB 3.0 Card Reader](#)
- [2 Explanation of Warning Symbols and Notes](#)
- [3 Safety Instructions](#)
- [4 System Requirements](#)
- [5 Product Features](#)
- [6 Getting started](#)
- [7 Care and Maintenance](#)
- [8 Exclusion of Warranty](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

hama

hama USB 2.0 and USB 3.0 Card Reader



Thank you for choosing a Hama product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner.

Explanation of Warning Symbols and Notes



Warning

This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.



Note

This symbol is used to indicate additional information or important notes.

Safety Instructions

- The product is intended for private, non-commercial use only.
- Protect the product from dirt, moisture and overheating and use it in dry rooms only.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Do not drop the product and do not expose it to any major shocks.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Do not open the device or continue to operate it if it becomes damaged.
- Dispose of packaging material immediately according to locally applicable regulations.
- Do not modify the product in any way. Doing so voids the warranty.
- Keep this product, as all electrical products, out of the reach of children!

System Requirements

The Card Reader supports the following operating systems:

- Windows 11 /10/ 8/7/ Vista /XP
- Mac OS 10.x or higher

Product Features

Note

- You will find a list of the supported card formats on the packaging or at www.hama.com (enter the item number in the search).
- Please refer to the packaging or our homepage www.hama.com (enter the item number in the search) to know whether the card reader supports UHS-I, UHS-II (SD /microSD) or UDMA (CompactFlash).
- The maximum data transfer rate is achieved when both the card and the card readers support UHS-I, UHS-II or UDMA.
- Please refer to the packaging or our homepage www.hama.com (enter the item number in the search) to know whether the card reader supports data exchange directly from memory card to memory card.

Getting started

Note –Compatibility

- USB 3.1/3.0 card readers are downward compatible with USB 2.0.
- No additional drivers are needed. The installation runs automatically.
- Plug your memory card into the appropriate slot of the Card Reader.
- Connect the Card Reader to an available USB port on your terminal device.
- You can now run the data transfer between your terminal device and the memory card.

Warning –Data Loss

- Ensure that the data transfer is done before you remove a memory card from your CardReader.
- Always use the eject function of your operating system before you remove a memory card from your Card Reader or disconnect your Card Reader (with inserted memory card) from your terminal device.
- Data loss can't be excluded at disregarded!
- Under no circumstance does Hama GmbH &CoKG accept liability for loss of data stored on data storage media.

Care and Maintenance

Only clean this product with as lightly damp, lint-free cloth and do not use aggressive cleaning agents. Make sure that water does not get into the product.

Exclusion of Warranty

Hama GmbH & CoKG assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

FAQ


- **Q: What should I do if the card reader is not recognized by my computer?**

A: Ensure the card reader is properly connected to the computer and try using a different USB port. You may also need to install drivers for the card reader.

- **Q: Can I use this card reader with SDXC memory cards?**

A: Yes, the USB 2.0 & USB 3.0 Card Reader supports SDXC memory cards along with other common formats.

Documents / Resources

	<p>hama USB 2.0 and USB 3.0 Card Reader [pdf] Instruction Manual mmo_36969773, 1652178335, 1626, 5217, USB 2.0 and USB 3.0 Card Reader, USB 3.0 Card Reader, Card Reader</p>
---	--

References

- hama.com
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.