



HANECO Dular Fix TRI Fixed and Adjustable LED Downlight Installation Guide

[Home](#) » [HANECO](#) » HANECO Dular Fix TRI Fixed and Adjustable LED Downlight Installation Guide 


HANECO Dular Fix TRI Fixed and Adjustable LED Downlight Installation Guide



This range of Haneco Lighting LED products have been tested as AS/NZS60598.2.2:2001 standards and are approved to the luminaire will not exceed 90°C when side abut or covered with ceiling insulation. Building insulation is used to abut and cover the luminaire must meet the following requirement:

1. Be of a type that can maintain it's dimensions and structural integrity when exposed to the maximum surface temperatures of the class of luminaire, being 90°C and must withstand a 30s needle flame test carried out in accordance with AS/NZS 60695.11.5 with the flame applied to all surfaces of the sample.


2. (New Zealand only) Loose fill insulation as defined in NZS4246 is not permitted to abut or cover this luminaire.




INFO & WARNING	
The minimum clearance distance from the top of the luminaire to any building insulation (mm).....	Omm
The minimum clearance distance from the side of the luminaire to any normally building insulation (mm).....	Omm

*INSTALLATION

1. Cut 90mm diameter hole
2. Connect live and neutral into the luminaire
3. Select CCT setting (WW, NW, CW)



4. Hold mounting clips up to sides of downlight and insert downlight into cut-out so that the springs retract onto rear face of ceiling



DULAR-FIX-TRI DULAR-FIX-BLK Diagram

Note: Ceiling max. thickness ≤14mm

Diagram Installation of the product is to be completed by a licensed electrician, in accordance with these instructions and relevant New Zealand standards and local regulations.

Warning:

a. Type Y: If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or by a service agent or licenced electrician in order to avoid hazard.



b. Non-user replicable light source.

c. The diffuser is not replaceable.

For more information

www.haneco.com.au

1300 001 LED



Contents

1 Documents /


Resources

1.1 References

Documents / Resources

	<p>HANECO Dular Fix TRI Fixed and Adjustable LED Downlight [pdf] Installation Guide Dular Fix TRI Fixed and Adjustable LED Downlight, Dular Fix TRI, Fixed and Adjustable LED Downlight, Adjustable LED Downlight, LED Downlight, Downlight</p>
--	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

-  [Haneco LED Lighting - Residential & Commercial Lighting | Australia](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.