

Hanwha Vision PNM-C32083RVQ Network Camera



Hanwha Vision PNM-C32083RVQ Network Camera User Guide

[Home](#) » [Hanwha Vision](#) » Hanwha Vision PNM-C32083RVQ Network Camera User Guide 

Contents

- 1 [Hanwha Vision PNM-C32083RVQ Network Camera](#)
- 2 [Warranty](#)
- 3 [SAFETY INFORMATION](#)
- 4 [COMPONENT](#)
- 5 [INSTALLATION](#)
- 6 [PASSWORD SETTING](#)
- 7 [CONNECTING TO WIFI](#)
- 8 [Documents / Resources](#)
 - 8.1 [References](#)
- 9 [Related Posts](#)



Hanwha Vision PNM-C32083RVQ Network Camera



Important

Please check 'Manuals' from our website, before connecting to the Supply,

<https://www.hanwhavision.com/en/download-data/>

Warranty

Please check "Product warranty information" from our website.

<https://www.hanwhavision.com/en/support/warranty/>

We recommend to use the officially compatible VMS version or latest Hanwha NVR version when integrating with VMS or Hanwha NVR.

The Risk Group 1 of a LEDs include in the equipment, so should be attached RG1 warning label at the end-product.



Hanwha Vision cares for the environment at all product manufacturing stages , and is taking measures to provide customers with more environmentally friendly products.

The Eco mark represents Hanwha Vision's devotion to creating environmentally friendly products and indicates that the product satisfies the EU RoHS Directive.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government

office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.




Correct disposal of batteries in this product

(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.



To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.


SAFETY INFORMATION




COMPONENT

As for each sales country, accessories are not the same.




 Options (not included)




SPP-C7400

INSTALLATION


1



2





3




4



• Not Included : Micro SD Card






6-1 • Directly installing on wall/ceiling




**7-1** • Installing using pipe


7-2




7-3




8




9






11-1


- Installing network cable (IP66)




11-2




11-3




12-1 • Installing alarm/audio cables




12-2 • Not Included : alarm/audio cable




12-3



13




14



15

• Not Included : Wi-Fi dongle, OTG adapter




16







17



18



19



20



PASSWORD SETTING

When you access the product for the first time, you must register the login password.

Administrator password change

New password

Confirm new password

- If the password is 8 to 9 characters long, it must include at least 3 of the following character types: English uppercase letters, English lowercase letters, numbers, and special characters. (support up to 64 characters)
- If the password is 10 characters or longer, it must include at least 2 of the following character types: English uppercase letters, English lowercase letters, numbers, and special characters.
- ID may not be used as password. The password and ID cannot be identical.
- The following special characters can be used: ~`!@#\$%^&*()_~+=[]\;:'"<>.,?/
- You may not use more than 4 consecutive characters. (example: 1234, abcd, etc.)
- You may not use the same character 4 or more times consecutively. (example: !!!!, 1111, aaaa, etc.)

Apply

For a new password with 8 to 9 characters, you must use at least 3 of the following: uppercase/ lowercase letters, numbers and special characters. For a password with 10 characters or longer, you must use at least 2 types of those mentioned.

(support up to 64 characters)

– Special characters that are allowed. : ~`!@#\$%^&*()_~+=[]\;:'"<>.,?/

- Space is not allowed for password.
- For higher security, you are not recommended to repeat the same characters or consecutive keyboard inputs for your passwords.
- If you lost your password, you can press the [RESET] button to initialize the product. So, don't lose your password by using a memo pad or memorizing it.

LOGIN

Whenever you access the camera, the login window appears.

Enter the User ID and password to access the camera.

- Enter "admin" in the <User Name> input box.
- Enter the password in the <Password> input field.
- Click [Sign in].

CONNECTING TO WIFI

Camera setting

1. Connect OTG adapter (5-pin) and Wi-Fi dongle to the micro USB terminal.

Smartphone setting

1. Install the Wisenet Installation application.

2. Select the camera SSID after turning on the WiFi.
3. Run the Wisenet Installation application.
4. When you log in to the camera, the video will be connected.
` The video will be played without being logged in during the initial connection.
5. You can adjust angle of view while watching the video through smartphone.

Türkiye Distribütörü

- **EDS Elektronik Destek Sanayi ve Ticaret Ltd. Şti.**

Meclis Mah. Teraziler Cad. Hayran Sk. (Eskisi Kılıç Sk.) No: 4 Sancaktepe / İstanbul / Türkiye Tel
+90.216.313.25.15 Faks +90.216.528.45.98

- **Koyuncu Elektronik Bilgi İşlem Sistemleri San. ve Dış. Tic. A.Ş.**

Emek Mah. Ordu Cad. No:18 Sancaktepe / İstanbul / Türkiye
Tel +90.216.528.88.88 Faks +90.216.313.18.18

- **NFS Teknoloji ve Otomasyon Sistemleri San. Ve Tic. Ltd. Sti.**

Cumhuriyet Mah Şair M.Akif Ersoy Sk. No:36 Üsküdar / İstanbul / Türkiye
Tel +90.216.505.82.28 Faks +90.216.505.82.29


- **Sensonet Teknoloji Elekt. ve Biliş. Hiz. San. ve Tic. Ltd. Şti.**

Ramazanoğlu Mah. Transtek Cad. No: 2 Pendik / İstanbul / Türkiye
Tel +90.216.999.49.49 Faks +90.212.381.61.02

- **ENTES ELEKTRONİK CİHAZLAR İMALAT VE TİC. A.Ş.**

Dudullu Org.San.Bölg. 1. Cad. No:23 34776 Ümraniye – İstanbul / Türkiye
Tel +90.216.313.01.10 Faks +90.216.314.16.15
Cihazın Ticaret Bakanlığınca önerilen ortalama ömrü
Cihazın EEE yönetmeliklerine uygun olduğuna benzer beyan

Documents / Resources

	Hanwha Vision PNM-C32083RVQ Network Camera [pdf] User Guide PNM-C32083RVQ Network Camera, PNM-C32083RVQ, Network Camera, Camera
---	--

References

- [User Manual](#)

