

Hanwha Vision TNV-C8011RW Web Camera User Manual

Home » Hanwha Vision » Hanwha Vision TNV-C8011RW Web Camera User Manual

Contents

- 1 Product Information
 - 1.1 Specifications:
- **2 SAFETY INFORMATION**
- **3 COMPONENT**
- **4 INSTALLATION**
 - 4.1 Log in
- **5 Connecting to WIFI**
- 6 Documents /

Resources

6.1 References

Product Information

Specifications:

• Model: TNV-C8011RW

Compatible VMS Version: Officially compatible VMS version or latest Hanwha NVR version

• LEDs Risk Group: RG1

· Environmental Certification: Eco mark indicating compliance with EU RoHS Directive

Important

Please check 'Manuals' from our website, before connecting to the Supply, https://www.hanwhavision.com/en/download-data/

Warranty

Please check "Product warranty information" from our website. https://www.hanwhavision.com/en/support/warrant

We recommend to use the officially compatible VMS version or latest Hanwha NVR version when integrating with VMS or Hanwha NVR.

The Risk Group 1 of a LEDs include in the equipment, so should be attached RG1 warning label at the end-

product.



Hanwha Vision cares for the environment at all product manufacturing stages, and is taking measures to provide customers with more environmentally friendly products.

The Eco mark represents Hanwha Vision's devotion to creating environmentally friendly products, and indicates that the product satisfies the EU RoHS Directive.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems) This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items

from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



Correct disposal of batteries in this product


(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these

substances can cause harm to human health or the environment.


To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

SAFETY INFORMATION




COMPONENT


Accessories vary by country of sale.





INSTALLATION





2 Not included: Micro SD card

























Password Setting

When accessing the product for the first time, you must first register a login password.

New password	
Confirm new password	
English uppercase letters 64 characters) If the password is 10 characters english uppercase letters ID may not be used as particle following special characters. You may not use more that	haracters long, it must include at least 3 of the following character types: , English lowercase letters, numbers, and special characters. (support up to racters or longer, it must include at least 2 of the following character types: , English lowercase letters, numbers, and special characters. ssword. The password and ID cannot be identical. racters can be used: ~'!@#\$%^&*()+={\[\;

- The new password must be at least 8~9 characters, including 3 types of English uppercase and lowercase, numbers and special characters, if used For more than 10 characters, at least 2 types must be used. (Maximum 64 characters)
 - The allowed special characters are: ~`!@#\$%^&*()_-+={ }[]|\;:""<>.,?
- · Password cannot contain spaces.
- For higher security, it is recommended that you do not reuse Use the same characters as your password, and do not use consecutive Keyboard input as password.
- If you lose your password, you can initialize the product by holding down the [RESET] button. So please use a notepad to write down or remember your password in case you lose it.

Log in

Whenever the camera is accessed, a login window appears. Enter user ID and password to access camera.

- 1. Enter "admin" in the <User Name> input box.
- 2. Enter the password in the <Password> input field.
- 3. Click [Sign in].

Connecting to WIFI

Camera settings

- 1. Connect the OTG adapter (5-pin) and WiFi receiver to Camera settings.
- 2. Install the Wisenet Installation application.
- 3. After turning on WiFi, select the camera.
- 4. Run the Wisenet Installation application.
- 5. After logging in to the camera, you can connect to the video.
 - No login required to play videos during initial connection.
- 6. You can adjust the viewing angle while watching videos on your smartphone.





To be used for its intended purpose Under normal conditions Service life: 7 years.



Documents / Resources



Hanwha Vision TNV-C8011RW Web Camera [pdf] User Manual TNV-C8011RW Web Camera, TNV-C8011RW, Web Camera, Camera

References

- W Warranty: Hanwha Vision Global Vision Solution Provider
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.