



## Home » Harmony Twenty Two » Harmony Twenty Two HTT-21 True Wireless Stereo Earbuds User Manual ₹

#### Contents [ hide ]

- 1 Harmony Twenty Two HTT-21 True Wireless Stereo Earbuds
- 2 Product Specifications
- 3 Package Contents
- 4 Product Overview
- 5 Touch Control Diagram
- 6 Wearing Earbuds
- 7 Power ON/ OFF
- 8 Pairing
- 9 Bluetooth Lost
- 10 Notes For Signal Transmission Distance
- 11 Reset
- 12 Touch Operation
- 13 Earbuds low battery alarm
- 14 Charge your earbuds
- 15 Product Parameter
- 16 Earbuds Warning
- 17 Battery Warning
- 18 FCC
- 19 Frequently Asked Questions
- 20 Documents / Resources
  - 20.1 References

# **Harmony**

## **Harmony Twenty Two HTT-21 True Wireless Stereo Earbuds**



## **Product Specifications**

• Model: HTT-21

• Type: True Wireless Stereo Earbuds


• Control: Touch Control

• Connectivity: Bluetooth

• Charging Port: Type-C

• Features: Ambient Noise Cancellation Mic, Voice Assistant


## **Package Contents**



## Type- C Charging Cable × 1PC

User Manual × 1 PC


#### **Product Overview**



## **Touch Control Diagram**




The touch area (MFB Touch Panel) is located in the upper part of earbuds handle.



## **Wearing Earbuds**



Note: The left earbud marked with L is worn in the left ear, and the right earbud marked with R is worn in the right ear.




## Power ON/ OFF



#### Power on

Auto: Open the charging case to power on


Manually: Press and hold the MFB for 3s.



Open cover to power on

#### Power off


Auto: Place both Earbud in your charging case, Close the lid. Manually: Press and hold the MFB for 5s.



## **Pairing**



- 1. Open the charging case, and take out the earbuds, earbud will pair automatically, One of the earbuds flashes b lue and red, the another earbud light goes out.
- 2. Activate Bluetooth on the device, turn on Bluetooth, search for pairing name "HTT-21" and click on it.



Tips: Next use, Open the charging case, earbuds auto connect phone.

#### **Single Mode**

When on dual mode, put one earbud into the charging case.

Only take one earbud out of the charging case and connect it.



#### **Bluetooth Lost**




- 1. Turn off mobile phone's Bluetooth, earbuds will enter the pairing mode and can pair with other devices.
- 2. If the connection range is exceeded, the earbuds will enter the back connection mode. No connection within 5 minutes, the earbuds will turn off

## **Notes For Signal Transmission Distance**

(as illustrate)






#### Reset



If your earbuds accidentally only get one earbud to work, or fail to pair, please reset the earphone.

- 1. Delete all "HTT-21" Bluetooth records on the phone, and turn off Bluetooth
- 2. Put earbuds into charging case, and then take out to pairing modes, tap L & R MFB 5 times simultaneously, hear "DU" prompt voice to clear all pairing.
- 3. Put earbuds into charging case.



Put earbuds into charging case

## **Touch Operation**



## Left Earbud







1x Play / Pause Tap the MFB once





1x Answer the call Tap the MFB once



2x Previous Track

Double tap the left MFB



2x End Call /Reject call Double tap the MFB



3x Volume -

Triple tap the left MFB




4x Game mode Four tap the MFB



1.5s Voice assistant

Press and hold the MFB for 1.5s



## Earbuds low battery alarm



When the battery power is low, every 1 minute voice reminder "Lower battery" and Red light double flashing, until the battery power is run out and turn off.




## Charge your earbuds



Place your earbuds the charging case and close the lid, earbuds automatically complete

#### charge.



#### **Product Parameter**



## Earbud(each)

• Model Name: HTT-21

• Bluetooth Version: V5.4

Speaker: Ф13mm

• Bluetooth Range: 10m/ 33ft(with out obstacles)

• Technology: HSP/ HFP/ A2DP/ AVRCP

• Frequency Range: 20Hz~20KHz

• Weight: 4g

• **Size:** 32.5\*25\*26mm

• Charging Time: 0.5H

• Battery Capacity: 40mAh

• Play Music Time: 6H

• Input: DC ==5V 0.08A

## **Charging Case**

• Weight: 37g

• **Size:** 50\*54\*33mm

• Charging Time: 2H

• Battery Capacity: 500mAh

• Input: DC 5V == 0.3A

## **Earbuds Warning**



- 1. Please do not place the product in an environment where the temperature is too low(above 45°C or below 0°C).
- 2. Do not dismantle or repair the earbuds under any circumstances. if necessary, please send the product to the seller for repair.
- 3. Do not throw and drop the earbuds to avoid damage.
- 4. The earbuds and the BT devices will be disconnected if the distance between them is more than 10 meters.
- 5. Keep the device and accessories away from children and pets.
- 6. Do not put the earbuds into the washing machine.

## **Battery Warning**



- 1. The battery in the product may cause fire disaster or risk of chemical burning if mishandled.
- 2. Please charge with a rated voltage charger.
- 3. The discard of battery should obey local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause a explosion.
- 4. Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause damage to prodct.













#### **FCC**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur

in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following

measures:

Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for

compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

two conditions:

1. this device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may

cause undesired operation.

FCC ID: 2BONF-HTT-21


**Frequently Asked Questions** 

Q: How do I know when the earbuds are low on battery?

A: When the battery power is low, you will receive a voice reminder every minute

along with a red light double flashing until the battery runs out.

**Documents / Resources** 



Website

☐ Save my name, email, and website in this browser for the next time I comment.

## **Post Comment**

#### Search:

e.g. whirlpool wrf535swhz

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.