



HARPER HRS-440 Radio with MP3 Player and Bluetooth Function Instruction Manual

[Home](#) » [HARPER](#) » HARPER HRS-440 Radio with MP3 Player and Bluetooth Function Instruction Manual 

Contents


- [1 HARPER HRS-440 Radio with MP3 Player and Bluetooth Function](#)
- [2 SPECIFICATION](#)
- [3 OPERATION](#)
- [4 INTERNAL BLUETOOTH FUNCTION OPERATION](#)
- [5 POWER SUPPLY](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



HARPER HRS-440 Radio with MP3 Player and Bluetooth Function



SPECIFICATION



OPERATION

1. Battery operation

- **A.** Load size UM1/D*2 batteries or 3.7V lithium battery into battery compartment.
 - **B.** Please charge 8 hours for the first time to use lithium battery:
 - **C.** Turn off the unit. The external DC(5V) charging time is 6 to 10 hours.
2. Push the function/band switch to select FM/FM/SW, turn the tuning knob to search stations.
 3. Turn the volume knob clockwise to increase volume, turn anti-clockwise to reduce volume.
 4. The external telescopic antenna for optimum reception on FM/SW.
 5. The unit equipped with a built-in ferrite antenna for AM. This built-in antenna is directional so reception from distant station may be improved by rotating the unit.
 6. The function /band switch select to "MP3.BT" position for music play.

INTERNAL BLUETOOTH FUNCTION OPERATION

Turn on the radio bluetooth and the bluetooth of cellphone or other mobile devices with bluetooth function, start to search a bluetooth name "HRS-440" and pair with it.

After successful pairing, it will beep. Now the cellphone or other mobile device can play the mp3 through bluetooth on radio. You can select /play and pause the mp3 by pressing NEXT/PREV/PLAY buttons on radio or cellphone or other mobile devices.

If you want to stop using bluetooth function just need to turn off the bluetooth in the cellphone or other mobile devices. If you want to use it again,only need to open the bluetooth in cellphone or other mobile devixes again and pair with “HRS-440” automatically.

POWER SUPPLY

DC:

- 3V(UM-1 /D*2pcs Batteries
- 3.V Lithium Battery

Frequency:

- AM :530-1600KHz
- FM:87-108MHz
- SW:5.9-10.8MHz

Warning

- The power supply of DC can not
 - over5V


When you don't want to use the radio for a long time,please take out the batteries from the unit.

ADDRESS: Harper International Trading Limited 15f, Radio City, 505 Hennessy Road, Causeway

PHONE: +74951330210,

EMAIL: info@harper.ru

Documents / Resources

 <p>RADIO WITH MP3 PLAYER AND BLUETOOTH FUNCTION HRS-440</p>	<p>HARPER HRS-440 Radio with MP3 Player and Bluetooth Function [pdf] Instruction Manual HRS-440 Radio with MP3 Player and Bluetooth Function, HRS-440, Radio with MP3 Player and Bluetooth Function, Radio with MP3 Player and Bluetooth, Bluetooth and MP3 Player Radio, Player Radio, Radio</p>
---	---