



Hatch Grow User Manual

[Home](#) » [Support](#) » Hatch Grow User Manual 

Contents

- [1 Hatch Grow](#)
- [2 GETTING STARTED](#)
- [3 GETTING TO KNOW HATCH BABY GROW](#)
- [4 CARE AND SAFETY](#)
- [5 FCC Compliance Statement](#)
- [6 DOWNLOAD](#)
- [7 Related Posts](#)

Hatch Grow



USER MANUAL

Smart Changing Pad and Scale


GETTING STARTED

Step 1: Remove the battery tab

Remove the battery tab from the bottom of Grow before using. Grow comes ready to use with 3 AA batteries.

Step 2: Move Grow into place

Place Grow on a flat and level surface, like the changing table or dresser in your nursery. It should be free from touching any walls, blankets or baby gear.



Step 3: Set up the safety belt

If you choose to use the safety belt, attach the rings of the belt to the hooks on the sides of Grow. Click up into place.

Step 4: Download the Hatch Baby app


You'll be able to test and use Grow once the app is downloaded.

Search for the Hatch Baby app on the Apple App Store or Google Play. Download the app to your phone or tablet. The app is compatible with devices running iOS (9 and higher) and Android (KitKat and higher).



See the app to learn more
about using Hatch Baby Grow.

GETTING TO KNOW HATCH BABY GROW




Foam Changing Surface

Easy to clean with a damp cloth or baby wipe.

Safety Belt Hooks

Attach the safety belt to the hooks on the sides of Grow. If you choose not to use the safety belt, please remove it from the safety belt hooks completely. Do not tuck it under the base. It may result in inaccurate readings.



Battery Compartment

To replace batteries, use a screwdriver to open the battery compartment cover. Grow requires 3 AA batteries.

Feet

All four feet of the device must be on a flat, level surface to take your baby's weight. Handle feet with care!

CARE AND SAFETY

Care Instructions

Wipe clean with a baby wipe, damp towel or cloth.

CAUTION: The device may be damaged if the underside of the scale comes into contact with liquid.

For Baby's Safety

WARNING-FALL HAZARD To prevent death or serious injury, always keep child within arm's reach. Please use on a level, stable and structurally sound surface of at least 32" by 16" (81 cm x 40 cm). Do not lift changing pad with child on it. Maximum weight is 44 pounds (20 kg).

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this

device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: QECGWBMD0X

IC ID: 22248-GWBMD0X

DOWNLOAD

Hatch Grow User Manual – [[Download PDF](#)]
