




Hatch Restore Smart Sound Machine Alarm Clock User Guide

[Home](#) » [Hatch](#) » Hatch Restore Smart Sound Machine Alarm Clock User Guide 

Hatch Restore Smart Sound Machine Alarm Clock



Contents

1 Meet your Hatch Restore

2 Controls

3 Rest Button

4 Rise Button

5 Rise Button

6 Volume

7 Brightness

8 Quick Tips

9 Documents / Resources

9.1 References

10 Related Posts

Meet your Hatch Restore

Step 1

Connect the power cable to Restore then plug it into your power outlet. Always keep your device plugged in.




Step 2

Download the Hatch Sleep app on your phone or tablet from the Apple App or Google Play store.



Step 3

Complete the steps in the Hatch Sleep app to connect your Restore. Wi-Fi is required.




Controls



Rest Button

- Press when you're ready to rest.
- Press again to move to the next step.
- Press and hold to stop.



Rise Button

- Press when you're ready to rise.
- Press again to move to the next step.
- Press and hold to stop.


Rise Button

- Press when you're ready to rise.
- Press again to move to the next step.
- Press and hold to stop.



Volume

Tap the lower right and left corners to adjust the volume.



Brightness

Tap above and below the clock display to adjust the brightness of the main light.



Tap for the time

When the clock display is hidden, gently tap Restore anywhere to check the time.

Quick Tips



Clock Brightness

You can adjust the brightness of the clock display in the Hatch app settings.



Alarm Snooze

Press either the Rest or Rise button to snooze your alarm. Press and hold to stop the alarm.



Hatch support is a dream

Contact us at hatch.co/support
Follow @hatchforsleep and see what dreams are made of.

Documents / Resources

	<p>Hatch Restore Smart Sound Machine Alarm Clock [pdf] User Guide Restore Smart Sound Machine Alarm Clock, Restore, Smart Sound Machine Alarm Clock, Mac hine Alarm Clock, Alarm Clock, Clock</p>
--	---

References

- [User Manual](#)