HCS RC366C Remote Control Replacement IR





HCS RC366C Remote Control Replacement IR Instructions

Home » HCS » HCS RC366C Remote Control Replacement IR Instructions

Contents

- 1 HCS RC366C Remote Control Replacement
- IR
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Frequently Asked Questions (FAQ)
- **5 Know your Remote**
- **6 BLE Manual Pairing**
- **7 Voice Function**
- **8 FCC information**
- 9 RF exposure statement
- 10 Documents / Resources
 - 10.1 References

HCS

HCS RC366C Remote Control Replacement IR



Product Information

Specifications:

Model: RC3662811/01BRFCC ID: 2AGOFRC366C

Compliance: FCC Part 15, Industry Canada's license-exempt RSSs
RF Exposure Compliance: FCC and ISED radiation exposure limits

Product Usage Instructions

Getting Started

Before using the remote control, ensure you have read the user manual completely.

Battery Installation

Open the battery compartment on the back of the remote and insert the required batteries following the correct polarity.

Pairing the Remote

If needed, follow the instructions in your device's manual to pair the remote control with the corresponding device.

Basic Operations

Use the buttons on the remote to navigate through menus, change settings, and control your device.

Maintenance

Keep the remote clean and avoid exposure to water or extreme temperatures to ensure optimal performance.

Frequently Asked Questions (FAQ)

· How do I replace the batteries?

To replace the batteries, open the battery compartment on the back of the remote, remove the old batteries, and insert new ones following the correct polarity.

Can I use this remote with multiple devices?

Depending on the compatibility, you may be able to use this remote with multiple devices. Refer to the user manual of your specific device for instructions on pairing.

Know your Remote

1 Papar 578	TV POWER	2 TV INPUT/SOURCE	3 STB POWER
2 3	B1017 4	5	6
5 6 7	DIGIT 1	DIGIT 2	DIGIT 3
8) (9)	DIGIT 4	DIGIT 5	DIGIT 6
10	DIGIT 7	11 DIGIT 8	12 DIGIT 9
		13 DIGIT 0	
. 14	GUIDE		15 SENTRICS MENU
		16 UP	
17	LEFT	18 OK	19 RIGHT
н-)	ELI I	20 DOWN	INGIII
21	BACK		22 RECORD
RICS. 23	V01 -	24	25
26	VOL+	MUTE 27	28 CH+
	VOL-	VOICE	CH-

BLE Manual Pairing

- Step 1: input 2*AAA batteries to Battery compartment.
- Step 2: point the remote to the STB IR receiver.
- Step 3: Pressed & hold <<SENTRICS MENU>> & << Digit 1>> keys for more than 3 seconds.
 - If pairing is successful, the STB LED will blink 2x (short pulse).
 - If the pairing is unsuccessful, the Both STB & TV LED will blink 4x (short pulse).
 - The remote can be unpaired by pressing <<SENTRICS MENU>> & <<DIGIT 9>> for more than 3 seconds. The STB LED will blink 2x (short pulse) if un-pairing is successful.

Voice Function

RCU features a button to activate the Voice Search application to search for content by speaking through the remote's built-in microphone.

FCC information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC information:

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- 1. This device may not cause interference; and
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement

This equipment complies with the FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Documents / Resources



HCS RC366C Remote Control Replacement IR [pdf] Instructions

RC366C Remote Control Replacement IR, RC366C, Remote Control Replacement IR, Control Replacement IR, Replacement IR, IR

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.