



HDWR CTR12
Time and
Attendance
Recorder



HDWR CTR12 Time and Attendance Recorder User Manual

[Home](#) » [HDWR](#) » HDWR CTR12 Time and Attendance Recorder User Manual 

Contents

- [1 HDWR CTR12 Time and Attendance Recorder](#)
- [2 Product Usage Instructions](#)
- [3 Specifications](#)
- [4 Original user manual](#)
- [5 Buttons and Function Description](#)
- [6 Shift work time settings](#)
- [7 Adding employees](#)
- [8 Downloading and viewing attendance reports](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)



HDWR CTR12 Time and Attendance Recorder



Specifications

- Product: Time and attendance recorder CTR12
- Mounting: Wall mountable
- Interface: Access control interface
- Settings: Shift work time, department names, attendance policy
- Reports: Downloadable via USB

Product Usage Instructions

Mounting to the Wall

1. Remove the bottom screw with a screwdriver.
2. Remove the back cover from the device.
3. Align the holes drilled in the wall and screw the back cover to the wall with screws.
4. Install the device on the back cover.
5. Lock the back cover with the bottom screw.

Access Settings

To access settings, follow these steps

1. Press [M] key to enter the main menu.
2. Press T key to select Setting.

3. Press [OK] key to enter the interface.
4. Select Access to set door open time, anti-disassembly alarm, doorbell function, and other settings.

Shift Work Time Settings

1. Press [MENU] and enter the main menu.
2. Select Attend. Rules -> Shift -> Shift 1 (up to 10 shifts can be set).
3. Press the [OK] button to enter the hour modification option.
4. Use the +/- buttons to select the numbers you want to modify.
5. Press [OK] to confirm the changes. Press [ESC] to exit the settings.

Frequently Asked Questions (FAQ)

Q: How do I reset the device to factory settings?

A: To reset the device to factory settings, go to the main menu, navigate to System Settings, and select Reset to Factory Defaults. Confirm the action when prompted.

Specifications

- Warranty: 1 year
- Model: CTR12
- Material: ABS+PC
- Verification Type: Fingerprint, Password, 125kHz RFID Card
- Frequency of Compatible RFID Accessories: 125 kHz Key Fobs and Cards
- Max number of employees in the base: 1000
- Max number of administrators in the database: 10
- Max. number of fingerprints in the database: 1000
- Max. number of entries in the database: 1000
- Max. log capacity in the database: 100,000
- Number of buttons: 16
- Display: 2.4 inch, TFT LCD
- Supported drives: USB FAT32
- Connectors: USB
- Access Control: Relay Output
- Magnetic Input: One-way Output
- Ring/Alarm: Local Transmission or Relay Output
- Wiegand Input/Output: WG26/WG34
- Operating Voltage: DC12V
- Resistance: IP54
- Error rate: 1/1,000,000
- Operating Temperature: 0~60
- Operating Humidity: 20~80%
- Device dimensions: 19.2 x 8.5 x 3.7 cm
- Package dimensions: 22.5 x 11 x 5.3 cm

- Device weight: 250 g
- Package weight: 310 g

Features

- Verification Type: Fingerprint, Password, RFID Card/Key Fob
- RFID technology: Yes
- Max number of employees in the base: 1000
- Communication: USB
- LAN: No
- Extra battery: no
- Power supply: 12V

Set contents

- CTR12 Time and Attendance Recorder
- Communication tape for access control (20 cm)
- Mounting pins and screws


Original user manual

Mounting to the wall:


1. Remove the bottom screw with a screwdriver




2. Remove the back cover from the device




3. Align the holes drilled in the wall and screw the back cover to the wall with screws




4. Install the device on the back cover



5. Lock the back cover with the bottom screw




Description of access control interface:



Access settings:

Press [M] key to enter the main menu, press T key to select “Setting”, press [OK] key to enter the interface, and then select “Access”, which can set door open time, anti-disassembly alarm, doorbell function and other settings.

Buttons and Function Description



Shift work time settings

1.



Press [MENU] and enter the main menu, press to select “Attend. Rules” -> “Shift” -> “Shift 1” (up to 10 shifts can be set)

1. Press the [OK] button to enter the hour modification option.

Use the and buttons ▼ and ▲ to select the numbers you want to modify. On the left are the shift start times and minutes, and on the right are the shift end hours and minutes. After changing the value in the selected field, press [OK] to confirm the changes. To exit the settings, press [ESC].

EXAMPLE

The company works in a single shift mode without overtime, morning check-in time 08:00, afternoon end time 17:00, employee drop-off 2 times a day.

Setting for Shift 1 as below

Time 1 8:00-17:00
Time2 0:00-0:00
Overtime 0:00-0:00

Note: In case there are no more shift options, Shift1 is by default.

Setting the department names:

Department	
1.Dept. 1	Not Set1
2.Dept. 2	Not Set2
3.Dept. 3	Not Set3
4.Dept. 4	Not Set4
5.Dept. 5	Not Set5
Exit-ESC	Continue-OK

Setting department names

Press [MENU] and enter the main menu. Press to select “Attend. Rules” and press the [OK] button to enter. Press V to select

“Department” and press [OK] to enter the department modification interface. Select your department with the arrows and the [OK] button to enter a new name, then press the [OK] button to save.

Dept. 1							
Week	Mon	Tue	Wed	Thu	Fri	Sat	Sun
	01	01	01	01	01	01	01
Schedule: 1-10 Shift, empty/0-holidays							
Exit-ESC				Ok-OK			

Set changes for a department

Press [MENU] and enter the main menu. Press T to select “Attend. Rules” and press the [OK] button to enter.

Press I to select

“Department” and press [OK] to enter to the department modification interface. Then select Shift1 to display the Zm1an settings interface for the department and days of the week. Numbers 1~10 indicate the Shift from 1 to 101 respectively, position 00 means holidays.

Note: When shift work is complicated or the department’s schedule doesn’t meet your requirements, we recommend that you download the attendance setup form to set up shifts and schedules for workers.

Attendance policy settings

Attend.Rules	
1. Company	
2. Shift	
3. Department	
4. Scheduling	Department
5. Attend. Time Allowed	
Exit-ESC	Continue-OK

Press [MENU] to enter the main menu, press to select “Attend. Rules”.

From this level you can set m.in:

- company name,
- shift work and departmental arrangement,
- Alarms

- permissible time of delays,
- Acceptable early exit time
- Repeated incorrect attendance time

Adding employees

The image shows two screenshots of a system interface for adding employees.

The top screenshot is titled "Enroll" and contains the following fields and buttons:


- ID: 000001
- Name: (empty field)
- Dept.: Not Set1
- Enroll button

The bottom screenshot is titled "Employee Info" and displays a list of fields with their current values:

Employee Info	
1.ID	000001
2.Name	0
3.Finger	0
4.Password	0
5.Dept.	Not Set1
Exit-ESC Continue-OK	

1. Press [MENU] to enter the main menu, select "Employee" and press OK. To add a new employee, select the "Enroll" option.
2. After filling in all the data – ID (each subsequent number is assigned automatically), user name and associated department, go down to the "Enroll" key with the arrows, confirm [OK], and then exit [ESC]. To enter the employee edition, you need to go back to the "Employee" menu and select the "Browse" option. After entering, you can use the arrows and the [OK] button to select the desired employee to configure its options:
 - ID: The number assigned automatically by the system (up to a maximum of 1000 employees can be added).
 - Name: Ability to edit username
 - Finger: Ability to add the employee's fingerprint by reading it 2 times. To delete stored prints, enter this option and press [MENU].
 - Card: An RFID card can be assigned to an employee.
 - Password: A maximum 6-character user password can be set.
 - Dept: Ability to select department affiliation.
 - Authority: press [OK] to select user permissions.

Downloading and viewing attendance reports



1. Connect an external drive or flash drive to the DVR's USB port.
2. Press [MENU] to enter the main menu, then press v to select "Attendance"
3. Use the Select Reports to Download button, press the [OK] key to enter the report download interface, enter the time period you want to generate the report from, and press the [OK] key to download it.

Remark:

Downloading reports on an external drive or flash drive requires FAT32 formatting. If the recording device does not recognize the disc, first format the disc to FAT32 format, and then reconnect it.

Documents / Resources

<p>User Manual</p> <p>Time and attendance recorder</p> <p>CTR12</p>	<p>HDWR CTR12 Time and Attendance Recorder [pdf] User Manual</p> <p>CTR12 Time and Attendance Recorder, CTR12, Time and Attendance Recorder, Attendance Recorder, Recorder</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.