

HEAD 3 Hand Watch with Date User Manual

Home » HEAD » HEAD 3 Hand Watch with Date User Manual



Contents


- 1 HEAD 3 Hand Watch with Date
- **2 OVERVIEW**
- 3 How to set time
- 4 How to set date and day display of the week
- **5 Power depletion warning function**
- 6 Documents / Resources
- 7 Related Posts



HEAD 3 Hand Watch with Date



OVERVIEW



	Crown position		
	N = normal	1 = 1st click	2 = 2nd click
Crown	Free	 Turn counterclockwise for date change Turn clockwise for day of the week change 	Time setting

How to set time

- 1. Pull the crown out to the 2nd click position when the second hand is at the 12 o'clock position.
- 2. Turn the crown to set the hour and minute hands. Consider am/pm when setting the hour and minute hands to the desired time. When setting the minute hand, set it 4 to 5 minutes ahead of the desired time, then turn it back to the exact time.
- 3. Push the crown back to the normal position.

How to set date and day display of the week

- 1. Pull the crown out to the 1st click position.
- 2. Turn the crown to set the date and the day of the week. Do not set the date and day of the week between 9:00 pm and 4:00 am.
- 3. Push the crown back to the normal position.

Tip: If the date changes during daytime, it happens when am/pm is set incorrectly. Advance the hour hand by 12 hours.

Power depletion warning function

When the battery is nearing the end, the second hand will move at two-second intervals instead of the normal one-second intervals. In this case, have the battery replaced with a new one as soon as possible. The watch will remain accurate while the second hand moves at two-second intervals.

Note: The availability of this function varies depending on the caliber. For more information please visit www.headwatches.com

Documents / Resources



Manuals+,