

# **HELTEC AUTOMATION V3 Capsule Sensor Instruction Manual**

Home » HELTEC AUTOMATION » HELTEC AUTOMATION V3 Capsule Sensor Instruction Manual



### Contents

- 1 HELTEC AUTOMATION V3 Capsule
- **2 Product Usage Instructions**
- **3 Description**
- **4 Specifications** 
  - 4.1 LoRa RF Characteristics
- **5 Physical Dimensions**
- 6 Resource
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**



**HELTEC AUTOMATION V3 Capsule Sensor** 



### **Specifications**

• Product Name: Capsule Sensor V3

• Type: IoT Device

• Manufacturer: Chengdu Heltec Automation Technology Co.,Ltd.

• Wireless Technology: LoRa/LoRaWAN

• Microcontroller: ESP32-S3

• Transceiver: SX1262

• Battery: 250mA rechargeable battery

• Features: Tiny, waterproof, WirelessBoot technology

### **Product Usage Instructions**

#### Overview

The Capsule Sensor V3 is a portable IoT device based on ESP32-S3 and SX1262. It is designed to work with various sensors for building IoT applications easily.

### **Features**

- Modular design for sensor adaptability
- · WirelessBoot technology for easy setup
- Compact and stylish design
- Waterproof construction
- · Rechargeable battery for portability

### **Product Variants**

The Capsule Sensor V3 is available in two variants:

- 1. Capsule Sensor 433: For 433MHz LoRa frequency.
- 2. **Capsule Sensor 470to510:** For 470~510MHz working LoRa frequency, suitable for China mainland (CN470) LPW band, EU868, IN865, and other LPW networks.

### **Battery Charging**

To charge the 250mA rechargeable battery, use the provided charging cable and connect it to a power source. The device should be powered off during charging.

#### **Document version**

Version	Time	Description	Remark
V1.0	2024-01-16	Documents creating	Richard

#### **Copyright Notice**

All contents in the files are protected by copyright law, and all copyrights are reserved by Chengdu Heltec Automation Technology Co., Ltd. (hereinafter referred to as Heltec). Without written permission, all commercial use of the files from Heltec are forbidden, such as copy, distribute, reproduce the files, etc., but non-commercial purpose, downloaded or printed by individual are welcome.

#### **Disclaimer**

Chengdu Heltec Automation Technology Co., Ltd. reserves the right to change, modify or improve the document and product described herein. Its contents are subject to change without notice. These instructions are intended for you use.

### **Description**

### Overview

Capsule Sensor V3 is a tiny portable LoRa/LoRaWAN device based on ESP32-S3 and SX1262. Modular design allows it to adapt to different sensors, so you can easily build applications without being an expert in IoT. Thanks to WirelessBoot1 technology, Capsule Sensor V3 is small, stylish, waterproof, and has a 250mA rechargeable battery, making it perfect for complex environments.

Whether you want to build your applications or run open-source programs like Meshtastic2, Capsule Sensor V3 is a great choice.

Capsule Sensor are available in two product variants:

Table 1.1: Product model list

No.	Model	Description	
1	Capsule Sensor – 433	For 433MHz LoRa frequency	
		For 470~510MHz working LoRa frequency, used for	
2	Capsule Sensor – 470to510	China mainland (CN470) LPW band.	
		For EU868, IN865 and other LPW networks with	
3	Capsule Sensor – 863to870	operating frequencies between 863~870MHz.	
		For US915, AU915, AS923, KR920 and other LPW	
4	Capsule Sensor – 902to928	networks with operating frequencies between 902~92 8MHz	

#### **Product features**

- ESP32-S3 + SX1262.
- Wireless communication method include Wi-Fi, Bluetooth and LoRa.
- Modular design, with a BTB interface reserved at the bottom, capable of connecting and replacing different sensors.
- Built in 250mAh rechargeable battery, magnetic suction charging port.
- Built in LoRa and Wi-Fi/BLE antennas, stylish appearance, compact and light.
- · High strength plastic, IP65 waterproof.
- Support Heltec Wireless Boot system, download firmware, exchange information, and print logs through Wi-Fi.
- Meshtastic compatible.
- Secondary development can be done through Arduino, Platform.io, etc.

### **Application scenarios**

CapSule's application is mainly realized by replacing the sensor module, and here are just some typical application scenarios.

- · Environmental monitoring;
- · Data converter;
- Asset/pet/person tracking;
- · Children education;
- · Meshtastic;
- As a common Arduino development board.

### **Specifications**

### **General specifications**

Table 2-1: General specifications

Parameters	Description	
MCU	ESP32-S3FN8	
LoRa Chip	SX-1262	
Memory	384KB ROM; 512KB SRAM; 16KB RTC SRAM; 8MB SiP	
Frequency	433MHz, 470~510MHz, 863~870MHz, 902~928MHz	
Max TX Power	21 ± 1dBm	
Receiving sensitivity	-135dBm	
Wi-Fi	802.11 b/g/n	
Bluetooth	Bluetooth LE: Bluetooth 5, Bluetooth mesh	
Charging	5V, Magnetic 2P-2.54mm	
Battery	150mAh	
Protection grade	IP65	
Operating temperature	-20 ~ 60°C	
Dimensions	47mm * 26mmφ	

# **Flash Partitions**

Name	Туре	SubType	Offset	Size
nvs	data	nvs	0x009000	0x005000
otadata	data	ota	0x00e000	0x002000

арр	арр	ota_0	0x010000	0x250000
flashApp	арр	ota_1	0x260000	0x0A0000
spiffs	data	spiffs	0x300000	0x100000
factory	арр	factory	0x400000	0x100000
secondApp	арр	ota_2	0x500000	0x2D0000

# **Electrical Characteristics**

Table 2-2: Power supply

Parameter		Typical	Unit
	Charging	5	V
Power Supply	Battery	3.0~4.2	V
	LoRa Sending	230	mA
	LoRa Receiving	90	mA
Consumption	Sleep	18	uA

### LoRa RF Characteristics

### **Transmit Power**

Table2-3-1: Transmit power

Operating frequency band	Maximum power value/[dBm]
470~510	21 ± 1
867~870	21 ± 1
902~928	21 ± 1

# **Receiving Sensitivity**

The following table gives typically sensitivity level of the Capsule Sensor.

Table2-3-2: Receiving sensitivity

Signal Bandwidth/[KHz]	Spreading Factor	Sensitivity/[dBm]
125	SF12	-135
125	SF10	-130
125	SF7	-124


# **Operation Frequencies**

Capsule supports LoRaWAN frequency channels and models corresponding table.

Table2-3-3: Operation Frequencies

Region	Frequency (MHz)	
EU433	433.175~434.665	
CN470	470~510	
IN868	865~867	
EU868	863~870	
US915	902~928	
AU915	915~928	
KR920	920~923	
AS923	920~925	

# **Physical Dimensions**



# Resource

# **Relevant Resource**

- Heltec ESP32 framework (Already included Heltec ESP32 LoRaWAN library)
- Heltec LoRaWAN test server based on TTS V3
- User Manual Document
- Wireless Boot instructions

#### **Contact Information**

Heltec Automation Technology Co., Ltd Chengdu, Sichuan, China

Email: support@heltec.cn

Phone: +86-028-62374838

https://heltec.org

### Frequently Asked Questions (FAQ)

### Q: Can I use Capsule Sensor V3 in extreme weather conditions?

**A:** Yes, the Capsule Sensor V3 is waterproof and suitable for use in various environments, including extreme weather conditions.

#### Q: How do I switch between different sensor modules?

**A:** To switch between sensor modules, carefully detach the current module and attach the new one following the provided instructions in the user manual.

### Q: Is Capsule Sensor V3 compatible with third-party IoT platforms?

**A:** Yes, Capsule Sensor V3 can work with open-source IoT platforms like Meshtastic for enhanced functionality and connectivity.

### **Documents / Resources**



HELTEC AUTOMATION V3 Capsule Sensor [pdf] Instruction Manual V3 Capsule Sensor, Capsule Sensor, Sensor

### References

- Real-Time Bidding Platform | SSP, DSP Solutions Platform.IO
- # Heltec Automation –
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.