

HERCULES DJ Controller Inpulse 200 MKII Beginner Set Owner's Manual

Home » Hercules » HERCULES DJ Controller Inpulse 200 MKII Beginner Set Owner's Manual




HERCULES DJ Controller Inpulse 200 MKII Beginner Set



Contents

- 1 Description
- 2 BASS
- 3 TREBLE
- **4 VOLUME**
- **5 POWER SWITCH**
- **6 POWER INPUT**
- **7 OUTPUT**
- 8 INPUT
- 9 Bluetooth
- 10 Documents /
- Resources
 - 10.1 References
- 11 Related Posts

Description



BASS

Use the bass control for low frequency adjustment, turn left for decreasing low frequencies and turn right for increasing low frequencies.

TREBLE

Use the treble control for high frequency adjustment, turn left for decreasing high frequencies and turn right for increasing high frequencies.

VOLUME

With the volume control it's possible to adjust the input sensitivity, turn left for decreasing the input sensitivity and turn right for increasing the input sensitivity.

POWER SWITCH

Turns the loudspeaker on/off. Make sure the volume knob is set to minimum before turning it on!

POWER INPUT

Connect the included power adapter to this input and connect the other end of the cable to a power source.

OUTPUT

RCA connector for slave speaker (right).


INPUT

RCA input left and right.

Bluetooth

To pair with Bluetooth, first press the Bluetooth button until the Bluetooth blinks, then turn on the Bluetooth Settings on your mobile device, search the list of "MTO3B" devices, select it, and complete the pairing process. Once the pairing is complete, the Bluetooth button will be fixed in blue and you can enjoy the transmission from your mobile device. If you press the bluetooth button again, it will turn off.

Documents / Resources



HERCULES DJ Controller Inpulse 200 MKII Beginner Set [pdf] Owner's Manual 200 MKII, DJ Controller Inpulse 200 MKII Beginner Set, Controller Inpulse 200 MKII Beginner Set, Inpulse 200 MKII Beginner Set, Set

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.