



hidealite 7705424 Sharp Wall and Post Instruction Manual

[Home](#) » [hidealite](#) » hidealite 7705424 Sharp Wall and Post Instruction Manual 

Contents



- [1 hidealite 7705424 Sharp Wall and Post](#)
- [2 DIMENSION](#)
- [3 SYMBOLS](#)
- [4 SAFETY INSTRUCTIONS](#)
- [5 Accessories](#)
- [6 Installation – Sharp Wall](#)
 - [6.1 Installation](#)
- [7 Elektro Elco AB](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

hidealite

hidealite 7705424 Sharp Wall and Post




DIMENSION



Factory setting: 4000K | 31W

E-nr	Snro	El.nr	GTIN	Name	Color temp	Color (RAL)	Effect
770542 4	452818 3	310167 8	739297114522 8	Sharp Wall	3000/4000K	Grey (RAL 7042)	10,5W, 21W, 31 W
770542 5	452818 4	310167 9	739297114523 5	Sharp Wall	3000/4000K	Anthracite (RAL 7016)	10,5W, 21W, 31 W
770542 6	452818 5	310168 0	739297114524 2	Sharp P ost	3000/4000K	Grey (RAL 7042)	10,5W, 21W, 31 W
770542 7	452818 6	310168 1	739297114525 9	Sharp P ost	3000/4000K	Anthracite (RAL 7016)	10,5W, 21W, 31 W

SYMBOLS



For explanation of symbols see www.hidealite.se


This product contains a light source of energy efficiency class E to Regulation (EU) No 2019/2015.

SAFETY INSTRUCTIONS


Read these instructions carefully before commencing installation and retain for future reference. The luminaire should be installed by a licensed electrician and in accordance with local regulations. Make sure that the power is off before installation or maintenance.

Accessories

Corner bracket Sharp Wall











Mounting plate Sharp Wall



Installation – Sharp Wall





POWER OFF





Factory setting: 4000K | 31W





mA	Watt	3000K	4000K
250mA	10,5W	1100lm	1150lm
500mA	21W	1950lm	2000lm
750mA	31W	2900lm	2950lm




Installation


Sharp Post

POWER OFF







Accessories installation – Mounting plate Sharp Wall



Accessories installation – Corner bracket Sharp Wall



- Replaceable control gear by a professional




- Non-replaceable light source

Elektro Elco AB

- Tallvägen 5, SE-56435 Bankeryd, Sweden
- info@elco.se
- www.hidealite.se
- www.hidealite.com
- www.hidealite.fi
- www.hidealite.no
- www.hidealite.dk

Documents / Resources

	hidealite 7705424 Sharp Wall and Post [pdf] Instruction Manual 7705424 Sharp Wall and Post, 7705424, Sharp Wall and Post, Sharp Wall, Wall
---	---

References

- [h LED lighting of the highest quality - Hidealite](#)
- [h Vi udvikler og sælger LED belysning - Hidealite](#)
- [h LED-valaisimet & LED-valaistus kotiin ja julkisiin tiloihin - Hide-a-lite](#)
- [h LED-belysning, downlights, spotlights och utendørs belysning av topp kvalitet - Hidealite](#)
- [h LED-belysning & LED-armaturer för ditt projekt! - Hide-a-lite](#)

Manuals+.