



hidealite Arc and Arc Socket Instruction Manual

[Home](#) » [hidealite](#) » hidealite Arc and Arc Socket Instruction Manual 

hidealite Arc and Arc Socket Instruction Manual



Contents

- [1 SAFETY INSTRUCTIONS](#)
- [2 Symbols](#)
- [3 Specifications](#)
- [4 Dimensions](#)
- [5 Installation](#)
- [6 DIP-Switch dimming](#)
- [7 Installation – Arc Uttag](#)
- [8 DIP-Switch dimming](#)
- [9 Installation – External driver](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

SAFETY INSTRUCTIONS

Read these instructions carefully before commencing installation and retain for future reference. The luminaire should be installed by a licensed electrician and in accordance with local regulations. Make sure that the power is off before installation or maintenance.

Symbols



For explanation of symbols see www.hidealite.se




Specifications






E-nr	Snro	El.nr	GTIN	Name	LED color	Color	Total Effect
77 033 27	45 234 45	31 060 33	7392971131290	Arc	3000K	White	7W
77 033 28	45 234 46	31 060 34	7392971131306	Arc	3000K	Grey	7W
77 033 29	45 234 47	31 060 35	7392971131313	Arc	3000K	Anthracite	7W
77 033 30	45 234 48	31 060 36	7392971131320	Arc Socket*	3000K	White	7W
77 033 31	45 234 49	31 060 37	7392971131337	Arc Socket*	3000K	Grey	7W
77 033 32	45 234 50	31 060 38	7392971131344	Arc Socket*	3000K	Anthracite	7W

Dimensions




Installation














DIP-Switch dimming




Installation – Arc Uttag






DIP-Switch dimming



Installation – External driver



Elektro Elco AB, Tallvägen 5, SE-56435 Bankeryd, Sweden | info@elco.se | www.hidealite.se | www.hidealite.uk | www.hidealite.fi | www.hidealite.no | www.hidealite.dk

hidealite

Documents / Resources

	hidealite Arc and Arc Socket [pdf] Instruction Manual Arc and Arc Socket, Arc, Arc Socket
--	--

References

- [h Vi udvikler og sælger LED belysning - Hidealite](#)

- [!\[\]\(eae20f1adff742df783f6f7e3bbe72d1_img.jpg\) LED-valaisimet & LED-valaistus kotiin ja julkisiin tiloihin - Hide-a-lite](#)
- [!\[\]\(43c6e08c5a1618d745b54da5c843274e_img.jpg\) LED-belysning, downlights, spotlights och utendørs belysning av topp kvalitet - Hidealite](#)
- [!\[\]\(f5ee48910650695cea680b2433c1d60d_img.jpg\) LED-belysning & LED-armaturer för ditt projekt! - Hide-a-lite](#)
- [!\[\]\(da0f02caffeb5a74776a1d5d1892b059_img.jpg\) LED lighting of the highest quality - Hidealite](#)

Manuals+.