

HIKVISION

HIKVISION
DS-3WG105GP-SI
Router



HIKVISION DS-3WG105GP-SI Router User Guide


[Home](#) » [Hikvision](#) » HIKVISION DS-3WG105GP-SI Router User Guide 

Contents

- [1 HIKVISION DS-3WG105GP-SI Router](#)
- [2 Legal Information](#)
- [3 Safety Instructions](#)
- [4 Device Installation](#)
- [5 Packing List](#)
- [6 Mounting Methods](#)
- [7 Cable Connection](#)
- [8 Remote Management](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

HIKVISION[®]

HIKVISION DS-3WG105GP-SI Router



[Legal Information](#)

[About this Document](#)

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as “Hikvision”) makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- HIKVISION and other Hikvision’s trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED “AS IS” AND “WITH ALL FAULTS AND ERRORS”. HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS.

YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Applicable Models

This manual is applicable to DS-3WG router series, including DS-3WG105G-SI, DS-3WG105GP-SI, DS-3WG210GP-SI, and DS-3WG507G-SI models.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
<p>Note</p> 	<p>Provides additional information important points of the main text.</p> <p>to emphasize or supplement</p>
<p>Caution</p> 	<p>Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.</p>
<p>Danger</p> 	<p>Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.</p>

Safety Instructions

To ensure normal operation and prolong the lifespan of the device, read the safety precautions in this section carefully before installation. Note that the precautions do not cover every possible hazardous condition.

- Use the device indoors only and place it in a dry and well-ventilated location.
- To prevent potential damage from a fall, do not place the device on an unstable support platform, such as an unstable table.
- Keep the device clean and dust-free. Do not place it in humid locations or allow liquid intrusions.
- Do not place exposed flame sources, such as lit candles, on the device.
- Reserve a minimum clearance of 10 cm (3.94 in) around the device for heat dissipation.
- To avoid blocking the ventilation holes and hindering airflow, do not cover the ventilation holes with items such as newspapers, tablecloths, and curtains, or place the device on a sofa, carpet, or any other similar surface.
- To protect the signal ports on the device from damages caused by overvoltage and overcurrent from lightning

- strikes, route the interface cables for the device indoors. Do not route the interface cables outdoors
- Do not block the power socket or outlet for the device. Make sure the power socket or outlet is easily accessible.
 - Before connecting, installing, or removing the device, make sure power is disconnected from the device.
 - After removing the power connector for the device, power remains on the metal part of the connector. Do not touch the connector within 5 minutes.
 - Make sure the protective grounding of the device is connected reliably to the building's protective grounding.
 - Set up the grounding facility for the device separately and away from that of power distribution equipment and lightning protection system.
 - Position the device far away from high-power radio transmitters, radar transmitters, and high-frequency, high-current equipment.
 - Use only the power cord supplied with the device. Do not use any non-matching products. The power voltage must be in the input voltage range of the dedicated power cord.
 - If you notice any unusual symptom from the device such as smoke, strange smells, or abnormal noises, immediately disconnect power to the device and contact the distributor or service center.

Device Installation

- The models in this router series share similar installation procedures. This Manual uses the DS-3WG507G-SI router as an example. The figures in this Manual are for illustration only.
- Never place the device in an unstable location. The device may fall, causing serious personal injury or death. Install safety protection equipment if necessary. Check regularly.
- It is recommended to install the device according to the following instructions. We are not responsible for any results coming from individual arbitrary modification or installation.

Installation Tool

No installation tools are provided with the device. Prepare the installation tools yourself as required.

Always wear an ESD wrist strap when operating the device. Make sure the wrist strap makes good skin contact and is reliably grounded.

Table 1-1 Installation Tools

Name	Quantity
Flathead screwdriver	× 1
Phillips screwdriver	× 1
Needle-nose pliers	× 1
Wire stripper	× 1
Heat gun	× 1
Diagonal pliers	× 1
ESD wrist strap	× 1
Marker	× 1

Packing List

- The packing list varies by device. The actual packing list prevails.
- Any other installation accessories needed during installation, such as the M4 rack screw or floating nut, should be prepared by yourself.

Table 1-2 Packing List

Item	DS-3WG105G- SI	DS-3WG105GP- SI	DS-3WG210GP- SI	DS-3WG507G- SI
Smart Managed Router	× 1	× 1	× 1	× 1
Mounting Kit	–	–	–	× 1
Screw Anchor and Screw	× 1	× 1	–	–
Rubber Foot	–	–	–	× 4
Power Adapter	× 1	× 1	× 1	–
Releasable Cable Tie	–	–	–	× 1
AC Power Cord	–	× 1	× 1	× 1
Grounding Cable	× 1	× 1	× 1	× 1
Quick Start Guide	× 1	× 1	× 1	× 1
Regulatory Compliance and Safety Information	× 1	× 1	× 1	× 1

Mounting Methods

Mounting Device on Workbench

You can install DS-3WG105G-SI and DS-3W105GP-SI routers on a workbench directly without using rubber feet. For any of the other routers, you need to mount the device on a workbench according to the following instructions.

Danger

- Make sure the workbench is reliably grounded.
- Do not place heavy objects on the router.

Step 1 Attach the rubber feet to the bottom of the device.

Step 2 Place the router on the workbench with the top side facing upwards.



Figure 1-1 Mount Device on Workbench

Mounting Device in Rack

Only the DS-3WG507G-SI router can be installed in a rack.

Step 1 Install cage nuts on the rack posts.




Figure 1-2 Install Cage Nuts

Step 2 Attach mounting brackets to the device.



Figure 1-3 Attach Mounting Brackets

Step 3 Install the device in the rack.



Figure 1-4 Install Device in Rack

Cable Connection

Grounding Cable Connection

Step 1 Connect one end of the grounding cable to the grounding hole in the device.

Step 2 Connect the other end of the grounding cable to a grounding strip.




Figure 2-1 Connect Grounding Cable

Power Connection

Note

- Only the DS-3W507G-S| router can use an AC power cord for power input. The other router models use a power adapter for power input.
- Before connecting power to the device, make sure the device is reliably grounded. To avoid bodily injury, connect the power cord or power adapter first to the device and then to the power supply system in the equipment room.
- Use the power adapter that comes with the device to supply power to it. Using a mismatched power adapter could lead to damage due to issues like insufficient power.

Connecting Power Adapter

Connect one end of the power adapter to the power port on the device, and the other end to an external AC power outlet.




Figure 2-2 Connect Power Adapter

Connecting AC Power Cord

Step 1 Insert one end of the AC power cord into the AC power receptacle on the router and secure it with a cable tie.

Step 2 Connect the other end of the AC power cord to an external AC power outlet.




Figure 2-3 Connect AC Power Cord

Remote Management

The device models described in this manual can be set up and managed remotely by Hik-Partner Pro App (hereinafter referred to as HPP). The following briefly introduces the start-up steps of the device by using the HPP.

Before You Start:

- Complete device installation, cable connection, and network connection.
- Connect your phone to a Wi-Fi network and download the HPP.



Figure 3-1 Scan to Download HPP

- **Step 1** Open the HPP and scan the QR code on the device body.
- **Step 2** Lean your phone towards the device to join the device network.
- **Step 3** Enter a password to activate/verify the device.
- **Step 4** Follow the prompts to set device network.
- **Step 5** Follow the prompts to set device Wi-Fi network.
- **Step 6** Follow the prompts to add the device in a desired mode to a desired site.



Figure 3-2 Scan QR Code on Device body

WARRANTY CARD

Category	Product Type	Warranty (Month)
Analog Camera	Analog Camera	24
IP camera	1/2 Series IPC	24
Speed Dome	Speed Home	24
DVR	DVR	36
NVR	NVR	36
Commercial Monitor	LCD	36
	LED	12
	IFP	24
	Digital Signage	24
	Monitor	24
HDD	Decoder	36
	Hikvision HDD	36
Audio	Analog Audio	24
	IP Audio	36
Transmission	Switch	24
	Wireless Bridge	36
	Wireless Router	36
	AC	36
	AP	36
	UPS	24
	Cable	60
Acces Control	Access Control Terminal	24
	Card Reader	24
	Lock	24
Intercom	Video Intercom	24



Router
DS-3WG105GP-SI
Router
DS-3WG105GP-SI
Router
DS-3WG105GP-SI
Router
DS-3WG105GP-SI
Router
DS-3WG105GP-SI

[HIKVISION DS-3WG105GP-SI Router \[pdf\] User Guide](#) DS-3WG105GP-SI Router, DS-3WG105GP-SI, Router

References

- [H Hikvision USA - Leading the future of AIoT](#)
- [H Hikvision USA - Leading the future of AIoT](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.