



Home » Hikvision » HIKVISION DS-K1T341CMW Face Recognition Terminal Instructions

HIKVISION DS-K1T341CMW Face Recognition Terminal Instructions

September 4,

2025

Contents [hide]

- 1 DS-K1T341CMW Face Recognition Terminal
- 2 Product Information
 - 2.1 Specifications:
 - 2.2 Product Usage Instructions:
 - 2.2.1 Setting up the DS-K1T341CMW/CMFW with the Bosch Solution 6000 panel
 - 2.2.2 Wiring Diagram:
 - 2.3 FAQ (Frequently Asked Questions):
 - 2.3.1 Q: How do I reset the device to factory settings?
 - 2.3.2 Q: Can I connect multiple DS-K1T341CMW/CMFW terminals together?
 - 2.3.3 Documents / Resources
 - 2.3.3.1 References

DS-K1T341CMW Face Recognition Terminal

Product Information

Specifications:

Product Name: Hikvision DS-K1T341CMW/CMFW Face Recognition
 Terminal

Model: DS-K1T341CMW/CMFW

• Manufacturer: Hikvision

• Website: www.netdigital.com.au

Product Usage Instructions:

Setting up the DS-K1T341CMW/CMFW with the Bosch Solution 6000 panel

Refer to Page 9 on Bosch Solution 6000 Quick Reference Guide for detailed setup instructions.

- ADD TOKEN: Choose Reader Wi# Keypad #
 Name
- 2. **Step 7:** Present Face to Face Terminal, wait for the Read on the Solution 6000.
- 3. Step 8: For more faces, repeat Step 5.
- 4. **Step 9:** Press and Hold the Menu Key to Exit.

Wiring Diagram:

FAQ (Frequently Asked Questions):

Q: How do I reset the device to factory settings?

A: To reset the device to factory settings, follow these steps:

- 1. Access the device settings menu.
- 2. Navigate to the "Reset" or "Factory Reset" option.
- Confirm the reset action and wait for the device to restart.

Q: Can I connect multiple DS-K1T341CMW/CMFW terminals together?

A: Yes, you can connect multiple terminals together for a synchronized access control system. Refer to the user manual for detailed instructions on setting up multiple terminals.

"

View Fullscreen



Step 1: On DS-K1T341CMW/CMFW terminal · Activate Device at the Start Up Screen (Follow when prompted) · Keep following prompt to add Admin User

Step 2: · Hold Finger on screen until Swipe Finger Symbol appears, then Swipe Left · Log into Unit with Username and Pass Code · Go to User Icon and Press + · Edit Name · Add Card (this is required) then Press + You can use a generic number here, ie made up number OR

use a MiFare Card. \cdot Press Tick to Save \cdot Add Face and/or Fingerprint Press + to add then (Tick) to Save

Step 3: \cdot Go to Comm Icon \cdot Go to Wiegand – Tap to On and Change from Input to Output, leave as 26 Bit then Press <

Step 4: Exit Programme

Step 5: On Solution 6000 · Make Sure that you have set up Door Control on the Panel Refer Pg 9 on Bosch Solution 6000 Quick Reference Guide.

Step 6: Menu 1-2-0 · Select User

ADD TOKEN Choose Reader Wi# Keypad # Name

Step 7: Present Face to Face Terminal, wait for the Read on the Solution 6000.

Step 8: For more faces repeat Step 5.

Step 9: Press and Hold the Menu Key to Exit.

www.netdigital.com.au

Page 1

NetDigital Security | Ph: 03 9558 8088 | Address: 121/45 Gilby Rd, Mount Waverley VIC 3149 | Email: vicsales@netsecurity.com.au | Web: www.netdigital.com.au

Wiring Diagram:

www.netdigital.com.au

Page 2

NetDigital Security | Ph: 03 9558 8088 | Address: 121/45 Gilby Rd, Mount Waverley VIC 3149 | Email: vicsales@netsecurity.com.au | Web: www.netdigital.com.au

Documents / Resources



HIKVISION DS-K1T341CMW Face Recognition Terminal [pdf] Instructions DS-K1T341CMW, DS-K1T341CMW Face Recognition Terminal, Face Recognition Terminal, Recognition Terminal

References

- User Manual
- Hikvision
- ▶ DS-K1T341CMW, DS-K1T341CMW Face Recognition Terminal, Face Recognition Terminal, Hikvision, Recognition Terminal, Terminal

Leave a comment

Comment *			

Email				
Website				
☐ Save my name	email, and website in the	nis browser for the ne	ext time I comment.	

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.