



HILTI S-BT-ER W10 Screw-In Stud Instruction Manual

[Home](#) » [HILTI](#) » HILTI S-BT-ER W10 Screw-In Stud Instruction Manual 






S-BT-ER W10/M10 HC
2353586-03.2023

Contents


















[1 S-BT-ER W10 Screw-In Stud](#)



[2 Documents / Resources](#)


S-BT-ER W10 Screw-In Stud




















	SBT 4	SBT 6 SF 6
	TS-BT 5.3-65 S	
	TS-BT 5.3 HC	
	S-DG BT M10-W10/15 HC 6	
	Torque Tool S-BT 1/4" 16 Nm / 11.8 lb-ft	
	S-NS P 1/4" HKH 17 (M10) S-NS 9/16" C 95/3 1/4" (W10)	
	S-CC BT HC 6	






	SBT 6
	TS-BT 5.3-65 S
	TS-BT 5.3 HC
	S-SH BT M10/W10
	Torque Tool S-BT 1/4" 16 Nm / 11.8 lb-ft
	S-NS 15 C 95/3 1/4" S-NS 9/16" C 95/3 1/4"



Documents / Resources

	HILTI S-BT-ER W10 Screw-In Stud [pdf] Instruction Manual S-BT-ER W10 Screw-In Stud, S-BT-ER W10, Screw-In Stud, Stud
---	---

[Manuals+.](#)