




Home » HINKLEY » HINKLEY 1504BZ Carson LED Path Light Installation Guide 📆


HINKLEY 1504BZ Carson LED Path Light



Contents [hide]

- 1 Typical Ground Stake Mounting
- 2 Installation Instructions
- 3 Customer Support
- 4 Documents / Resources
 - 4.1 References

Typical Ground Stake Mounting



Installation Instructions

Item No: 1504

start here

- 1. Find a clear area in which you can work.
- 2. Unpack fixture and glass from carton.
- 3. Carefully review instructions prior to assembly.

SAVE THESE INSTRUCTIONS:

Note: This Luminaire is designed for use with Hinkley approved 12 volt landscape systems. Connection to other systems may cause premature failure or non-intended operation.

LUMINAIRE MOUNTING: (for typical ground stake mounting).

- 1. To prevent electrical shock, disconnect transformer from electrical supply before installation or service.
- 2. Run wire from Luminaire through mounting hole in top of ground stake.

- 3. Attach Luminaire to ground stake by threading to the mounting hole in stake until it fits snuggly against the bottom of stem.
 - Place stake in desired position and insert into ground until the flange of stake is flush with ground.
- 4. Strip the two wire leads from the Luminaire and connect to the main supply wire using the provided silicone filled wire nut. Silicone filled nuts are intended for one-time use. Wire Nut Capacity -2 pcs 18 AWG + 2 pcs 12 AWG

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS, IMPORTANT SAFETY INSTRUCTIONS.

- 1. Lamp gets hot quickly! Contact only switch / plug when turning on.
- 2. Do not touch hot lens, guard or enclosure.
- 3. Keep lamp away from materials that may burn.
- 4. Do not operate the luminaire fitting with a missing or damaged shield.
- 5. Luminaires shall not be installed within 10 feet (3m) of pool, spa or fountain.

The main low voltage cable from the Luminaire is to be:

- 1. Protected by routing in close proximity to the luminaire or fitting, or next to a building structure such as a house or deck.
- 2. The main secondary wire is intended for shallow burial less than 6 inches (15.2cm) in order to connect to the main low voltage cable.
- 3. Have the length cut off so that it is connected to a connector within 6 inches (15.2cm) from a building structure, a luminaire or fitting.

Customer Support

HINKLEY 33000 Pin Oak Parkway, Avon Lake, OH 44012 800.446.5539 / 440.653.5500 hinkley.com

HINKLEY

Documents / Resources



HINKLEY 1504BZ Carson LED Path Light [pdf] Installation Guide

1504BZ, 1531-3-4, 1504BZ Carson LED Path Light, 1504BZ, Carson LED Path Light, LED Path Light, Path Light

References

- H<u>HINKLEY</u>
- User Manual
- HINKLEY

Website

◆ 1504BZ, 1504BZ Carson LED Path Light, 1531-3-4, Carson LED Path Light, HINKLEY, LED Path Light, Path Light

—Previous Post

HINKLEY 903352FMM-LIA Metro Illuminated LED Ceiling Fan Instruction Manual

Next Post—

HINKLEY 15030OZ-LL Freeport Coastal Elements Freeport LED Path Light Instruction Manual

Leave a comment

| Your email address will not be published. Required fields are marked* |
|---|
| Comment * |
| |
| |
| |
| |
| Name |
| |
| Email |
| |

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.