



hitron CGNDP3M Coax Network Testing Meter User Guide

[Home](#) » [Hitron](#) » hitron CGNDP3M Coax Network Testing Meter User Guide 



Contents

- [1 CGNDP3M Coax Network Testing Meter](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

CGNDP3M Coax Network Testing Meter


	Battery Level
	Battery Charging Indicator
	Wi-Fi Indicator
	DOCSIS Registration Indicator
	Upstream Ranging Indicator
	Downstream Scan Indicator
	Power Indicator

S-Reset: Short press for a reboot

S-Reset: 6+ seconds for factory reset (When Wi-Fi is broadcasting)

H-Reset: Force power off



		Charge:100%
		75%
		50%
		25%
		(Red/Green/Blue blinking) <10%
		

		Charging
		Wi-Fi Broadcasting
online		Registration Complete
		Registration in Progress
US		Upstream Ranging Complete
		Upstream Ranging
DS		Downstream Lock Complete
		Scanning Downstream
		Power on
		Port1: AC Detected
		Port2: AC Detected

1. Attach barrel and jumper to Port 1 and route jumper through jumper guide. Terminate Port 2 if not in use (Port 2 is designed for advanced functions).
2. Power on CGNDP3M and connect to CGNDP3M Wi-Fi under device settings :
SSID: CGNDP3M-(last 4 of MAC)
Password: default key

For certification statements and Safety Warnings, please go to: us.hitrontech.com/cgndp3m
Keep this card inside the carrying bag



P3300066VN42

Documents / Resources



[hitron CGNDP3M Coax Network Testing Meter](#) [pdf] User Guide

CGNDP3M, Coax Network Testing Meter, Network Testing Meter, Testing Meter, CGNDP3M, Meter