

hitron CGNM-2250 WiFi Modem Self-Connect Router User Guide

[Home](#) » [Hitron](#) » hitron CGNM-2250 WiFi Modem Self-Connect Router User Guide 



Contents

- [1 hitron CGNM-2250 WiFi Modem Self-Connect Router User Guide](#)
- [2 Wi-Fi Modem Self-Connect Guide](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)




Wi-Fi Modem Self-Connect Guide

- Connect the supplied coaxial cable to the wall plate
- Connect the other end to the modem
- Ensure the connectors are as tight as you can possibly make them
- Plug in the supplied power cord to the modem
- Plug the other end of the power cord into the wall
- Lights should come on
- Wait 5 minutes.



- Connect your cable (network) to your PC, if you need to, with the supplied Ethernet/ Network Cable
- Search for the Wi-Fi connection, if applicable, which is labeled on the back of the modem (network name, SSID, etc)

- Insert the supplied password
- Test connectivity
- In a small number of cases, the modem may reboot after 15 minutes. This is normal, however, if the modem lights do not look the same as above, please call us
- If the lights look like this after 5 min try another outlet (location).
- [Login and Reset Instructions](#)



To watch an instructional video, please visit support.westmancom.com and search for “Self-Connect”.

204.725.4300

1.800.665.3337

westmancom.com

Read More About This Manual & Download PDF:

Documents / Resources

	<p>hitron CGNM-2250 WiFi Modem Self-Connect Router [pdf] User Guide CGNM-2250, WiFi Modem Self-Connect Router, CGNM-2250 WiFi Modem Self-Connect Router</p>
--	---

References

- [Westman Communications Group - Customer Support Portal - Home](#)
- [Westman Communications Group: Your local telecommunications provider](#)