

hohem HRT-03 All-in-One Remote Control User Manual

Home » hohem » hohem HRT-03 All-in-One Remote Control User Manual

Contents

- 1 hohem HRT-03 All-in-One Remote
- 2 Pairing the remote control with the gimbal
 - 2.1 During the pairing process:
- 3 Specifications
- **4 FCC Statement**
- **5 Documents / Resources**
- **6 Related Posts**



hohem HRT-03 All-in-One Remote Control



Pairing the remote control with the gimbal

Please press the function button of the gimbal 7 times once the gimbal is turnedon, the bluetooth light will flash alternately in yellow and green and enter the pairing mode.

haeke pasiruirnegt hmeogdiem beafolirseo the rimote control

During the pairing process:

- a.The pairing can be completed in 3 seconds after the gimbal Bluetooth light stop flashing alternately in yellow and green;
- b. Ifthe remote-control isnot paired within 30 seconds, the pairing will be canceled;
- c. Click the function button to caricelpairing;
- d. Double-deck the function button to clear the paired remote control and cancel pairing; (And the paired remote control will be unavailable and need tobe repaired)

1. Power Button

ON: PowerOn **OFF**: PowerOff

2. @Shutter Button

Make sure the app connects to the gimbal successful} Single Press: Take a photo,S tart/End video Double Press: Switch the photo and video modes TriplePress: Switch the front and rear cameras (Only available in the app)

3. Function Button

Single Press: Switch the landscape and portrait modes

Double Press: Recenterthegimbal

Triple Press: inception(Autorotation

4. M Button (Gimbal working Mode)

Single Press: Pan&Tilt Follow

Double Press: Pan Follow

TriplePress: Alllock

Quartic Press: POV (All Follow)

Long Press: Switch the zoom in/out mode and gimbal tilt control mode (Zoom in/out mode only available in the


app)

5. Navigation Buttons: Up/Down/Left/Right

- Tilt ControlOndicator light shows green)
- Control the image zoom in/out (Indicator light shows blue and only available inthe app)
- Left/Right:PanControl

6. Indicator light

The indicator light shows green or blue in button operation. If no lights hows, it means the remote control is not turned on or no battery. Greenlight: Gimbal controlling Blue light: Phone camera controlling



Specifications

Product Model	HRT-03	Notice
Product Name	All-in-one Remote Control	The remote control is built with a button battery. When the battery is low or power off, the indicator light will not light up. Please open the back cover of the remote control to replace the battery.
Size	38*27*8mm	
Weight	10g	
Remote Control Transmission Distance (Straight line without stuck)	10m	

FCC Statement

Federal Communication Commission (FCC) Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirements, The device can be used in portable exposure condition without restriction

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized

modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources



hohem HRT-03 All-in-One Remote Control [pdf] User Manual RT, 2AIB7RT, HRT-03 All-in-One Remote Control, HRT-03, All-in-One Remote Control

Manuals+,