



## HOLMAN CO1605 Digital Tap Timer User Guide

[Home](#) » [Holman](#) » HOLMAN CO1605 Digital Tap Timer User Guide 

### Contents

- [1 HOLMAN CO1605 Digital Tap Timer](#)
- [2 GLOSSARY](#)
- [3 INSTALLATION](#)
  - [3.1 BATTERY INSTALLATION](#)
- [4 MANUAL WATERING](#)
- [5 TECHNICAL DATA](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)




**HOLMAN CO1605 Digital Tap Timer**



[www.holmanindustries.com.au](http://www.holmanindustries.com.au)

## GLOSSARY



- A. UNIVERSAL TAP ADAPTOR
- B. TAP CONNECTION
- C. UNION NUT
- D. LCD DISPLAY
- E. CONTROL BUTTONS
- F. BATTERY COMPARTMENT

- G. CLEAR SCREW-ON COVER
- H. SNAP-ON HOSE CONNECTION

## INSTALLATION

Make sure the washer is in place, then screw the Tap Timer to the tap. Turn it clockwise (hand tighten only)  
There should be no need to use thread seal tape, as long as the tap seals onto the washer

## BATTERY INSTALLATION



1. Hold the tap timer with the battery compartment facing you
  2. Remove the battery compartment tray
- Connect a 9V ALKALINE battery to the battery connector  
Insert the connected battery and push in the battery tray

When changing a battery, the timer will hold the current program if you fit the battery within 2 minutes. When changing the battery, make sure the battery compartment stays dry


Use only 9V ALKALINE batteries

## SETTING THE CURRENT TIME



1. Press until the clock is displayed in the top left corner next to 'TIME'. This means you are in 'TIME' mode
2. Press ARROW-CIRCLE-RIGHT and the hour will flash
3. Press PLUS-CIRCLE or Minus-Circle to adjust the hour
4. Press ARROW-CIRCLE-RIGHT to select the minutes
5. Press PLUS-CIRCLE or Minus-Circle to adjust the minutes
6. Press ARROW-CIRCLE-RIGHT to select the day (the black box will be flashing)
7. Press PLUS-CIRCLE to reach the current day. Press ARROW-CIRCLE-RIGHT to save the day


## SETTING THE DURATION



'DURATION' is the length of time you want the water to run for

1. Press until the hour glass is displayed on the left next to 'DURATION'. This means you are in 'DURATION' mode
2. The hour display will be flashing, press PLUS-CIRCLE or Minus-Circle to adjust the hour
3. Press ARROW-CIRCLE-RIGHT to select the minutes
4. Press PLUS-CIRCLE or Minus-Circle to adjust the minutes

## SETTING THE WATERING DAYS



'DAYS' is where you select what day(s) you want to water on

1. Press until the calendar is displayed on the left next to 'DAYS'. This means you are in 'DAY' mode
2. Press ARROW-CIRCLE-RIGHT and the black box under 'M' will flash
3. Press PLUS-CIRCLE to select that day, press Minus-Circle to deselect that day

4. Press ARROW-CIRCLE-RIGHT to scroll through the days, press PLUS-CIRCLE if you need to reselect that day
5. Press to save the schedule


## SETTING THE START TIMES



'STARTS' is the time of day you want your watering to begin. You can schedule up to 4 start times per day

1. Press until the alarm clock is displayed in the bottom left corner next to 'STARTS'. This means you are in 'STARTS' mode
2. Start '1' is the time you want your watering to first begin. Use PLUS-CIRCLE or Minus-Circle to adjust the hour
3. Press ARROW-CIRCLE-RIGHT then PLUS-CIRCLE or Minus-Circle to adjust the minutes
4. Press to change to the next start time and repeat steps 2 and 3
5. To turn a start time 'OFF' adjust the 'HOUR' until it reads 'OFF'

## MANUAL OPERATION



No 'MANUAL' allows you to manually turn on your tap timer and set a watering duration.

This will not effect your automatic schedule.

## MANUAL OPERATION CONT

1. Press – to begin manual watering. The pre-set time is 10 minutes. This will start automatically unless the duration is changed

2. Manually set the duration time using – or –
3. Once the watering duration has finished the tap timer will automatically end watering and return to the automatic schedule

## SUSPENDING OPERATION

Use this feature when you want to temporarily suspend the automatic schedule. This feature is generally used when it has been raining or during winter.

**Suspension:** Press w


## MANUAL WATERING

### OPTION 1: Manual Watering

To start Manual Watering, turn the 'INTERVAL' dial to 'RESET'. Turn the 'RUN TIME' dial to 'ON'. Turn on your tap and water as needed. To stop watering, turn your tap off. Turn the 'RUN TIME' dial to 'OFF', or re-enter the watering operation

### OPTION 2: Manual Watering (Auto-Stop)

To start Manual Watering with an auto-stop, turn the 'INTERVAL' dial to 'RESET'. Turn the 'RUN TIME' dial to the desired time you wish to water for. Turn on your tap, watering will stop once 'RUN TIME' minutes have lapsed



## TECHNICAL DATA

**PRODUCT:** Low Pressure Tap Timer

**PRODUCT CODE:** CO1603

**MAXIMUM WATER PRESSURE:** 600 kPa

**BATTERY:** Use 2 x AAA ALKALINE batteries

**FLUID:** Only use cold water with NO added chemicals

**FREQUENCY OPTIONS:** Every 1 hrs, 2 hrs, 3 hrs, 4 hrs, 6 hrs, 8 hrs, 12 hrs, 24 hrs, 48 hrs, 72 hrs, Week, Reset

**RUN TIME OPTIONS:** 1, 3, 5, 10, 15, 20, 30, 60, 90, 120, ON, OFF

**WARNINGS:** Do not use this device without the appropriate filter

Every 4 seconds the LED will flash to confirm the battery is working. If the LED flashes any quicker, please replace the batteries

We really appreciate having you as a customer, and would like to say thank you for choosing us. Should you have

any questions about this product or its operation please call customer service on 1300 716 188


Head Office/Service

11 Walters Drive, Osborne Park WA 6017 Tel: +61 8 9416 9999 Fax: +61 8 9416 9920

[support@holmanindustries.com.au](mailto:support@holmanindustries.com.au) [www.holmanindustries.com.au](http://www.holmanindustries.com.au)

Copyright © 2020 Holman Industries

## Documents / Resources



[HOLMAN CO1605 Digital Tap Timer](#) [pdf] User Guide  
CO1605, Digital Tap Timer

[Manuals+](#)