



## HOLMAN Digital Tap Timer CO1605 User Guide

[Home](#) » [Holman](#) » HOLMAN Digital Tap Timer CO1605 User Guide 

### HOLMAN Digital Tap Timer CO1605



## Contents

- [1 BATTERY INSTALLATION](#)
- [2 GLOSSARY](#)
- [3 INSTALLATION](#)
- [4 SETTING THE CURRENT TIME](#)
- [5 SETTING THE DURATION](#)
- [6 SETTING THE WATERING DAYS](#)
- [7 SETTING THE START TIMES](#)
- [8 MANUAL OPERATION](#)
- [9 SUSPENDING OPERATION](#)
- [10 TROUBLESHOOTING](#)
- [11 FUNCTIONS](#)
- [12 MAINTENANCE](#)
- [13 TECHNICAL DATA](#)
- [14 Documents / Resources](#)
- [15 Related Posts](#)

## BATTERY INSTALLATION

1. Hold the Tap Timer with the BATTERY COMPARTMENT facing you
2. Remove the BATTERY COMPARTMENT tray
3. Connect a 9V alkaline battery to the battery connector
4. Insert the connected battery and push in the BATTERY COMPARTMENT tray

**i** When changing a battery, the Tap Timer will hold the current program if you fit the battery within 2 minutes. When changing the battery, make sure the battery compartment stays dry

**i** Use only 9V alkaline batteries



## GLOSSARY

- A. UNIVERSAL TAP ADAPTOR
- B. TAP CONNECTION
- C. UNION NUT
- D. LCD DISPLAY

- E. CONTROL BUTTONS
- F. BATTERY COMPARTMENT
- G. CLEAR SCREW-ON COVER
- H. SNAP-ON HOSE CONNECTION



## INSTALLATION

Make sure the washer is in place, then screw the Digital Tap Timer to the tap. Turn it clockwise (hand tighten only).


**i** There should be no need to use thread seal tape, as long as the tap seals onto the washer

## SETTING THE CURRENT TIME



1. Press Undo-Alt until the clock is displayed in the top left corner next to TIME. This means you are in TIME mode
2. Press **➡** and the hour will flash
3. Press **+** or **-** to adjust the hour
4. Press **➡** to select the minutes
5. Press **+** or **-** to adjust the minutes
6. Press **➡** to select the day (the black box will be flashing)
7. Press **+** to reach the current day. Press **➡** to save the day


## SETTING THE DURATION



**DURATION** is the length of time you want the water to run for.

1. Press until the hour glass is displayed on the left next to **DURATION**. This means you are in **DURATION** mode
2. The hour display will be flashing, press or Minus-Circle to adjust the hour
3. Press to select the minutes
4. Press or Minus-Circle to adjust the minutes


## SETTING THE WATERING DAYS



**DAYS** is where you select what day(s) you want to water on.


1. Press until the calendar is displayed on the left next to **DAYS**. This means your are in **DAYS** mode
2. Press and the black box under **M** will flash
3. Press to select that day, press to deselect that day
4. Press to scroll through the days, press if you need to reselect that day
5. Press to save the schedule

## SETTING THE START TIMES



1. Press until the alarm clock is displayed in the bottom left corner next to **START**. This means you are in **START** mode
2. Start **1** is the time you want your watering to first begin. or to adjust the hour
3. Press then or to adjust the minutes
4. Press to change to the next start time and repeat steps 2 and 3
5. To turn a start time **OFF** adjust the **HOUR** until it reads **OFF**

## MANUAL OPERATION



**MANUAL** allows you to manually turn on your tap timer and set a watering duration.

This will not effect your automatic schedule


1. Press to begin manual watering. The pre-set time is 10 minutes. This will start automatically unless the duration is changed
2. Manually set the duration time using or
3. Once the watering duration has finished the **Tap Timer** will automatically end watering and return to the automatic schedule

## SUSPENDING OPERATION

Use this feature when you want to temporarily suspend the automatic schedule. This feature is generally used when it has been raining or during winter.

Suspension: Press and the sprinkler off icon will appear.

The schedule is now suspended.

Cancel Suspension: to resume the automatic schedule press  .

Manual operation can still be used during suspension.

## TROUBLESHOOTING

To stop manual or automatic watering press  .



Low battery warning: The battery indicator has 5 levels. 4 levels of battery and 1 flashing bar when the battery is flat. The **Tap Timer** will not water when the battery is in this mode. We advise to change the battery when it is down to 2 bars to ensure reliable watering.

## FUNCTIONS



Press to end manual or automatic watering



Press to scroll through the programming modes



Press to decrease time or eliminate a day



Press to increase time or add a day



Press to select a function



Press to begin manual watering

## MAINTENANCE

Remove the battery if the **Tap Timer** will not be used for a long period of time. The **Tap Timer** contains an internal filter which has to be removed and cleaned every few months.

## TECHNICAL DATA

Max Water Pressure: 600kPa Min Water Pressure: 60kPa  
Flow Rate: 19L/min at 200kPa Power Source: 9 volt alkaline battery  
Power Consumption: 20 micro amps in standby mode

We recommend registering your new product to ensure we have a copy of your purchase, and to activate an extended warranty. Keep up to date with relevant product information and special offers available through our newsletter.

[www.holmanindustries.com.au/product-registration/](http://www.holmanindustries.com.au/product-registration/)

We really appreciate having you as a customer, and would like to say thank you for choosing us. Should you have any questions about this product or its operation please call customer service on 1300 716 188

# HOLMAN

Head Office/Service

11 Walters Drive, Osborne Park WA 6017


**Tel:** +61 8 9416 9999

**Fax:** +61 8 9416 9920

[support@holmanindustries.com.au](mailto:support@holmanindustries.com.au)

[www.holmanindustries.com.au](http://www.holmanindustries.com.au)

## Documents / Resources



[HOLMAN Digital Tap Timer CO1605](#) [pdf] User Guide

HOLMAN, Digital, Tap Timer, CO1605

[Manuals+.](#)