



# HOMCOM 824-043V70 Oscillating Tower Fan User Manual

[Home](#) » [HOMCOM](#) » HOMCOM 824-043V70 Oscillating Tower Fan User Manual 

## Contents

- [1 HOMCOM 824-043V70 Oscillating Tower Fan](#)
- [2 SPECIFICATION](#)
- [3 FUNCTIONS & OPERATION](#)
- [4 ASSEMBLING](#)
- [5 CLEANING AND MAINTENANCE](#)
- [6 ACCESSORY](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)



**HOMCOM 824-043V70 Oscillating Tower Fan**




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.













## SPECIFICATION

RATED VOLTAGE TENSION NOMINALE	RATED POWER PUISSANCE NOMINALE
220-240V~,50HZ	60W


## FUNCTIONS & OPERATION

### Plug in first







- Push the button  to start and stop the fan.

- **SPEED button:** Push the button  to select speed of: Low  – Middle  –High 
- **TIMER button:** Push  to select the timers from 1hours to 8 hours, it will show on the display panel
- **MODE button:** Push the button  to select mode of Normal , "Nature" , "Sleep" .
- **SWING button:** Push the button  to oscillate the fan, and push it again to stop the function.
- **Negative ion function:** Push the button  for 3 seconds to start function of the negative function, push the button  for 3 seconds to stop the function.


All the buttons are on the control panel as below:



## REMOTE CONTROL

- Push the button  to start the fan
- Push the button  to select fan speed of Low- Middle –High
- Push the button  to select mode of "Normal", "Nature", "Sleep"
- Push the button  to oscillate the fan, push it again to stop the function
- Push the button  to select the timers from 1 hours to 8 hours.
- Push the button  to select the negative ion function.

## ASSEMBLING



- **Step 1:** Aiming the assemble poles with the corresponding holes, and insert the poles into the holes.
- **Step 2:** Aiming the assembled base to screw poles of the fan body
- **Step 3:** After well connect of the body and base, screw into the screw holes of the base. And put the power cord into the slot of the base.
- **Step 4:** Put the fan flatly



- In the front of the fan, there is a small box below the vent. There is a sponge inside the fragrance box.
- Take out the box and put some fragrance on the sponge if you would like the wind blow with fragrance.

## CAUTION

1. Use as per the rating voltage.
2. Do not repair or remake the appliance by yourself, it should be repaired by the repairmen.
3. Do not operate the appliance with wet hands, in order to avoid damage.

4. If the supply cord is damaged, it must be replaced by a same cord from the manufacturer or its service agents.
5. When the appliance is not in use, switch it off and unplug it.
6. Do not insert things to air outlets and inlets, in order to avoid damage.
7. Do not use the appliance near explosive and combustible gas.
8. Use the appliance only on a flat surface.
9. Do not use outdoors.
10. Do not turnover the appliance. Unplug the power supply if it is toppled over and there have some water in the body. Dry the body before use. 13. Clean the appearance with a lightly damp cloth. It can clean with neutral detergents. Do not rinse with water.
11. Do not make air outlets and inlets near the wall or curtain.
12. Do not knock or shake the body when use, otherwise it may cause stop.
13. The appliance must not be located immediately below a socket outlet. The rating current of socket should exceed 10A.
14. Do not use the appliance in the immediate surrounding of a bath, a shower or a swimming pool.
15. This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
16. Children should be supervised to ensure that they do not play with the appliance.

## **CLEANING AND MAINTENANCE**

- Clean with neutral detergent and soft cloth.
- **Attention:** unplug the power plug when clean the appliance, since there is high pressure in the body. Do not leave any water on the control panel.

## **ACCESSORY**

- Screws for assemble the base ;
- Remote control

If you have any questions, please contact our customer care center.

### **Our contact details are below:**

- 0044-800-240-4004
- [enquiries@mhstar.co.uk](mailto:enquiries@mhstar.co.uk)

## **IMPORTER ADDRESS**

- MH STAR UK LTD
- Unit 27, Perivale Park, Horsenden lane South Perivale, UB6 7RH
- MADE IN CHINA

## **Documents / Resources**



[HOMCOM 824-043V70 Oscillating Tower Fan](#) [pdf] User Manual  
824-043V70, 824-043V90, 824-043V70 Oscillating Tower Fan, Oscillating Tower Fan, Tower Fan, Fan

References

[Manuals+](#).