Manuals+ — User Manuals Simplified.

homematic IP HmIP-BRA-A Button Rocker for Band Switch System Instruction Manual

homematic IP HmIP-BRA-A Button Rocker for Band Switch System Instruction Manual

Contents

Information about this manual

Please read this manual carefully before beginning operation with your Homematic IP component. Keep the manual so you can refer to it at a later date if you need to. If you hand over the device to other persons for use, please hand over this manual as well.

Symbols used:

⚠️ **Attention!**
This indicates a hazard.

ℹ️ **Please note:**
This section contains important additional information

Function and device overview

The Homematic IP Button Rocker for brand switch systems can simply be clicked to a Homematic IP actuator (e.g. switch actuator or blind actuator for brand switch systems) to switch the actuator via the pushbutton rocker.

Installation is very easy thanks to the adapter that is already inserted into the push-button rocker and the design customized to Hematic IP actuators.

Mounting

Due to the push-button design in the dimension of 55 mm, also most popular brand manufacturers can be integrated as an alternative to the enclosed removable frame.

Device overview (see figure 1):

(A) Clip-on frame
(B) Adapter
(C) Push-button rocker
(D) Button 1 (e.g. on/higher/up, depending on the Homematic IP actuator)

(E) Button 2 (e.g. off/darker/down, depending on the Homematic IP actuator)

Mounting

⚠️ In parallel to this mounting instruction, please also refer to the installation instructions as well as hazard and safety instructions in the user manual of the respective wireless actuator.
To install the button rocker and the clip-on frame, please proceed as follows:

- Place the clip-on frame (A) onto the installed Homematic IP actuator (see fig. 2). Alternatively, you can continue using the existing frame with an inner dimension of 55 mm (see "4 Mounting into frames of other manufacturers" on page 12).
- Place the push-button rocker (C) with the already inserted adapter (B) into the clip-on frame, so that both latching lugs fit into the existing elongated holes **(see figure 3).**

Mounting into frames of other manufacturers

An over of compatible frames of other manufacturers can be found in the download area at **www.homematic-ip.com**

Maintenance and cleaning

⚠️ The button rocker is maintenance-free. Enlist the help of an expert to carry out any maintenance.

ⓘ Clean the device using a soft, lint-free cloth that is clean and dry. You may dampen the cloth a little with lukewarm water in order to remove more stubborn marks. Make sure that no moisture will ingress into the actuator. Do not use any detergents containing solvents, as they could corrode the plastic housing and label.

Technical specifications

Short description: HmIP-BRA-A
Ambient temperature: 5 to 35 °C
Dimensions : (W x H x D): 86 x 86 x 16 mm
Weight: 45 g

Subject to technical changes.

Instructions for disposal

Do not dispose of the device with regulardomestic waste! Electronic equipment must be disposed of at local collection points for waste electronic equipment in compliance with the Waste Electrical and Electronic Equipment Directive.

Information about conformity

The CE sign is a free trading sign addressed exclusively to the authorities and does not include any warranty of any properties.

For technical support, please contact your retailer.

Kostenloser Download der Homematic IP App! Free download of the Homematic IP app!

Bevollmächtigter des Herstellers:
Manufacturer's authorised representative:

Maiburger Straße 29 26789 Leer / GERMANY   **www.eQ-3.de**

Documents / Resources

	homematic IP HmIP-BRA-A Button Rocker for Band Switch System [pdf] Instruction Manual HmIP-BRA-A, HmIP-BRA-A Button Rocker for Band Switch System, HmIP-BRA-A Button Rocker, Button Rocker for Band Switch System, Rocker for Band Switch System, Button Rocker, Switch System

References

- **Startseite - eQ-3**
- **Home page | Homematic IP**